

# ENGINEER PROGRAMMING MANUAL

**ECLIPSE 8**  
**ECLIPSE 8+**  
**ECLIPSE 16**  
**ECLIPSE 32**  
**ECLIPSE 99**

(S.W. 3.xx)

**ALARM CONTROL PANELS**



**Attention:**

This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer. The entire manual should be carefully read.

The information in this manual is a subject to change without notice!

**Table of Contents:**

1. GENERAL INFORMATION .....	4
2. SUPPORTED KEYBOARDS FOR PROGRAMMING AND OPERATION .....	7
2.1. LED/LCD Keyboards .....	7
2.2. Supported Trouble Events in ECLIPSE Series.....	8
2.3. Buttons Functions .....	9
2.4. Sound Signalization from Keyboards .....	10
2.5. General Information for Operation with LED 8/16A .....	10
2.6. General Information for Operation with LED 16A VG and LED32.....	12
2.7. General Information for Operation with LCD Keyboard.....	13
2.8. Entering text for LCD Keyboard.....	13
3. PROGRAMMING WITH SPECIALIZED ProsTE SOFTWARE .....	15
4. OPERATION WITH A SERVICE KEYBOARD .....	15
5. ENROLLING/DELETING OF DEVICES .....	17
5.1. Enrolling Devices during the Initial Start-up of the Control Panel.....	17
5.2. Enrolling Devices to a working system configuration via LCD keyboard .....	17
5.3. Enrolling Devices to a working system configuration via LED keyboard.....	18
5.4. Deleting of a device from the system configuration.....	18
6. ENGINEER PROGRAMMING .....	19
6.1 Organization of the Engineer Programming Menus .....	19
6.2 Indication.....	19
6.3 Special Symbols in this Manual .....	20
7. ENGINEER MENUS – Programming Tables .....	21
1. MAINTENACE MENU.....	21
2. SETTINGS MENU .....	23
3. CODES MENU .....	30
4. INPUTS MENU .....	37
5. OUTPUTS.....	49
6. PARTITIONS .....	58
7. SCHEDULES.....	65
8. COMMUNICATION.....	69
9. DEVICES .....	77
APPENDIXES.....	86
APPENDIX 1. Memory LOG Events .....	86
APPENDIX 2. FIRE DELAY Operation Algorithm .....	89
APPENDIX 3. VD/DTMF Operation Algorithm .....	89
APPENDIX 4. Text Tree-Structure Menus ECLIPSE Series.....	90
APPENDIX 5. Style Diagrams for Zone Connection .....	99

## GUARANTEE

### The guarantee terms are determined by the serial number (barcode) of the electronic device!

During the guarantee period the manufacturer shall, at its sole discretion, replace or repair any defective product when it is returned to the factory. All parts replaced and/or repaired shall be covered for the remainder of the original guarantee, or 6 months, whichever period is longer. The original purchaser shall immediately send manufacturer a written notice of the defective parts or workmanship.

### INTERNATIONAL GUARANTEE

Foreign customers shall possess the same guarantee rights as those any customer in Bulgaria, except that manufacturer shall not be liable for any related customs duties, taxes or VAT, which may be payable.

### GUARANTEE PROCEDURE

The guarantee will be granted when the appliance in question is returned. The guarantee period and the period for repair are determined in advance. The manufacturer shall not accept any product, of which no prior notice has been received via the RAN form at: <https://teletek-electronics.com/en/ran-form>

The setup and programming included in the technical documentation shall not be regarded as defects. Teletek Electronics JSC bears no responsibility for the loss of programming information in the device being serviced.

### CONDITIONS FOR WAIVING THE GUARANTEE

This guarantee shall apply to defects in products resulting only from improper materials or workmanship, related to its normal use. It shall not cover:

- Devices with destroyed serial number (barcode);
- Damages resulting from improper transportation and handling;
- Damages caused by natural calamities, such as fire, floods, storms, earthquakes or lightning;
- Damages caused by incorrect voltage, accidental breakage or water; beyond the control of the manufacturer;
- Damages caused by unauthorized system incorporation, changes, modifications or surrounding objects;
- Damages caused by peripheral appliances unless such peripheral appliances have been supplied by the manufacturer;
- Defects caused by inappropriate surrounding of installed products;
- Damages caused by failure to use the product for its normal purpose;
- Damages caused by improper maintenance;
- Damages resulting from any other cause, bad maintenance or product misuse.

In the case of a reasonable number of unsuccessful attempts to repair the product, covered by this guarantee, the manufacturer's liability shall be limited to the replacement of the product as sole compensation for breach of the guarantee. Under no circumstances shall the manufacturer be liable for any special, accidental or consequential damages, on the grounds of breach of guarantee, breach of agreement, negligence, or any other legal notion.

### WAIVER

This Guarantee shall contain the entire guarantee and shall be prevailing over any and all other guarantees, explicit or implicit (including any implicit guarantees on behalf of the dealer, or adaptability to specific purposes), and over any other responsibilities or liabilities on behalf of the manufacturer. The manufacturer does neither agree, nor empower, any person, acting on his own behalf, to modify, service or alter this Guarantee, nor to replace it with another guarantee, or another liability with regard to this product.

### UNWARRANTED SERVICES

The manufacturer shall repair or replace unwarranted products, which have been returned to its factory, at its sole discretion under the conditions below. The manufacturer shall accept no products for which no prior notice has been received via the RAN form at: <https://teletek-electronics.com/en/ran-form>.

The products, which the manufacturer deems repairable, will be repaired and returned. The manufacturer has prepared a price list and those products, which can be repaired, shall be paid for by the Customer. The devices with unwarranted services carry 6 months guarantee for the replaced parts.

The closest equivalent product, available at the time, shall replace the products, the manufacturer deems un-repairable. The current market price shall be charged for every replaced product.

## STANDARDS AND CONFORMITY

The Eclipse Series control panels are designed according and with conformity to the European Union (EU) Low Voltage Directive (LVD) 2006/95/EC and Electro-Magnetic Compatibility (EMC) Directive 2004/108/EC.

The CE mark is placed for indication that the Eclipse control panels comply with the requirement of EU for safety, health, environmental and customer protection.

## CERTIFICATIONS AND APPROVALS

<p>Alarm Control Panel: <b>Eclipse 8, Eclipse 16, Eclipse 32</b></p> <p>EN50131-1:2006 EN50131-3:2009 EN50131-6:2017 EN50131-10:2015 EN50136-1:2012 EN50136-2:2013</p> <div style="text-align: center;">                   Cert. No: TT-449/2019             </div> <p><b>Grade 2 Class I SP2</b></p>	<p>Alarm Control Panel: <b>Eclipse 99</b></p> <p>EN50131-1:2006 EN50131-6:2008 EN50131-3:2009 EN50136-1:2012 EN50136-2:2013 EN50131-10:2014</p> <div style="text-align: center;">                   Cert. No: TT-76/2018             </div> <p><b>Grade 3 Class I SP2</b></p>
--	--

## 1. GENERAL INFORMATION

ECLIPSE Series are control panels providing security and management of small and medium residential or office sites.

The ECLIPSE family includes:

- **ECLIPSE 8** for management of small sites up to 8 zones organized in 1 common area.
- **ECLIPSE 8+** for management of small to medium sites up to 16 zones organized in 3 independent areas.
- **ECLIPSE 16** for management of small to medium sites up to 16 zones organized in 3 independent areas.
- **ECLIPSE 32** for management of medium sites up to 32 zones and 8 independent areas.
- **ECLIPSE 99** for management of medium sites up to 99 zones and 16 independent areas.

The programming of options, parameters and attributes is organized in menus and the engineer can choose among three programming styles according his preferences:

1. 4-digit addresses;
2. 3-digit operations;
3. Text menus (tree-structure).

The default programming style is the one using text tree-structure for the engineer menus. To change the programming style at the beginning you have to enter first the engineer menu with valid code (7777 by default) and choose in sequence:

### 7777 – 2.SETTINGS – 14. MENU STYLE: TEXT, ADDRESS or OPERATION

Confirm your choice with ENTER button – the keyboard will confirm the operation with a sound signal. The next entering in the engineer menu will be with the selected programming style.


For installer's convenience, the menus in this manual are presented with all programming styles as they are pointed at the head and the functionality in details is described in the table under it.

**The engineer menus are available for programming only when the system is disarmed and the engineer access is enabled from the Manager programming menus!**

### General information about the programming styles


- **4-digit addresses.** The programming of the system parameters is organized with 4-digit address codes. The menus have the following structure:
  - 0xxx – General Settings Menu.
  - 1xxx – General User Menu; 1uuy – User Settings, where “uu” is a user number from 01 to 64, and “y” is an option.
  - 2xxx – General Zone Settings Menu; 2zzy – Zone settings, as “zz” is a zone number from 01 to 32, and “y” is an option.
  - 3xxx – General Setting for PGM 4; 3ppy – Settings for PGMs, as “pp” is a PGM number from 01 to 32, and “y” is an option.
  - 4xxx – General Areas Menu; 4aay – Area Settings, as “aa” is an Area from 01 to 08, and “y” is an option.
  - 5tty – Timeslots Settings, as “tt” is a timeslot number from 01 to 08, and “y” is an option.  
In addition, at addresses 5411 to 5524 are set holidays and nonworking days by months.
  - 60xx – General Settings for the digital communicator; 6nny – Phone Settings, as “nn” is a phone number from 01 to 04, and “y” is an option.
  - 61xx – General settings for the voice dialler; 61ny – Phones settings, as “n” is a phone number from 1 to 8, and “y” is an option.
  - 69xx – General settings for UDL remote programming.
  - 8ddy – Device Menu, as “dd” is a device number from 01 to 31, and “y” is an option.

**Note:** The Device 01 is always the main PCB of the control panel.




- **3-digit operations.** The programming of the system parameters is organized with 3-digit operation codes. The menus have the following structure:
  - 0xx – General Settings Menu.
  - 1xx – General User Menu; 1uu - Options for Users, as “uu” is an option number; after the option number is necessary to enter a user number from 01 to 64.
  - 2xx – General Zone Menu; 2zz – Zone options settings, as “zz” is an option number; after the option number is necessary to enter a zone number from 01 to 32.
  - 3xx – General Setting for PGM 4; 3pp – PGM options settings, as “pp” is an option number; after the option number is necessary to enter a PGM number from 01 to 32.
  - 4xx – General Areas Menu; 4aa – Area options settings, as “aa” is an option number; after the option number is necessary to enter an Area number from 01 to 08.
  - 5tt – Timeslot Menu, as “tt” in an option number; after the option number is necessary to enter a Timeslot number from 01 to 08. In addition, at addresses 541 to 544 are set holidays and nonworking days – and the number of the month from 01 to 12.
  - 6xx – General Settings for the digital communicator; 6nn – Phones options settings; after the option number is necessary to enter a phone number from 01 to 04.
  - 67x – General settings for the voice dialler, where “x” is number of an option from 0 to 3.
  - 680 – Entering of telephone numbers for the voice dialler.
  - 69x – General settings for UDL remote programming.
  - 810 + dd – Device Menu, as “dd” is a device number from 01 to 31.

**Note:** The Device 01 is always the main PCB of the control panel.



- **Text menu (tree-structure).** The system parameters are organized in text menus with tree-structure:



To enter in a text menu select it with the arrow buttons and confirm with ENTER. The programming of the parameters in the menus may differ according to their usage. Use the arrow buttons to scroll of the available menus or submenus. You can also directly enter in a menu with pressing its number – see the structure above.


The exit to the upper menu or submenu is with pressing the CANCEL (X) button.

There are several ways for setting parameters – that depends on the menu:


- **When the submenu allows choosing only one option** or attribute, or parameter from a list, the installer scrolls down to the desired one and confirms his choice with  button. The set option is displayed with a “check” mark in front of it. The exit of the submenu is automatic. See Example 1 below.

- **When the submenu allows choosing of several options** or attributes, or parameters at the same time then the installer has to scroll down to each one and to enable it with pressing the  button. The set option is displayed with a “check” mark in front of it. The installer has to move to the next option using the arrow buttons and so on. To disable an option, scroll down to it and press  button – the “check” mark will be deleted. When all the desired options are selected, the choice is confirmed with  button. See Example 2 below.

**Example 1 (ECLIPSE 8)**



**Example 2 (ECLIPSE 8)**




## 2. SUPPORTED KEYBOARDS FOR PROGRAMMING AND OPERATION

Eclipse Series alarm control panel supports operation with the full range of Eclipse Series keyboards.



**ATTENTION:** The operation with text menus is set by default for control panels ECLIPSE Series. The text menus are accessible for operation with LCD keyboards. In case of using a LED keyboard for programming and settings the 4-digits address menus are used by default.

### 2.1. LED/LCD Keyboards



**LED 8/LED 16A** (open protective cover)

Supported programming style types:

- 4-digit address menus – by default
- 3-digit operation menus

The keyboard provides specialized LED indication about the programming style and visualization of the selected parameter, option or attribute with the digit buttons.

The installer can review the number of the entered address or operation code using a special information button.

*The general operation with LED8/16A keyboard is described in item 2.5.*



**LED 16A VG/LED 32** (open protective cover)

Supported programming style types:

- 4-digit address menus – by default
- 3-digit operation menus

**LED 16A VG** is a control keyboard with voice guiding messages to support users' daily operation with the intruder system.

*The general operation with the keyboards is described in item 2.6.*

**LCD 32** (open protective cover)



Supported programming style types:

- 4-digit address menus
- 3-digit operation menus
- Text menus (tree-structure) – by default

**LCD 32 Sensitive**



Supported programming style types:

- 4-digit address menus
- 3-digit operation menus
- Text menus (tree-structure) – by default

*The general operation with the keyboards is described in item 2.7.*

Summary for ECLIPSE Series Keyboards:

Keyboard	Display	Areas	Zones	Proxi Reader	Address	Operation	Text menu	AUX PGM
LED 8	LED	1	8	×	✓	✓	×	×
LED 16A	LED	3	16	×	✓	✓	×	×
LED 16A VG	LED	3	16	×	✓	✓	×	×
LED 32	LED	8	32	✓ (option)	✓	✓	×	×
LCD 32	LCD	Up to 16*	Up to 99*	✓ (option)	✓	✓	✓	✓
LCD 32S	LCD	Up to 16*	Up to 99*	✓	✓	✓	✓	✓

\* Depends on the type of the control panel.

## 2.2. Supported Trouble Events in ECLIPSE Series

The possible system troubles are listed in the table below as the indication differs according the type of the used keyboard:

- Keyboard LED 8 – The troubles are displayed with a lighting zone LED or lighting up digit button.
- Keyboards LED 32, LED 16A, LED 16A VG – The troubles are displayed with a lighting zone LED.
- Keyboards LCD 32 and LCD 32 Sensitive – The troubles are displayed as text messages.

The sound signalization for a system trouble (two short sound signals at every 20 seconds) can be disabled/enabled in Menu 2. SETTINGS – 03. TRBL SOUNDS (ADDRESS 0013 or OPERATION 013). The signalization is common for all troubles. By default, the sound signalization for all system troubles is enabled.

LED 8	LED 32/ LED 16A/ LED 16A VG	LCD 32/ LCD 32 Sensitive	Description	Control panels Eclipse			
				8	8+/16	32	99
①	①	1. AC Loss	The mains power supply is lost.	✓	✓	✓	✓
②	②	2. Battery Trouble	The accumulator battery is discharged or missing.	✓	✓	✓	✓
③	③	3. Blown fuse	Blown out fuse.	✓	✓	✓	✓
④	④	4. Comm. TRBL	Telephone line (PSTN) or digital communicator (GPRS) is lost. Communication with central Monitoring station fails. Sending of message (PSTN/GPRS/LAN) is impossible.	✓	✓	✓	✓
⑤	⑤	5. Tamper	Open tamper in system.	✓	✓	✓	✓
⑥	⑥	6. Sysbus err	System bus error. It could be short circuit in the line or lost device.	✓	✓	✓	✓
⑦	⑦	7. Fire line Error	Fire Detector Loss or the fire line is broken.	×	×	✓	✓
⑧	⑧	8. Siren Fault*	Problem with connected siren; no siren connected to PGM5.	×	✓	✓	✓
Button "1"	⑨	9. Invalid clock**	The internal clock has to be set to an actual time and date.	✓	✓	✓	✓
Button "2"	⑩	10. WL device trouble.	Possible problems: - Low battery charge of wireless device; - Wireless device lost; - Dirty chamber of a wireless fire detector.	×	✓	✓	✓
Button "3"	⑪	11. WL RF jamming.	Radio signal jamming.	×	✓	✓	✓
Button "4"	⑫	12. AUX PSU trouble.	Possible problems with power supply of expander modules: - The mains power supply is lost; - Problem with the backup battery; - Blown out fuse.	×	✓	✓	✓

\* It is possible, after the initial power-up of ECLIPSE 32 or ECLIPSE 99 panel, a trouble message for 8. SOUNDER FAULT to be displayed on the screen of LCD keyboards (8 zone number lights on the LED display). That indicates some problems with sounder connected to PGM5. In case the monitored PGM is used as a standard output, you have to terminate it with 1K resistor, or to program it as regular output – disable option 1 at ADDRESS 3051.

\*\* It is possible, the message to be displayed after the initial power-up of the panel and after every hardware reset of the system. The installer must set the actual time to clear the trouble message.


### 2.3. Buttons Functions

**Note:** The functionality of *BYPASS*, *TROUBLE* and *MEMORY* buttons for LED 8 and LED 16A keyboards is accessible through the manager and user menus only with the respective LED indication on the display. The specialized LED indication of the LED 8/16A keyboard is described in details in item 2.5.

Button	Function	Description
	ENTER	Confirmation of the entered data; step ahead in the engineer programming menus*. For LED 8 and LED 16A keyboards: Use the button to review the memory log file, the system troubles and the bypassed zones – the respective system LED is blinking during the review.
	CANCEL	Cancelling the entered parameters; exit from a programming mode.
	FULL ARM	Quick button for Full Arming Mode.
	DISARM	Disarming the system. The button has a special function in text entering mode – deletes the current symbol and moves the cursor on one position to the left (like Backspace button on a standard PC keyboard).
	STAY ARM	Quick button for Stay Arming Mode. The button has a special function in text entering mode – shifting between small and capital letters.
	SLEEP ARM	Quick button for Sleep Arming Mode.
	PRG	Entry in Manager and User programming modes. The button has a special function in engineer programming mode – saving the entered settings and moves forward as the current index number is increased with +1 (see the note and the example following this table). Entry in Service Keyboard Mode.
	BYPASS	Bypassing zones. The button lights on permanently if there are bypassed zones in the system. The button is blinking during the bypassed zones review. The button has a special function in engineer programming – cancelling the entered settings and moves forward as the current index number is increased with +1 (see the note and the example following this table), option 0.
	TROUBLE	Reviewing the system troubles. The button lights on permanently if there are system problems. The button is blinking during the system troubles review.
	MEMORY	Reviewing the memory events log file. The button lights on permanently if there are memory events. The button is blinking during the memory events review. The button has a special function in text entering mode – entering of special symbols (see the item 2.8 Entering text for LCD Keyboard).
	Scroll arrows	Arrows for moving the cursor on the left and on the right in programming mode.
0 - 9	Digit Buttons	Digital buttons for entering parameters, codes, etc. For LED 16A VG keyboard: Use button 1 to arm/disarm Area A; use button 2 to arm/disarm Area B; use button 3 to arm/disarm Area C.

\* The functionality is available in 4-digit address programming style.

The structure of the addresses is as follows:



**Example:**

When pressing PRG button, the next viewed address is formed as the current index number is increased +1 and option number is the same. Example, from ADDRESS 2021 after pressing PRG the menu moves to ADDRESS 2031.

When pressing BYPASS button, the next viewed address is formed as the current index number is increased +1 and option is first possible. Example, from ADDRESS 2024 after pressing BYPASS the menu moves to ADDRESS 2030.

## 2.4. Sound Signalization from Keyboards

All Eclipse Series Keyboards have sound signalization for occurring of different system events. The sound signalization has 4 volume levels adjustable at address 90 from the Manager programming menus.

Sound Signal	Description
Button	Single short beep indicating pressing of a key.
Confirmation	Two long sound signals, indicating the system confirmation to executed operation.
Cancel operation	A single long beep, indicating system incorrectly executed operation.
Entry time	Continuous beep, indicating intrusion into an entrance zone in an armed area.
Exit time	Short beeps, indicating the system is armed and the user is required to leave the entrance zone. Ten seconds before the exit time is over beeps frequency increase.
Technical problem	Two short beeps at every 20 sec, indicating a technical trouble. To stop the sound signalization – enter a valid user code and press in sequence TROUBLE and ENTER buttons (for LCD32 and LED32 keyboard), or twice ENTER button (for LED8 and LED16A keyboards).
Chime	Short beeps with subsequently increasing period, indicating intrusion into a zone with an activated chime option.
Fire alarm	Three sound signals in sequence repeated every 5 seconds. That kind of signalization shows activated fire detector in the premises.

## 2.5. General Information for Operation with LED 8/16A

LED8/16A are a compact size keyboards with LED display, suitable for management and programming of ECLIPSE Series control panels. The keyboards have indication for 8 or 16 zones and can control 1 or 3 areas.

LED8/16A are equipped with specialized LED indication for informing the installer of the set programming style menu and specific visualization of the programming values and parameters.

The entering of codes, 3- and 4-digit addresses and values is with the digit buttons. For arming the system are used the quick buttons for the respective arming mode.

### Specialized LED indication for LED 8/16A keyboard:

LED	Indication	Description
	Lights on	The system is in engineer or manager programming mode.
	Blinking	Shows a selected device in an engineer programming mode; Fast blinking – service keyboard.
	Lights on	The 3-digit programming style type is selected. View mode (of OPERATION number) after pressing the DISARM button. [O] is short from OPERATION.
	Lights on	The 4-digit programming style type is selected. View mode (of ADDRESS number) after pressing the DISARM button. [A] is short from ADDRESS.
	Lights on	The system waits for entering of a parameter, or option. [V] is short from VALUE.
	Lights off	No active alarms in the system.
	Lights on	Alarm in the system. The active alarms are reviewed by pressing the ENTER button.
	Blinking	View mode for active alarms.
	Lights off	No system troubles in the system.
	Lights on	System trouble. The active troubles are reviewed by pressing the ENTER button.
	Blinking	View mode for system troubles.
	Lights off	No bypassed zones in the system.
	Lights on	Bypassed zones in the system. The zone numbers are reviewed by pressing the ENTER button.
	Blinking	View mode – The numbers of bypassed zones are lighting on.

In normal operation mode the DISARM button (LED 8) or Area Letters (LED 16A) light on in green. The DISARM button has a specific functionality in engineer programming menus.

Button	Functionality	Description
	DISARM	System disarming.
	INFORMATION	<p>Information about the ADDRESS number in engineer programming mode. The functionality is useful when the installer is confused during the engineer programming and wants to check up the current ADDRESS number before continue with the respective parameter or option settings.</p> <p>The button is used in the following way:</p> <ol style="list-style-type: none"> <li>1. The symbols  and  are lighting on permanently together with a number of zone(s), according the type of the programmed parameter. A blinking digit shows that parameter which is in setting mode, and lighting on digit button shows the current set value for this parameter.</li> <li>2. To find out what is the number of the current ADDRESS, press the  button. If the set programming style is with 4-digit ADDRESSES – the  symbol lights on, and if it is with 3-digit operations - the  symbol lights on. The zone numbers from 1 to 4 or from 1 to 3 are lighting on, the zone 1 is blinking, and lighting on button shows the first digit of the address (operation) number.</li> <li>3. Press the right arrow button. The cursor will move one position on the right, zone 2 starts blinking and lighting on digit number shows the next number of the address (or operation).</li> <li>4. Proceed in an analogical way reviewing the address number up to the last digit.</li> <li>5. Press the  button again to step back in parameter setting mode.</li> </ol> <p><i>Note: You can also leave the view mode and with single pressing the CANCEL button.</i></p> <p><b>Recommendation:</b> If you are not familiar in details with the engineer programming menus (address and operation numbers) write down in sequence the digits (of lighting buttons) corresponding to the respective address positions (zone numbers).</p>

### - Engineer Programming

The engineer programming menus are accessible only when the system is disarmed. Lighting on symbols  or  indicate the currently set programming style type.

To access the engineer programming menus, enter valid engineer code (7777 by default). A confirmation sound signal is heard and the system starts waiting for the installer to enter ADDRESS or OPERATION number for programming. According the set programming style, the LED displays:

- The zone numbers **1, 2, 3 and 4**, and  lighting on - **4-digit ADDRESS programming style**
- The zone numbers **1, 2 and 3**, and  lighting on - **3-digit OPERATION programming style**

The  symbol lights on permanently together with the letter for the set programming style – 4-digit ADDRESS programming style is set by default.

To proceed with programming, enter ADDRESS number and according the descriptions provided in item 7, set parameters, attributes and options for the system configuration. Use the digit buttons to enter the address number. Every pressing of a button turns one zone number off, and the pressed button lights on. After pressing the last digit of the address number, the system enters automatically in mode for setting parameters -  lights on, and  or  lights off.

Several zone numbers will light on as their number depends on the current parameters for programming. Zone 1 is blinking to show that the first digit of the value is currently set. A permanently lit digit button shows the current set value. To change it, press a digit button according the parameter. If there are several values (when setting the date for example), you can review them using the arrow buttons. *Note: In case of setting options from ENABLE/DISABLE type keep in mind that the option is disabled when all digit buttons are off, and the option is enabled when all digit button are lighting on. You can change the setting of the option with pressing random digit button or arrows buttons.*

To confirm the entered settings, press the ENTER button – the system automatically moves to the next address number. To cancel the entered parameters, press the CANCEL button – the system will move back to the main screen for ADDRESS entry. To exit to main screen press, CANCEL button a couple of times. In normal operation mode only the DISARM button lights on in green.

According the entered ADDRESS number, the LED indication will differ. Use the detailed descriptions in item 7 to become familiar with the system settings.

**Attention:** The exit from the engineer programming menus is not automatic! Press CANCEL button several times to exit to the main display and normal operation mode – only the DISARM button lights on in green.

Example for reviewing of ADDRESS number in engineer menu with LED 8/16A keyboard:

- The symbols  and  are lighting on. Zone 1 is blinking and Button 1 lights on.
- Press the   button. It starts blinking showing that the system is in mode for address reviewing.
- The symbols  and  light up. Letter A means that the set programming style is with 4-digit ADDRESSES.
- Zone 1 is blinking. Button 0 is lighting on – this is the first digit of the ADDRESS number.
- Press the right arrow button.
- Zone 2 is blinking. Button 0 is lighting on – this is the second digit of the ADDRESS number.
- Press the right arrow button again.
- Zone 3 is blinking. Button 9 is lighting on – this is the third digit of the ADDRESS number.
- Press the right arrow button for the last time.
- Zone 4 is blinking. Button 7 is lighting on – this is the last digit of the ADDRESS number.
- The reviewed ADDRESS number is 0097 – Changing the programming style type.
- To go back to the parameter settings mode, press the   button again.

### - Manager Programming

To access the manager programming menus, enter valid manager code (0000 by default). A confirmation sound signal will be heard. Press the PRG () button to enter in manager programming menus. Zone numbers 1 and 2, and LEDs  and  are lighting on. The manager programming menus are 2-digit and are described in details in ECLIPSE Series Operation Manual – Manager and User Programming. If 30 sec after entering the manager programming there is no activity (pressed button), the system will exit in normal operation mode. It is possible to enter in manager programming menus from several keyboards at a time using the same manager access code.

Example for date setting in Manager programming menus using LED 8/16A keyboard:

- Enter valid Manager code (0000 by default) and press  button.
- LEDs  and  are lighting on. Zone number 1 is blinking and zone number 2 is lighting on – the system waits for entering of 2-digit ADDRESS number.
- Enter 15 – ADDRESS for date setting.
- LEDs  and  are lighting on. Zone number 1 is blinking, zones from 2 to 6 are lighting on. The “0” digit button is lighting on (the set date by default is 01/01/19).
- Enter the new date using the format DDMMYY. You can use the buttons with arrows to review the entered new date before saving it – the lighting on digit button shows the set value for every currently blinking zone number on the display.
- Confirm the new set date with ENTER.

## 2.6. General Information for Operation with LED 16A VG and LED32

LED 16A VG/LED 32 is a keyboard with LED display, suitable for management and programming of ECLIPSE Series control panels.

LED 16A VG has indication for 16 zones and can control 3 independent areas. The keyboard is equipped with voice guiding messages helping user in operation. LED 32 has indication for 32 zones and can control 8 independent areas.

The keyboards operate with limited functionality when connected to ECLIPSE 8 control panel – operation with one area only and 8 zones. LED 32 operates with limited functionality when connected to ECLIPSE 8+/16 control panel – operation with three areas (A, B and C) and 16 zones.

### - Engineer Programming

The engineer programming menus are accessible only when the system is disarmed.

According to the set programming style after entering an engineer code (7777 by default) the LED displays:

- The zone numbers **13, 14, 15 and 16** lighting on - **4-digit ADDRESS programming style**
- The zone numbers **14, 15 and 16** lighting on - **3-digit OPERATION programming style**

The both LEDs, “lightning” (white) and “padlock” (red), are blinking together showing that the system is in engineer programming mode. Now, the system waits for entering of ADDRESS or OPERATION for programming – by default the 4-digit ADDRESS programming style is set.

Use the digit buttons to enter an ADDRESS number – the detailed description of the ADDRESSES and their functionality is provided in item 7. Every pressing of a button enters one digit and the lighting on zone numbers are reduced with one, the number of the pressed digit button lights up (for 0 lights on digit 10). According the entered address number, the indication for the parameters is different. Use the address descriptions provided in item 7 to orientate for the required settings. To confirm the entered settings, press the ENTER button, to reject them – the CANCEL button. To return to the display for address entering press single the CANCEL button. To exit the engineer

programming menu, press the CANCEL button once again. The keyboard is in normal operation mode when LEDs “Lightning” (white) and “padlock” (green) are lighting on together with the numbers of the used areas.

**Attention:** The exit of engineer programming menu is not automatic! To exit the engineer menu press, CANCEL button several times until return to the normal operation mode.

### - Manager Programming

To access the manager programming menus, enter valid manager code (0000 by default). A confirmation sound signal will be heard. Press the PRG (⚙️) button to enter in manager programming menus. Zone numbers 15 and 16 are lighting on, and both LEDs “Lightning” and “padlock” are blinking only on the keyboard for programming. The manager programming menus are 2-digit and are described in details in ECLIPSE Series Operation Manual – Manager and User Programming. If 30 sec after entering the manager programming there is no activity (pressed button), the system will exit in normal operation mode. It is possible to enter in manager programming menus from several keyboards at a time using the same manager access code.

- **Supported voice messages for Eclipse LED 16A VG**

The control keyboard Eclipse LED 16A VG is equipped with voice guiding messages for events to support user operation. The following messages are performed:

“System is armed” - The exit time is over and the system is armed (Full, Stay or Sleep mode).

“System is disarmed” - The entry time is over and the system is disarmed.

“Please, enter your code to disarm” – The entry time is running on. The message is played on every 5 seconds until a valid user code is entered and the system is disarmed.

“Please, leave the premises” – The exit time is running on. The message is played on every 5 seconds until the system is armed (Full, Stay or Sleep mode).

“AC power is failure” – The main power supply is missing or off. The message is played after disarming the system; during exit time is running on; activation of entry-exit or follow type zone when the system is disarmed.

“Battery is discharged” – The backup battery is low charged or missing. The message is played after disarming the system; during exit time is running on; activation of entry-exit or follow type zone when system is disarmed.

**Attention:** The voice messages cannot be muted or switched off. They can be only silenced at address 90 (text menu “5. KBD Settings – 1. Busser Level”) in the manager programming menus. The volume level can be set in range from 1 (the lowest) to 4 (the highest).

## 2.7. General Information for Operation with LCD Keyboard

The LCD32 and LCD32 Sensitive are keyboards for management and control with text LCD displays.

The keyboards LCD32 and LCD32 Sensitive operate with limited functionality when connected to ECLIPSE 8/8+/16 control panel – operation with 1/3 areas and 8/16 zones.

To enter codes, addresses and parameters use the digit buttons. For arming the system can be used neither the quick buttons with the respective pictograms, or to choose the arming type from the screen scrolling with the arrows and confirmation with ENTER button. Use the provided in item 7 detailed descriptions of the all addresses in the system. To exit the engineer or manager programming menu press CANCEL button several times until return to main screen in normal operation mode.

## 2.8. Entering text for LCD Keyboard

The keyboard models LCD32 and LCD32 Sensitive support text entering including small and capital letters, digits, punctuation marks and other specific symbols. Three versions of the display are available according the supported language: Cyrillic, Greek and EU version. **Note:** The type of the display is placed on the sticker on the back of the keyboard: CYR (supports Cyrillic, English, Turkish fonts), GR (supports English and Greek fonts) or EU (supports English, Hungarian, Italian and Portuguese fonts).

The regular letters and digits can be entered directly by the buttons or as a code combination after pressing the MEMORY button – look at the tables below. It is possible to enter text up to 16 symbols including space.

Button	Letters, digits				
0	_	0			
1	1				
2	a	b	c	2	
3	d	e	f	3	
4	g	h	i	4	
5	j	k	l	5	
6	m	n	o	6	
7	p	q	r	s	7
8	t	u	v	8	
9	w	x	y	z	9

**Table for correspondence of the buttons:**

Use the STAY ARM (🏠) button to enter capital letters.

Use the DISARM (🔒) button to delete a symbol – the cursor moves with one step to the left.

Use the MEMORY (🔔) button to enter some special symbols and Cyrillic/Greek letters. To enter a specialized symbol, move the cursor to the desired position, press the MEMORY button (a solid cursor appears) and then using the digit buttons enter the respective code for the symbol or letter as check in the table below.

**Table of the symbols and codes correspondence for CYR keyboard version:**

032	040	048	056	064	072	080	088	096	104	112	120	160	168	176	184	192	200	208	216	224	232	240	248	
033	041	049	057	065	073	081	089	097	105	113	121	161	169	177	185	193	201	209	217	225	233	241	249	
034	042	050	058	066	074	082	090	098	106	114	122	162	170	178	186	194	202	210	218	226	234	242	250	
035	043	051	059	067	075	083	091	099	107	115	123	163	171	179	187	195	203	211	219	227	235	243	251	
036	044	052	060	068	076	084	092	100	108	116	124	164	172	180	188	196	204	212	220	228	236	244	252	
037	045	053	061	069	077	085	093	101	109	117	125	165	173	181	189	197	205	213	221	229	237	245	253	
038	046	054	062	070	078	086	094	102	110	118	126	166	174	182	190	198	206	214	222	230	238	246	254	
039	047	055	063	071	079	087	095	103	111	119	127	167	175	183	191	199	207	215	223	231	239	247	255	

*Example: To enter the "asterisk" symbol, first press the MEMORY button (a solid cursor appears on the place) and after that enter code 042. The asterisk symbol will appear and the cursor will move one position to the right.*

**Table of the symbols and codes correspondence for GR keyboard version:**

016	024	032	040	048	056	064	072	080	088	096	104	112	120	128	136	144	152	160	168	176	184	192	200	208	216	224	232	240	248	
017	025	033	041	049	057	065	073	081	089	097	105	113	121	129	137	145	153	161	169	177	185	193	201	209	217	225	233	241	249	
018	026	034	042	050	058	066	074	082	090	098	106	114	122	130	138	146	154	162	170	178	186	194	202	210	218	226	234	242	250	
019	027	035	043	051	059	067	075	083	091	099	107	115	123	131	139	147	155	163	171	179	187	195	203	211	219	227	235	243	251	
020	028	036	044	052	060	068	076	084	092	100	108	116	124	132	140	148	156	164	172	180	188	196	204	212	220	228	236	244	252	
021	029	037	045	053	061	069	077	085	093	101	109	117	125	133	141	149	157	165	173	181	189	197	205	213	221	229	237	245	253	
022	030	038	046	054	062	070	078	086	094	102	110	118	126	134	142	150	158	166	174	182	190	198	206	214	222	230	238	246	254	
023	031	039	047	055	063	071	079	087	095	103	111	119	127	135	143	151	159	167	175	183	191	199	207	215	223	231	239	247	255	

**Table of the symbols and codes correspondence for EU keyboard version:**


032	040	048	056	064	072	080	088	096	104	112	120	128	136	144	152	160	168	176	184	192	200	208	216	224	232	240	248		
033	041	049	057	065	073	081	089	097	105	113	121	129	137	145	153	161	169	177	185	193	201	209	217	225	233	241	249		
034	042	050	058	066	074	082	090	098	106	114	122	130	138	146	154	162	170	178	186	194	202	210	218	226	234	242	250		
035	043	051	059	067	075	083	091	099	107	115	123	131	139	147	155	163	171	179	187	195	203	211	219	227	235	243	251		
036	044	052	060	068	076	084	092	100	108	116	124	132	140	148	156	164	172	180	188	196	204	212	220	228	236	244	252		
037	045	053	061	069	077	085	093	101	109	117	125	133	141	149	157	165	173	181	189	197	205	213	221	229	237	245	253		
038	046	054	062	070	078	086	094	102	110	118	126	134	142	150	158	166	174	182	190	198	206	214	222	230	238	246	254		
039	047	055	063	071	079	087	095	103	111	119	127	135	143	151	159	167	175	183	191	199	207	215	223	231	239	247	255		

### 3. PROGRAMMING WITH SPECIALIZED ProSTE SOFTWARE

ProSTE is specialized software for direct programming of burglary and fire alarm panels manufactured by Teletek Electronics JSC.

The programming of ECLIPSE Series control panels is via serial connection using specialized “cable ProSTE” or via standard micro USB cable available for the following or higher hardware revisions: Eclipse 8 – HW 2.0, Eclipse 8+ - HW 1.1, Eclipse 16 – HW 1.5, Eclipse 32 – HW 2.3, Eclipse 99 – HW 1.4.

It is strongly recommended as a first step to read the set to control panel parameters, as second – changing parameters and at the end – writing the new settings to the control panel.



Serial connection between ECLIPSE and PC with ProSTE software

### 4. OPERATION WITH A SERVICE KEYBOARD

The service keyboard is a device, which is not a part of the system configuration, but can provide full access to all engineer programming menus. Every keyboard of Eclipse Series can be used as service, **when it is not enrolled at address** in the system configuration.

The service keyboard is not enrolled at a certain address and that is why its removing will not cause a system trouble for a lost device.

You can connect only one service keyboard to the system configuration at the same time.

The “Service keyboard” mode allows access only to the engineer programming menus and the Manager and User programming menus are not available. The system arming and disarming is also unavailable.

**Every Eclipse Series keyboard can be service keyboard if it is not currently enrolled to the system configuration.**

The service keyboard can be connected to the control panel in two ways:


- Via specialized cable for connection of service keyboard to the interface connector “Service KBD” on the control panel PCB.
- To the system bus of the control panel.

The indication of a keyboard when used as service keyboard in the system depends on its type:

Keyboard	LED	Indication
LED 8	⚙️	Blinks fast in red.
LED 16A		
LED 16A VG		
LED32	🔒	Blinks in red and green in turn.
LCD 32 (S)		

- **Using a service keyboard cable**

This is a specialized cable for quick connection of service keyboard to an Eclipse series control panel. The cable is factory prepared for connection to interface connector “Service KBD” on the panel’s PCB from the one side and for connection to the keyboard terminals at the other.



To enter in the service keyboard mode:

- Connect the interface connector to “Service KBD” terminals on the panel.
- Connect the color wires to the keyboard terminals as observe the polarity of the connection.
- Wait the initial initialization to complete.
- Single press the PRG button (⚙️).
- When you finish with the engineer programming, exit to the main screen.
- Unplug the interface connector from the “Service KBD” terminal.

- **Using the system bus of the panel**

To enter the “Service keyboard” mode **with a new keyboard**:

- Connect the keyboard to the system bus and wait the initial initialization to complete.
- Single press the PRG button (⚙️).
- When you finish with the engineer programming, exit to the main screen.
- Power off the keyboard and disconnect it from the system bus.

To enter the “Service keyboard” mode **with a present keyboard in the system configuration**:

- Use one of the other keyboards in the system configuration to delete the unique ID number of the one selected for service keyboard – enter the keyboard ID address 8xx0, where “xx” is the device number from 02 to 32 (01 is always the PCB of the control panel), and delete the ID number with pressing the “0” button for 2-3 seconds. It is not necessary to confirm with ENTER.
- Press the PRG (⚙️) button.
- When you finish with the engineer programming, exit to the main screen.



**ATTENTION: If the engineer access is disabled from the manager programming menu the access will be denied and for the service keyboard!**

- **Adding of service keyboard to the system configuration**

Every service keyboard, connected to the panel can be added to the system configuration and to be available for operation from users. Whether the service keyboard is connected to “Service KBD” connector or to the system bus of the panel, it can be added to the system configuration as follows:

- Enter the engineer programming menu using the service keyboard.
- Choose a free position for device enrolment (free address)
- Press in sequence the tamper-switch and the (✓) (ENTER) button of the service keyboard.
- After the initial initialization is complete the keyboard will ready for additional settings and user operation.

## 5. ENROLLING/DELETING OF DEVICES

### 5.1. Enrolling Devices during the Initial Start-up of the Control Panel

1. With set RESET jumper on the main PCB power-up the Eclipse control panel.
2. Wait the initial initialization of the connected to the system bus keyboards. At the end of the procedure, the bus LED of all devices including the main PCB is lighting permanently in red. A text message "SW revision XX; Press ENTER" is displayed on LCD screen, and at LED keyboards is lighting on only the power LED. For LED 8/16A only the buttons 0-9 are lighting on.
3. Start to press the ENTER button or the address button of other devices – the manufacturer recommends first to enrol the keyboards in the system, then proxy readers, modules, etc. The system starts an automatic enrolment procedure of the devices on consecutive addresses as the first is attached at address 2 (in address menus 8020). Remember that the first enrolled device to the system bus is always the main PCB of the panel. It is strongly recommended the next enrolled device to be LCD keyboard for programming, especially for system configurations with Eclipse 99 control panel.
4. Remove the RESET jumper and wait the system bus LED to stop blinking in green. The system is ready for further programming and parameter configuration.
5. Set an actual time and date.



**IMPORTANT NOTE! When enrolling devices to ECLIPSE 8 control panel, the first is automatically added to ZONE 7, and the second to ZONE 8!**

### 5.2. Enrolling Devices to a working system configuration via LCD keyboard

1. Enter engineer code (7777 by default).
2. Press button "9" for direct access to menu "9. DEVICES". Use the buttons with arrows to reach a free address position for adding a new device. Choose in sequence:

**XX. Device [Free] – ENTER – 1. ID – ENTER – [Free] [\_\_\_\_\_]**

3. Press the ENTER button (for a keyboard), the tamper-switch (for modules and standalone proxy reader) or approach a proxy card (for a reader) of the device connected to the system bus and which you want to enrol to the system configuration.
4. After successful enrolment to the control panel, the screen displays:

**[Device type] [unique ADDRESS] for the respective device.**

The following device types are supported from ECLIPSE Series:

Device	Description	ECLIPSE 8*	ECLIPSE 8+/16**	ECLIPSE 32***	ECLIPSE 99***
MAIN	The main PCB of the panel	✓	✓	✓	✓
LED	Keyboard LED 8/16A/32	✓	✓	✓	✓
LCD	Keyboard LCD 32/32S	✓	✓	✓	✓
ZEXP	Zone expander	×	✓	✓	✓
PEXP	PGM expander	×	×	✓	✓
WEXP	Wireless expander	×	✓	✓	✓
PRX	Proximity card reader	✓	✓	✓	✓
PIR	Wireless motion detector	×	✓	✓	✓
MC	Wireless magnetic contact	×	✓	✓	✓
FLD	Wireless flood detector	×	✓	✓	✓
FIRE	Wireless fire detector	×	✓	✓	✓
SIRN	Wireless outdoor siren	×	✓	✓	✓
REMT	Remote key fob	×	✓	✓	✓

\* **Eclipse 8:** Up to 2 devices can be enrolled to the system bus: 2 keyboards, 2 proximity card readers or 1 keyboard and 1 proximity card reader.

\*\* **Eclipse 8+/16:** Up to 5 devices can be enrolled to the system bus irrespective of their type.

\*\*\* **Eclipse 32/99:** Up to 30 devices can be enrolled to the system bus irrespective of their type.

**NOTE:** It is not necessary to enrol the built-in proximity reader in keyboards LED 32, LCD 32 and LCD 32S. The wireless devices can be enrolled only to wireless expander module Eclipse WL, which already has been added to the system configuration.

5. Press ENTER button of the used for programming keyboard. The keyboard will confirm the end of the successful enrolment procedure with sound signal.

6. The new enrolled device is in normal operation mode and ready for further programming and configuration.

**Note:** Other way for enrolling of a new device is to enter its unique ID number directly at a free address as use the digit buttons of the keyboard. The unique ID number is provided from the manufacturer with a sticker on the backside of the PCB of the device.

### 5.3. Enrolling Devices to a working system configuration via LED keyboard

1. Enter engineer code (7777 by default) – zone numbers 13, 14, 15 and 16 are lighting on. (For LED 8/16A - 1, 2, 3 and 4).
2. Enter ADDRESS 8020 and press BYPASS button several times until you reach a free address in the system – zone numbers from 1 to 16 are lighting on. (For LED 8/16A – button “0” is lighting on).
3. Press the ENTER button (for a keyboard) or the tamper-switch (for module, proxy reader or other) of the device you want to enrol to the system configuration.
4. After successful enrolment to the control panel, the screen displays lighting on zone number according the type of the enrolled device (for LED 8/16A - a lighting button):

Number	Description	ECLIPSE 8*	ECLIPSE 8+/16**	ECLIPSE 32***	ECLIPSE 99***
1	The main PCB of the panel	✓	✓	✓	✓
2	Keyboard LCD 32/32S	✓	✓	✓	✓
3	Keyboard LED 8/16A/32	✓	✓	✓	✓
4	Zone expander	×	✓	✓	✓
5	PGM expander	×	×	✓	✓
6	Wireless expander	×	✓	✓	✓
7	Proximity card reader	✓	✓	✓	✓
11	Wireless outdoor siren	×	✓	✓	✓
12	Wireless magnetic contact	×	✓	✓	✓
13	Wireless motion detector	×	✓	✓	✓
15	Remote key fob	×	✓	✓	✓
16	Wireless fire detector	×	✓	✓	✓
18	Wireless fire detector	×	✓	✓	✓

\* **Eclipse 8:** Up to 2 devices can be enrolled to the system bus: 2 keyboards, 2 proximity card readers or 1 keyboard and 1 proximity card reader.

\*\* **Eclipse 8+/16:** Up to 5 devices can be enrolled to the system bus irrespective of their type.

\*\*\* **Eclipse 32/99:** Up to 30 devices can be enrolled to the system bus irrespective of their type.

**NOTE:** It is not necessary to enrol the built-in proximity reader in keyboards LED 32, LCD 32 and LCD 32S. The wireless devices can be enrolled only to wireless expander module Eclipse WL, which already has been added to the system configuration.

5. Press ENTER button of the used for programming keyboard. The keyboard will confirm the end of the successful enrolment procedure with sound signal.

6. The new enrolled device is in normal operation mode and ready for further programming and configuration.


### 5.4. Deleting of a device from the system configuration

1. Enter engineer code (7777 by default)
2. Enter the address of the device you want to delete from the system configuration.
3. At the respective address press and hold the button “0” for 2-3 seconds – the LCD shows [Free] for the address, LED 32 – LEDs from 1 to 16 are lighting on, LED 8/16A – button “0” lights on. A continuous sound signal is heard.

**Attention:** Deleting the unique ID number with button “0” is permanent and you cannot reject the operation with CANCEL button! To enrol the device again follow the procedure described at items 5.2 and 5.3.

## 6. ENGINEER PROGRAMMING

The Engineer programming menus are available only when the system is fully disarmed. By default, the engineer access code is 7777. The display performance is different according to the used keyboard model for programming:



The access to the Engineer programming menus is from one keyboard only while all other connected to the system bus keyboards are temporarily disabled for any operation. The LCD keyboards display a message “Engineer Mode!!!”

The default programming style is the one using text tree-structure for the engineer menus. To change the programming style at the beginning you have to enter first the engineer menu with valid code (7777 by default) and choose in sequence:

**7777 – 2.SETTINGS – 14. MENU STYLE: TEXT, ADDRESS or OPERATION**

Confirm your final choice with ENTER.

At every exit from the engineer programming menu the system updates all changes of parameters and settings. The update will take some time depending on the system structure, volume and number of parameters’ changes.

**Before starting the programming of any system parameter read carefully the provided detailed information for each menu and make sure that you understand the descriptions.**

### 6.1 Organization of the Engineer Programming Menus

For Installer’s convenience, every programming parameter description includes the access via all the programming types:

ENG1 CODE	TEXT MENU	3. CODES – 2. ENGINEER – 1. ENG1 CODE
	ADDRESS	0000
	OPERATION	000

Programming Parameter

Menu type

Access

### Important Notes!


#### 6.2 Indication

The indication while programming different system parameter is performed in several common types according the structure of the address or operation.



#### - Indication for introducing time values

<b>LCD</b>		Enter the new time using the digit buttons. The time interval varies according the parameter. For values smaller than 10 enter “00” in front of it – for example 005.
<b>LED 32</b>		The zones 14, 15 and 16 show the number of the digits of the parameter. The zones from 1 to 10 show the current set value for every digit, as 10 means 0. The currently set digit is blinking. Use the arrows to review the values set to all digits. For example, the zone 14 is blinking – the first digit of the parameter and its value is 0 (10 lighting on). Move to the right to review the set value for the second digit – zone 15 is blinking and 1 is lighting on. Enter the new time using the digit buttons. Every pressing of a button sets new value and automatically moves the cursor to the right.
<b>LED8/ LED16A</b>		The zones 1, 2 and 3 show the number of the digits of the parameter. LED symbol “V” is lighting on to show that the system is in value programming mode. Lighting on digit button shows the current set value for every digit.

**- Indication for introducing parameter “ENABLE/DISABLE” type**

LCD		<p>“DISABLE” or “ENABLE” is displayed on the screen. Press random digit button or arrows to switch over.</p>
LED 32		<p>The “ENABLE” parameter is set when the zone numbers from 1 to 8 are lighting on; The “DISABLE” parameter is set when all zone numbers are off. Press random digit button or arrows to switch over.</p>
LED8/ LED16A		<p>The zone 1 is blinking and LED symbol “V” is lighting on to show that the system is in value programming mode. The “ENABLE” parameter is set when digit buttons from 0 to 9 are lighting on; The “DISABLE” parameter is set when all digit buttons are off. Press random digit button or arrows to switch over.</p>

**- Indication for introducing option/attribute number**

LCD		<p>The digits of the enabled options/attributes are displayed on the screen. The disabled options are performed with asterisk symbol “*”. To enable/disable an option press the respective digit number.</p>
LED 32		<p>The digits of the enabled options/attributes are lighting on the screen. The disabled options are off. To enable/disable an option press the respective digit number.</p>
LED8/ LED16A		<p>The zone 1 is blinking and LED symbol “V” is lighting on to show that the system is in value programming mode. The digit buttons corresponding to the enabled options/attributes are lighting on. The digit buttons corresponding to the disabled options are off. To enable/disable an option press the respective digit button.</p>

**6.3 Special Symbols in this Manual**

The engineer programming is common for every Eclipse Series control panels. Use the quick tables in the beginning of every menu to check the availability of address numbers for programming and settings. The pictograms for Eclipse series are placed in front of important notes concerning the different models control panels. The pictograms used in the descriptions below have the following meaning:

-  - The option, parameter or setting is available or specific for ECLIPSE 8 control panel.
-  - The option, parameter or setting is available or specific for ECLIPSE 8+ control panel.
-  - The option, parameter or setting is available or specific for ECLIPSE 16 control panel.
-  - The option, parameter or setting is available or specific for ECLIPSE 32 control panel.
-  - The option, parameter or setting is available or specific for ECLIPSE 99 control panel.
-  - The option, parameter or setting is accessible only through LCD keyboard.
-  - The setting is specific when using LED keyboard.
-  - The setting is specific when using LED 8 keyboard.
-  - The setting is specific when using LED 16A keyboard.
-  - Important note concerning programming.
-  - Useful tip.
-  - Example.
-  - The address description continues on the next page.

## 7. ENGINEER MENUS – Programming Tables

### 1. MAINTENANCE MENU

In menu “1. MAINTENANCE” are performed tests and review of memory events in the system.

Quick table for 1. Maintenance Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
1. View Log	0	0	4	0	LOG Review	✓	✓	✓	✓	✓
2. Walk Test	0	0	2	0	Perform walk Test	✓	✓	✓	✓	✓
3. PGM Test	0	0	2	1	Perform PGM Test	✓	✓	✓	✓	✓
4. Comm. Test	0	0	2	3	Perform Communication Test	✓	✓	✓	✓	✓
5. Software Revision	0	0	9	8	Review the Software Revision	✓	✓	✓	✓	✓

The “1. MAINTENANCE” menus are described in details in the following tables.

<b>LOG EVENT</b>	TEXT MENU	1. MAINTENANCE – 1. VIEW LOG
	ADDRESS	0040
	OPERATION	040

#### Reviewing the Memory LOG Events

##### Review of memory LOG events in the system.

The memory LOG file is with different capacity: 1024 (ECLIPSE 8/8+/16/32) and 5000 (ECLIPSE 99) system events. The events recorded in the power independent memory of the control panel can be traced with the help of the arrows. The first event which is visualized is the last recorded.



Use the digit button 2 to review some additional information for the event such as user, zone or area number. Use the digit button 1 to go back to the main screen for memory events review. For correct reading the information use the table for the events in the APPENDIX 1.






In case of using a LED keyboard to review the memory LOG file, keep in mind that the visualization of the memory events, as the user numbers, zones numbers, area numbers and etc, is presented in a binary form as the order is count from right to left side – see the column “Code” of APPENDIX 1, there is given the reference of the LED indication in a decimal form.



##### Examples:

Reviewing the events differs according the type of the used LED keyboard. On the first row of the keyboards (zones from 1 to 8) is displayed a user number, or zone number, or output number, etc, according the type of the event, and on the second row (zones from 9 to 16) is displayed an area number if supported. For LED 8 keyboard the area number is visualized with lighting up buttons. In the example is displayed reviewing of event 41 “Disarming with code” in Eclipse 32 control panel.



Area	Buttons light up
1	6
2	3
3	3+6
4	8
5	6+8
6	3+8
7	3+6+8
8	5

<b>WALK TEST</b>	TEXT MENU	1. MAINTENANCE – 2. WALK TEST
	ADDRESS	0020
	OPERATION	020

Enables functional test of zones. The respective light-emitting diode (LED keyboard) or a number of a zone (LCD keyboard), blinks while the zone is activated (open) in this mode. During the test, the zone activation is accompanied with "Chime" sound signal and with continuous sound for "reject" – open TAMPER zone.

<b>PGM TEST</b>	TEXT MENU	1. MAINTENANCE – 3. PGM TEST
	ADDRESS	0021
	OPERATION	021

Serviceability tests of programmable outputs are carried out in this menu. There are two fields available in the LCD keyboard display. The installer enters the number of PGM\* for test, and the PGM status ON (PGM activation)/OFF (PGM deactivation).



\* PGMs with set activation event 64 (see menu 5. OUTPUTS – 2. PGMs – 01. PGM – 4. ACTIVATION) cannot be tested in this menu.


**During the test is set low or high output level:**

OFF	(NO) The output is switching on high level: +12 V
ON	(NC) The output is switching on low level: 0 V

LED 8

LED 16A

**Important notes:** In operation with LED 8/16A, after entering the menu, the system automatically displays the value setting mode.



The blinking digit performs the value for editing, and lighting on button displays the current set value. To change the value, press a digit button – the cursor moves on the next zone number and so on.

**ECLIPSE 32/99:** The zone number 3 performs the PGM state – ON (all buttons light on) and OFF (all buttons light off). The state is alternatively changed with pressing a random digit button.

<b>COMM TEST</b>	TEXT MENU	1. MAINTENANCE – 4. COMM TEST
	ADDRESS	0023
	OPERATION	023



The performance of the communicator can be directly monitored in this menu.

Before starting the monitoring of the communicator performance, you have to enter a telephone number for the digital communicator (8. COMMUNICATION → 1. DIGITAL COMM → 5. PHONES → 01. PHONE → 1. PHONE NUMBER or at ADDRESS 6010).

The FULL Arm (🔒) button causes test transmission from the communicator to the central station and from the voice dialler to assigned telephone numbers. The 0 button aborts any running communication and deletes the queue of events to be sent. The meaning of the symbols is given below, as the "active state" means permanent lighting of the LEDs (LED keyboard) or a step number (LCD keyboard). After communication has been successfully completed, the keyboard emits a sound signal. Use CANCEL button to exit the menu.

Step	Action
1	Dialling the telephone number.
2	Waiting for "handshake" signal from the monitoring station.
3	Transmitting data to the monitoring station.
4	Waiting for confirmation signal from the monitoring station, "kissoff" signal.
5	Communication process has been completed and all data has been successfully transmitted to the central station.

<b>SW REVISION</b>	TEXT MENU	1. MAINTENANCE – 5. SW REVISION
	ADDRESS	0098
	OPERATION	098



The engineer can review the current software revision of the control panel in this menu.

## 2. SETTINGS MENU

In “2. SETTINGS” menu are performed general settings of the system parameters.

**Attention: Some of the addresses are available for programming only with LCD keyboard!**

**Quick table for 2. Settings Menu**

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
01. Ambush Code	0	0	1	0	Enabling Ambush Code	✓	✓	✓	✓	✓
02. KBD Lock	0	0	1	1	Enabling KBD Lock	×	×	×	✓	✓
02. Chime	0	0	1	2	Enabling Chime Signalization	✓	×	×	×	×
03. Trouble Sounds	0	0	1	3	Trouble Sounds Signalization	✓	✓	✓	✓	✓
04. Conf. Timer	0	0	1	4	Setting Confidential Timer	×	✓	✓	✓	✓
05. AC Delay	0	0	1	5	Setting AC Delay	✓	✓	✓	✓	✓
06. Sound Tamper	0	0	1	6	Enabling Sound Tamper	✓	✓	✓	✓	✓
07. Alarm Delay	0	0	1	7	Enabling Time Delay for the alarm	×	×	×	✓	✓
08. Hardware reset	0	0	3	0	Enabling of System Hardware Reset	✓	✓	✓	✓	✓
09. Part. Default	0	0	3	1	Partial Reset of Menus	✓	✓	✓	✓	✓
1. Settings	[0]				Partial Reset of Settings Menu	✓	✓	✓	✓	✓
2. Codes	[1]				Partial Reset of Codes Menu	✓	✓	✓	✓	✓
3. Inputs	[2]				Partial Reset of Inputs Menu	✓	✓	✓	✓	✓
4. Outputs	[3]				Partial Reset of Outputs Menu	✓	✓	✓	✓	✓
5. Partitions	[4]				Partial Reset of Partitions Menu	✓	✓	✓	✓	✓
6. Schedules	[5]				Partial Reset of Schedules Menu	×	×	×	✓	✓
7. Communication	[6]				Partial Reset of Communication Menu	✓	✓	✓	✓	✓
8. Devices	[8]				Partial Reset of Devices Menu	✓	✓	✓	✓	✓
10. Reset Manager	0	0	3	2	Reset of Main Manager Code (User 01)	✓	✓	✓	✓	✓
11. System Name	0	0	5	0	Enter a name for the system	✓	✓	✓	✓	✓
12. Time	0	0	5	1	Set the actual time	✓	✓	✓	✓	✓
13. Date	0	0	5	2	Set the actual date	✓	✓	✓	✓	✓
14. Menu Style	0	0	9	7	Set the type of the programming menus	✓	✓	✓	✓	✓
15. Standard	0	0	9	6	Set special parameters according EN50131	×	✓	×	✓	✓

<b>AMBUSH CODE</b>	TEXT MENU	2. SETTINGS – 01. AMBUSH CODE
	ADDRESS	0010
	OPERATION	010

**In this menu, the engineer sets the parameter as:**

DISABLE	Ambush code is not supported - the parameter is deactivated.
ENABLE	Ambush code is supported - the parameter is active.

This setting allows users to use an authority code during unauthorized forcing to disarm the system (ambush code).

The ambush code is a personal code that disarms the system but still sends an alarm signal to the central monitoring station to indicate that the user has been forcefully made to disarm the system. After entering the ambush code, the system will be disarmed with no sound signalization from the sirens, but is generated “silent panic” alarm – the event is recorded in the memory LOG file and an alarm message is sent to the central monitoring station.

The ambush code is produced from a personal code by increasing the last digit by one. If the last digit is 9, it is replaced by 0.



*The ambush code for 1234 is 1235, and for 9009 is 9000.*

The parameter status is changed with pressing of random digit button of the keyboard. The change is confirmed with ENTER button.

**Parameter by default: DISABLE**

<b>KBD BLOCK</b>	TEXT MENU	2. SETTINGS – 02. KBD BLOCK
	ADDRESS	0011
	OPERATION	011

**ECLIPSE 32**

**ECLIPSE 99**

**In this menu, the engineer sets the parameter as:**

DISABLE	The keyboard blocking mode is disabled.
ENABLE	The keyboard block mode is enabled – the keyboard buttons will be blocked for 90 seconds if three wrong codes are entered in sequence, a continuous sound signal is heard.

At this address, the engineer allows blocking the keyboard buttons for 90 seconds when three wrong user codes are entered in sequence or an invalid user card is placed in front of the proxy reader.

The access to the system is blocked only for that keyboard through which the three wrong user codes are entered. A continuous sound signal is heard when the access through the keyboard is enabled again.



*The keyboard blocking mode will be activated when the time between entered wrong codes is less than 15 seconds.*

*The access to a blocked keyboard can be restored also after entering of valid engineer code using any other keyboard connected to the system bus.*

In keyboard blocking mode, the LCD keyboard displays a message “Keyboard is locked” and a backward timer shows the remaining time to normal mode.

In keyboard blocking mode, the LED keyboard displays the numbers from 1 to 16 (1 to 8 for LED8) lighting off one by one during the backward timer.

The parameter status is changed with pressing of random digit button of the keyboard. The change is confirmed with ENTER button.

**Parameter by default: DISABLE**

<b>CHIME</b>	TEXT MENU	2. SETTINGS – 02. CHIME
	ADDRESS	0012
	OPERATION	012

**ECLIPSE 8**

**Chime Sound Signalization**

**At this address, you set the parameter as:**

DISABLE	The “Chime” sound signalization is deactivated.
ENABLE	The “Chime” sound signalization is activated.

At this address, the engineer can enable or disable the “Chime” sound signalization activated for opening of Entry-Exit, Follow or Instant type zones. The parameter status can be changed with pressing of random button of the keyboard. The change is confirmed with ENTER button.

**Parameter by default: ENABLED**

<b>TRBL SOUNDS</b>	TEXT MENU	2. SETTINGS – 03. TRBL SOUNDS
	ADDRESS	0013
	OPERATION	013

**Sound signalization for “Technical Problem”**

At this address the engineer can enable or disable the “Trouble sound indication” (two short beeps in every 20 seconds) from the keyboards in Technical Trouble mode – see item 2.2.

**At this address, you set the parameter as:**

DISABLE	The “Trouble sound indication” sound signalization is deactivated.
ENABLE	The “Trouble sound indication” sound signalization is activated.



*It is possible after the initial startup of the system a trouble message for 8. SOUNDER FAULT to be displayed on the screen of LCD keyboards (8 zone number lights on the LED display). That indicates some problems with sounder connected to PGM5. If case the PGM5 is used as a standard output, you have to terminate it with 1kOhm resistor, or to program it as regular output – disable option 1 at ADDRESS 3051.*

*It is also possible, the trouble message 9. INVALID CLOCK will be displayed after the initial startup of the system and after partial or full hardware reset. To clear the message, the installer must set new actual time in menu 12. TIME (address 0051).*

The parameter status can be changed with pressing of random button of the keyboard. The change is confirmed with ENTER button.

**Parameter by default: ENABLED**

<b>CONF. TIMER</b>	TEXT MENU	2. SETTINGS – 04. CONF. TIMER
	ADDRESS	0014
	OPERATION	014

**ECLIPSE 8+**

**ECLIPSE 16**

**ECLIPSE 32**

**ECLIPSE 99**

**“Confidential Mode” Timer**

This parameter is common for all keyboards. Enter a time from 010 to 180 seconds. The “Confidential mode” is a special mode for hiding the information for the activated zones and used areas. The mode is assigned for every keyboard in menu “9. DEVICES - XX. DEVICE - 3. OPTIONS” (address 8xx2 - options 3 and 4) – see the detailed description in Menu 9. Devices.

**ECLIPSE 8+/32/99:** *According the requirements of EN50131 the time interval is limited from 10 to 30 seconds when in menu 2. SETTINGS - 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled. If in this menu is set a bigger time interval (for example 45 seconds) it will be automatically reduced to 30 seconds; if the set time interval is smaller than 30 seconds it will not be changed.*



**Parameter by default: 010 (10 seconds)**

<b>AC DELAY</b>	TEXT MENU	2. SETTINGS – 05.AC DELAY
	ADDRESS	0015
	OPERATION	015

**AC Power Supply Failure Indication Delay**

**Programming of time for delay indication in case of 230 VAC power supply failure.**

Enter a time from 0 to 254 minutes. The set time is confirmed with ENTER button.

In case of using a LED keyboard, you can review the set time with arrow buttons. The blinking zone number indicates a programming mode for that value. A permanently lit zone number shows the current set value (10 means 0). To change it, press other digit button – the cursor automatically moves on the next value to the right.



**Attention: The indication for 230 VAC power supply failure can be completely disabled with setting value 255!**



**ECLIPSE 8+/32/99:** According the requirements of EN50131 the time interval is limited from 00 to 60 minutes when in menu 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled. If in this menu is set a bigger time interval (for example 70 minutes) it will be automatically reduced to 60 minutes; if the set time interval is smaller than 60 minutes it will not be changed.

**Parameter by default: 030 (30 minutes)**

<b>SOUND TMPR</b>	TEXT MENU	2. SETTINGS – 06.SOUND TMPR
	ADDRESS	0016
	OPERATION	016

**Programming of Silent/Audible Sound TAMPER signal**

Programming of silent or audible TAMPER event (a zone TAMPER type or physical tamper-switch is open) when the system is disarmed.

**At this address, you set the parameter as:**

<p>DISABLE <b>Silent TAMPER</b></p>	<p>In case of a TAMPER event:</p> <ul style="list-style-type: none"> <li>- The keyboard indication is activated;</li> <li>- The Outputs with TAMPER type are activated (the ALARM and SIREN outputs type are not activated);</li> <li>- A "TAMPER" alarm message will be sent to monitoring station (via PSTN, GPRS, LAN).</li> </ul>
<p>ENABLE <b>Audible TAMPER</b></p>	<p>In case of a TAMPER event:</p> <ul style="list-style-type: none"> <li>- The indication and the internal buzzer of the keyboards are activated and can be cleared only after entering of valid user code;</li> <li>- A TAMPER alarm signal activated (activation of outputs type ALARM, SIREN and TAMPER);</li> <li>- A TAMPER alarm message will be sent to monitoring station (via PSTN, GPRS, LAN).</li> </ul>

Programming this address will not affect the TAMPER signal when the system is in armed mode. Programming this address will affect the performance of the programmable outputs type SIREN, ALARM and TAMPER, the LED and sound indication of the keyboards and the digital communicator when the system is disarmed. Every pressing of a digital button alternatively changes the enabled/disabled status. The display indication is shown in the table.

**Parameter by default: ENABLE (audible TAMPER)**

<b>ALARM DELAY</b>	TEXT MENU	2. SETTINGS – 07.ALARM DELAY
	ADDRESS	0017
	OPERATION	017

ECLIPSE 32

ECLIPSE 99

**Programming of alarm message delay to monitoring station and siren activation** for 30 seconds or until the programmed entry time is over (the smaller value of both times is taken) in case a zone, out of the entry route, is activated.

**At this address, you set the parameter as:**

DISABLE	The delay is disabled – the system immediately sends an alarm message to the monitoring station (via PSTN, GPRS, LAN) and activates the siren outputs.
ENABLE	30 seconds delay is enabled – the system will delay sending of alarm message and siren outputs activation with 30 seconds when in arming mode: Instant type zone is activated after the Entry-Exit type zone <i>and these two zones are attached to one and the same area</i> . If the Instant type zone is activated first, <i>or it is attached to different area number</i> , the 30 seconds delay is ignored and the sirens are activated immediately. The system will wait 30 seconds for entering of valid user code to disarm or until the programmed entry time is over (the smaller value of both times is taken). If a valid user code is not entered in that period, the system will send an alarm message to the monitoring station and will activate the siren outputs.



*According to the requirements of EN50131 the ALARM DELAY is set automatically as ENABLED when in menu 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled. In that case the setting could not be changed!*

**Parameter by default: DISABLE**

<b>HWR RESET</b>	TEXT MENU	2. SETTINGS – 08.HWR RESET
	ADDRESS	0030
	OPERATION	030

**Hardware Reset Enable**



*Specialized service is required where the hardware RESET is disabled and the engineer code is obscure.*

The parameter status can be changed with pressing of random button of the keyboard.

**At this address, you set the parameter as:**

DISABLE	The hardware reset is not allowed.
ENABLE	The hardware reset is allowed.

**Parameter by default: ENABLE**

<b>SELECT MENU</b>	TEXT MENU	2. SETTINGS – 09.PART DEFAULT
	ADDRESS	0031
	OPERATION	031

**Partial software reset of a programming menu.**

The engineer can make a partial reset and to restore the system parameters for a certain programming menu at this address. Select a menu and press ENTER. The system will ask for a *confirmation password* – enter in sequence the service code 123456 and press ENTER. The system will restore the default settings for the chosen menu only.



*Pay attention that the partial reset of a menu will return the default settings of parameters and options only for this menu and that may cause conflict in operation in other menus. Be careful when applying the partial reset for inputs, users, communication and devices menus, because that may lead to discredit in operation of the whole system configuration.*



To restore the default parameters for a menu, press the respective digit button (in operation with 4- and 3-digit addresses):

- Button 0 – Menu 0. General Settings
- Button 1 – Menu 1. Users
- Button 2 – Menu 2. Zones
- Button 3 – Menu 3. PGM Outputs
- Button 4 – Menu 4. Areas
- Button 5 – Menu 5. Schedules (Timeslots)
- Button 6 – Menu 6. Communicator
- Button 8 – Menu 8. Peripheral Devices

ECLIPSE 32

ECLIPSE 99

<b>RESET MNG</b>	TEXT MENU	2. SETTINGS – 10. RESET MNG
	ADDRESS	0032
	OPERATION	032

**Main Manager Code Reset**

Restoration of the default main manager code (User 01). Buttons 1, 2, 3, 4, 5, 6 are pressed in succession and confirmed with the ENTER button. The system restores the default 0000 manager user code.

**Default Main Manager Code: 0000**

<b>SYSTEM NAME</b>	TEXT MENU	2. SETTINGS – 11. SYSTEM NAME
	ADDRESS	0050
	OPERATION	050

**LCD**

**Programming of the System Name**

The engineer can enter a new system name at this menu. The name has to be up to 16 symbols – letters (small and capital), digits and special symbols, including spaces. The letters can be entered directly using the digit buttons. The cursor moves automatically to the right after choosing of letter or digit, or may be moved manually by the arrows. To enter a digit, press the respective button and hold it for 2-3 seconds. See also item 2.8. Entering text for LCD Keyboard.

Confirm the new system name with ENTER button.

**Default system name: << TTE >>**

<b>TIME*</b>	TEXT MENU	2. SETTINGS – 12. TIME
	ADDRESS	0051
	OPERATION	051

**Setting the built-in clock.** The engineer sets at this address the current time (HH:MM).

**Default setting: [00:00]**

<b>DATE</b>	TEXT MENU	2. SETTINGS – 13. DATE
	ADDRESS	0052
	OPERATION	052

**Setting the system date.** The engineer sets at this address the current date (DD/MM/YY).

**Default setting: [01/01/19]**

\* There is a backup battery mounted on the back side of the Eclipse 32 and Eclipse 99 control panel PCBs. It allows keeping the actual time and date even when both main and backup power supplies are switched off. In the configuration of Eclipse 8, Eclipse 8+ and Eclipse 16 control panels a backup battery for time and date keeping is not included. When both main backup power supplies are switched off, when the panel is powered on again, the installer is required to set the current actual time and date.

<b>MENU STYLE</b>	TEXT MENU	2. SETTINGS – 14. MENU STYLE
	ADDRESS	0097
	OPERATION	097

**Programming Menu Style**

The engineer sets the programming menu style in this menu. Select the type with the arrows or choose a number of the menu style according your preference, as:

Text	Address	Description
Address	1	<b>Programming with 4-digit address menus.</b> In LCD keyboards with the 4-digit address is available also and a short text description. This programming menu style is available in operation with all keyboard models.
Operation	2	<b>Programming with 3-digit operation menus.</b> In LCD keyboards with the 3-digit address is available also and a short text description. This programming menu style is available in operation with all keyboard models.
Text	3	<b>Programming with text menus.</b> The text menus are available as tree-structure. This menu programming style is available only in operation with LCD keyboards.



*If you choose to operate with text menus, they will be available only with LCD keyboards in the system, while the engineer programming via the LED keyboards in the system will be available with 4-digit address menus.*

**Default setting: TEXT/[3]**

<b>STANDARD</b>	TEXT MENU	2. SETTINGS – 15. STANDARD
	ADDRESS	0096
	OPERATION	096

**ECLIPSE 8+**

**ECLIPSE 32**

**ECLIPSE 99**

**Programming of settings for EN50131 Grade 2 Standard**

This menu allows quick configuration of parameters with programming according the requirements of EN50131 Grade 2 Standard. The settings are:

<b>None [0]</b>	Default settings are applied for all menus. No limitation at time intervals and restrictions for changing values are active.														
<b>EN50131 G2 [1]</b>	<p><b>Quick automatic settings according the requirements of EN50131 Grade 2.</b> The following time interval limitations and values are set as defaults:</p> <table border="1"> <thead> <tr> <th>Menu</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>2. SETTINGS – 04. CONF. TIMER</td> <td>The “Confidential mode” timer is limited in interval from 10 to 30 seconds. If the previous set time was bigger (45 seconds for example) then the timer is set to 30 seconds. (Address 0014)</td> </tr> <tr> <td>2. SETTINGS – 05. AC DELAY</td> <td>The “AC Power Supply Failure” indication delay is limited in interval from 00 to 60 minutes. If the previous set time was bigger (65 minutes for example) then it is set to 60 minutes. (Address 0015)</td> </tr> <tr> <td>2. SETTINGS – 07. ALARM DELAY</td> <td>The “Alarm Delay” automatically is set to ENABLED and could not be changed until this option is on. (Address 0017)</td> </tr> <tr> <td>6. PARTITIONS – 5. AREAS – XX. AREA – 02. ENTRY TIME</td> <td>The entry times for area number are limited in interval from 00 to 45 seconds each. If the previous set time was bigger (60 seconds for example) then the entry time is set to 45 seconds (Address 4xx1, where “xx” is an area number from 1 to 16).</td> </tr> <tr> <td>6. PARTITIONS – 5. AREAS – XX. AREA – 06. ON/OFF OPT.</td> <td>The attribute “4. Quick ARM” is set to DISABLED and could not be changed until this option is on (Address 4xx5, where “xx” is an area number from 1 to 16).</td> </tr> <tr> <td>9. DEVICES – XX. DEVICE [Name] – 3. OPTIONS</td> <td>Options “3. Confidential Mode” and 4. “Exit Confidential Mode” are set as ENABLED and could not be changed until this option is on (Address 8xx2, where “xx” is a device number).</td> </tr> </tbody> </table>	Menu	Description	2. SETTINGS – 04. CONF. TIMER	The “Confidential mode” timer is limited in interval from 10 to 30 seconds. If the previous set time was bigger (45 seconds for example) then the timer is set to 30 seconds. (Address 0014)	2. SETTINGS – 05. AC DELAY	The “AC Power Supply Failure” indication delay is limited in interval from 00 to 60 minutes. If the previous set time was bigger (65 minutes for example) then it is set to 60 minutes. (Address 0015)	2. SETTINGS – 07. ALARM DELAY	The “Alarm Delay” automatically is set to ENABLED and could not be changed until this option is on. (Address 0017)	6. PARTITIONS – 5. AREAS – XX. AREA – 02. ENTRY TIME	The entry times for area number are limited in interval from 00 to 45 seconds each. If the previous set time was bigger (60 seconds for example) then the entry time is set to 45 seconds (Address 4xx1, where “xx” is an area number from 1 to 16).	6. PARTITIONS – 5. AREAS – XX. AREA – 06. ON/OFF OPT.	The attribute “4. Quick ARM” is set to DISABLED and could not be changed until this option is on (Address 4xx5, where “xx” is an area number from 1 to 16).	9. DEVICES – XX. DEVICE [Name] – 3. OPTIONS	Options “3. Confidential Mode” and 4. “Exit Confidential Mode” are set as ENABLED and could not be changed until this option is on (Address 8xx2, where “xx” is a device number).
	Menu	Description													
	2. SETTINGS – 04. CONF. TIMER	The “Confidential mode” timer is limited in interval from 10 to 30 seconds. If the previous set time was bigger (45 seconds for example) then the timer is set to 30 seconds. (Address 0014)													
	2. SETTINGS – 05. AC DELAY	The “AC Power Supply Failure” indication delay is limited in interval from 00 to 60 minutes. If the previous set time was bigger (65 minutes for example) then it is set to 60 minutes. (Address 0015)													
	2. SETTINGS – 07. ALARM DELAY	The “Alarm Delay” automatically is set to ENABLED and could not be changed until this option is on. (Address 0017)													
	6. PARTITIONS – 5. AREAS – XX. AREA – 02. ENTRY TIME	The entry times for area number are limited in interval from 00 to 45 seconds each. If the previous set time was bigger (60 seconds for example) then the entry time is set to 45 seconds (Address 4xx1, where “xx” is an area number from 1 to 16).													
	6. PARTITIONS – 5. AREAS – XX. AREA – 06. ON/OFF OPT.	The attribute “4. Quick ARM” is set to DISABLED and could not be changed until this option is on (Address 4xx5, where “xx” is an area number from 1 to 16).													
9. DEVICES – XX. DEVICE [Name] – 3. OPTIONS	Options “3. Confidential Mode” and 4. “Exit Confidential Mode” are set as ENABLED and could not be changed until this option is on (Address 8xx2, where “xx” is a device number).														



When the “EN50131 Grade 2” option is ENABLED, the regular users will not be able to arm the system in case any of the following troubles is active:

- 4. Comm TRBL
- 5. Tamper
- 6. Sysbus Err
- 8. Siren Fault
- a memory event for an Area

**ECLIPSE 99**

**Programming of settings for EN50131 Grade 3 Standard**

This menu allows quick configuration of parameters with programming according the requirements of EN50131 Grade 3 Standard. The settings are:

<b>None [0]</b>	Default settings are applied for all menus. No limitation at time intervals and restrictions for changing values are active.	
<b>EN50131 G2 [1]</b>	<b>Quick automatic settings according the requirements of EN50131 Grade 2.</b> Same described on the previous page.	
<b>EN50131 G3 [2]</b>	<b>Quick automatic settings according the requirements of EN50131 Grade 3.</b> All the restrictions concerning EN50131 Grade 2 are applied, including also:	
	<b>Menu</b>	<b>Description</b>
	3. CODES – 3. CODE LENGTH	The length of all used codes in the system (Users, Managers, Engineer and Maintenance) is automatically set to 6 digits. (Address 1000)



When the “EN50131 Grade 3” option is ENABLED, the remote arming of the system via key-switch will not be possible in case of active memory for event.

**IMPORTANT NOTE:**

In case of switching from “Grade 2/3” settings to “None” the described above parameters will not be set back to their default values. They will stay the same as set for “Grade 2/3” but are freely programmable – no restrictions are applied.

**Default setting: None**

**3. CODES MENU**

In “3. CODES” menu, the engineer programs some parameters and settings for the managers and users in the system.

**Some of the addresses are available for programming only with LCD keyboard!**

**Attention:** The USER 01 is the Chief Manager of the system. The Chief Manager has full rights to operate with manager’s programming menus. The Chief Manager rights cannot be changes. All other users in the system are with freely programmable rights.

The manager has extended rights in the system and can assign user codes and rights, and also to set the date and time, and adjust some options of the keyboards – setting of the buzzer level, brightness, etc.

Every regular user in the system can change its own code only, while the Manager can change all other regular users’ codes. A Manager in the system cannot change other Manager’s code (available for ECLIPSE 32/99).

ECLIPSE Control Panels Series – Codes capability:

Control panel	Max. user codes	Code digits	Chief Manager	Max. Manager codes	Engineer	Maintenance
ECLIPSE 8	8	4	1	1	1	-
ECLIPSE 8+	32	4	1	1	1	-
ECLIPSE 16	32	4	1	1	1	-
ECLIPSE 32	64	4/6	1	Up to 64	1	1
ECLIPSE 99	99	4/6	1	Up to 99	1	1

Quick table for 3. Codes Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
1. Users										
XX. User	1	X	X	Y	XX – User Number; Y - Option					
1. Options	1	X	X	0	Programming of user options	✓	✓	✓	✓	✓
2. Areas	1	X	X	1	Attaching areas to user code	✗	✓	✓	✓	✓
3. Name	1	X	X	2	Entering of unique name for the user	✓	✓	✓	✓	✓
4. Proxy Options	1	X	X	3	User option for operation with proxy card	✓	✓	✓	✓	✓
5. Timeslot	1	X	X	4	Attaching timeslots to user code	✗	✗	✗	✓	✓
6. RC*(A) Funct.	1	X	X	5	Setting the function of Button * or (A)	✗	✓	✓	✓	✓
7. RC(B) Function	1	X	X	6	Setting the function of Button (B)	✗	✓	✓	✓	✓
2. Engineer										
1. ENG1 Code	0	0	0	0	Change the Engineer code	✓	✓	✓	✓	✓
2. ENG2 Code	0	0	0	1	Change the code for Maintenance	✗	✗	✗	✓	✓
3. Code Length	1	0	0	0	Set the length of the code – 4 or 6 digits	✗	✗	✗	✓	✓
4. Code Clone	1	0	0	1	Automatic copying of user code parameters	✗	✗	✗	✓	✓

The menus are described for User 01 (Chief Manager) and User 02.

<b>USER 1 OPTIONS</b>	TEXT MENU	3. CODES – 1. USERS – 01. USER – 1. OPTIONS
	ADDRESS	1010
	OPERATION	110+01

**User 01 Operation rights**



*User code 01 is the Chief Manager in the system and **always has full rights for operation and programming of the system, which cannot be changed or erased!***

**The following options are available for User Code 01:**

<b>1. DISARM Enable</b>	The user has the right to disarm the system.
<b>2. Partial arming Enable</b>	The user has the right to perform partial arming of the system – STAY or SLEEP Arming type.
<b>3. Bypass Enable</b>	The user has the right to perform zone bypassing in system.
<b>4. PROGRAM Enable</b>	The user has the right to change its own access code, to review the memory LOG file, to enable/disable the chime option (ECLIPSE 8).
5. N.A	
6. N.A	
7. N.A	
<b>8. MANAGER Enable</b>	The user code is Manager in the system – it has the right to change other user access codes and to access the Manager’s programming menus.

ECLIPSE 32

ECLIPSE 99

**Default settings: All rights are enabled**

User code	ECLIPSE 8	ECLIPSE 8+	ECLIPSE 16	ECLIPSE 32	ECLIPSE 99
01		1, 2, 3, 4		1, 2, 3, 4, 8	

<b>USER 1 AREAS</b>	TEXT MENU	3. CODES – 1. USERS – 01. USER – 2. AREAS
	ADDRESS	1011
	OPERATION	111+01

**ECLIPSE 8+**

**Association of Areas to User 01**

The engineer associates areas to User code 01 in this menu. The User can operate (arm, disarm, bypass zones) only with area numbers associated to its code. One or several areas can be associated to the user code.

**ECLIPSE 16**

In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”.

**ECLIPSE 32**

In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.

**ECLIPSE 99**

The final configuration of enabled Area numbers is confirmed with ENTER button.



\* To associate/disassociate all areas at the same time press button “0”.

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.



**The User code 01 is always associated to at least one area number. All other user codes will be inactive if there are no associated areas to them, irrespective of the assigned rights at the previous address!**



It is possible the associated area numbers to the control device (keyboard or card reader) to be different according to the area numbers associated to User code 01. In this case, the user code or proximity card can operate only in the common areas for the device and the code. For example, if to the user code all areas are associated in the system, and the associated to the control device areas are 1, 2, 3 and 4, then and the user code can operate only with them.

**Default setting: All Areas**

<b>USER 1 NAME</b>	TEXT MENU	3. CODES – 1. USERS – 01. USER – 3. NAME
	ADDRESS	1012
	OPERATION	112+01

**LCD**

**Programming of the User 01 Name**

The engineer can enter a new name for User 01 in this menu. The name has to be up 16 symbols – letters (small and capital), digits and special symbols, including spaces.

The letters can be entered directly by the digit buttons. The cursor moves automatically to the right after choosing of letter or digit, or may be moved manually by the arrows. To enter a digit, press the respective button and hold it for 2-3 seconds. See also item 2.8. Entering text for LCD Keyboard.

Confirm the new user name with ENTER button.

**Default name: User 01**

<b>USER 1 PROXY</b>	TEXT MENU	3. CODES – 1. USERS – 01. USER – 4. PROXY
	ADDRESS	1013
	OPERATION	113+01

**Assigning rights for operation with proximity card for User code 01**

The engineer assigns rights to the proximity card for operation (arm, disarm) with User code 01. According the settings at the address the user code can perform disarming and/or arming the system.

The enabled option is indicated with “✓” in the text menus or a digit on the LCD display (address, operation menus), or lighting on zone number on the LED display. For LED 8/16A keyboards the set option is indicated with lighting on digit button.

The set options are confirmed with ENTER button.

In address and operation menus, the arming options are set as a combination of options 2 and 3. To enable an option, press the digit button corresponding to its number. The next pressing of the same button will deselect it.



**The options are assigned at address/operation menus as:**

<b>1. DISARM Enable</b>	Authorization for the user code to Disarm the site with a proximity card. DISARM ENABLE (1) – The user code can disarm the site with a proximity card. DISARM DISABLE (*) – The user code cannot disarm the site with a proximity card.			
<b>2. Proxy card ARMING options</b>	The options 2 and 3 are assigned in a certain combination to set the arming mode when using a proximity card:			
<b>3. Proxy card ARMING options</b>	<b>Text menu</b>	<b>Address menu</b>		<b>Arming type</b>
		<b>2</b>	<b>3</b>	
	ARM Disabled	*	*	Not used
	Full ARM	*	3	Full Arming mode
	Stay ARM	2	*	Stay Arming mode
Sleep ARM	2	3	Sleep Arming mode	

**Default settings: DISARM ENABLE; SLEEP ARM**

<b>USER 1 TIMESLOT</b>	TEXT MENU	3. CODES – 1. USERS – 01. USER – 5. TIMESLOT
	ADDRESS	1014
	OPERATION	114+01

**ECLIPSE 32**

**Programming of timeslot for User code 01**

**ECLIPSE 99**

In this menu the installer sets a timeslot number for the User code 01. The user code will be valid for the timeslot duration.

The valid timeslot numbers are from 1 to 8 (Eclipse 32) and from 1 to 16 (Eclipse 99). If the selected access code is not to be restricted by a timeslot, enter 0.

Use the digit buttons to enter the timeslot number. The entered number is confirmed with ENTER. For programming of timeslots, see for details Menu. 7 Timeslot Programming.

**Default settings: 0**

<b>USER 1 RC * (A) FUNCTION</b>	TEXT MENU	3. Codes – 1. Users – 01. User – 6. RC * (A) FUNCTION
	ADDRESS	1015
	OPERATION	115+01

**ECLIPSE 8+**

**Setting of a functionality of button “\*” or “A” of a BRAVO remote key fob**

**ECLIPSE 16**

In this menu the installer sets functionality of the button “\*” of two-way operation BRAVO RC remote key fob, or button “A” of one-way operation remote key fobs BRAVO RC-41 and BRAVO RC-11 enrolled to Eclipse WL wireless expander in the system.

**ECLIPSE 32**

Only one option can be selected for the button “\*” or “A” function of a remote key fob.

**ECLIPSE 99**

For function of button “\*” or “A” can be set one of the following options:

Text menus	Address	Description
Unused	0	The button is not used.
Sleep ARM	1	The button will perform Sleep Arming.
Stay ARM	2	The button will perform Stay Arming.
FIRE Alarm	3	The button will perform Fire panic alarm.
MEDICAL Alarm	4	The button will perform Medical panic alarm.
POLICE Alarm	5	The button will perform Police panic alarm.
PGM Switch	6	Activation of PGM output with set activation event “BRAVO RC btn” (event number 42) – see also menu “5. Outputs – 2. PGMs – XX. PGM – 4. Activation” (address 3013).

In operation with text menus, the option is enabled with button “1” and it is disabled with button “0”. In operation with addresses, the option is enabled with choosing a digit button corresponding to its number. Press ENTER button to confirm.

**Default settings: Unused**

<b>USER 1 RC (B) FUNCTION</b>	TEXT MENU	3. Codes – 1. Users – 01. User – 7. RC (B) FUNCTION
	ADDRESS	1016
	OPERATION	116+01

<b>ECLIPSE 8+</b>	<b>Setting of a functionality of button “B” of a remote key fob</b>
<b>ECLIPSE 16</b>	In this menu the installer sets functionality of the button “B” of one-way operation remote key fob BRAVO RC-41 enrolled to Eclipse WL wireless expander in the system.
<b>ECLIPSE 32</b>	Only one option can be selected for the button “B” function of a remote key fob.
<b>ECLIPSE 99</b>	The options for operation of button “B” are the same described for “6. U1 RC * (A) FUNCTION”. Select the option and confirm the chosen setting with the ENTER button.

**Default settings: Unused**



**Important Note**

Operation with Eclipse WL wireless expander is supported from Eclipse 8+, Eclipse 16, Eclipse 32 and Eclipse 99 alarm control panels, as the number of assigned remote key fobs is as follows:

- Eclipse 8+ – up to 32 remote key fobs
- Eclipse 16 – up to 32 remote key fobs
- Eclipse 32 – up to 64 remote key fobs
- Eclipse 99 – up to 99 remote key fobs

All enrolled BRAVO key fobs are automatically attached to the corresponding User numbers in the system:  
 BRAVO Remote 1 to USER 1,  
 BRAVO Remote 2 to USER 2,  
 ...  
 BRAVO Remote 99 to USER 99

**Attention: Up to 4 different Eclipse WL expanders can be attached to a single Eclipse panel. To USER 1 are assigned all BRAVO key fobs attached to the 1<sup>st</sup> position of the expanders; to USER 2 – all key fobs attached to the 2<sup>nd</sup> position of the expanders, and so on. In this way to a User can be assigned up to 4 different BRAVO remote key fobs, as every of them will operate in the range covered of the expander to which it is attached. Note also, that the functionality of the special buttons “\*”, “A” or “B” will be same for all of the key fobs because the option of their operation is set for the User code number, and not for the key fob itself.**

Compatible remote key fobs BRAVO series for operation with ECLIPSE panels via WEXP wireless expander module:

BRAVO RC	BRAVO RC-41	BRAVO RC-21	BRAVO RC-11
Two-way communication key fob with 4 buttons. - Programmable button “*” Menu: 6. U1 RC * (A) FUNCTION	One-way communication key fob with 4 buttons. - Programmable button “A” Menu: 6. U1 RC * (A) FUNCTION - Programmable button “B” Menu: 7. U1 RC (B) FUNCTION	One-way communication key fob with 2 buttons. - No programmable button.	One-way communication key fob with 1 button. - Single programmable button suitable for panic alarm. Menu: 6. U1 RC * (A) FUNCTION

User codes from 02 to 08/32/64/99 are programmed in an analogical way. The rights of User codes which are set in menu 3. CODES – 1. USERS – 01. USER – 1. OPTIONS (addresses 1xx0; 110 + xx, where “xx” is a user number from 02 to 08/32/64/99), can be enabled or disabled according the system settings.

<b>Uxx OPTIONS</b>	TEXT MENU	3. CODES – 1. USERS – xx. USER – 1. OPTIONS
	ADDRESS	1xx0
	OPERATION	110+xx

**User xx Operation rights** (xx is a user number from 02 to 99, according the panel's type). To select an attribute, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute. In text menus the options are enabled with button 1, and are disabled with button 0.

**The following options are assigned for the User xx Code:**

1. DISARM	DISARMING the site: DISARM ENABLE (1) – the user code has right to disarm the site DISARM DISABLE (*) – the user code has not right to disarm the site
2. PART ARM <b>Partial arming</b>	Partial arming STAY or SLEEP type: PART ARM ENABLE (2) – the user code has right to realize partial arming STAY or SLEEP type PART ARM DISABLE (*) – the user code has not right to realize partial arming STAY or SLEEP type
3. BYPASS <b>Zone Bypassing</b>	Bypassing zones in the site: BYPASS ENABLE (3) – the user code has right to bypass zones BYPASS DISABLE (*) – the user code has not right to bypass zones
4. PROGRAM	Programming – change own code, reviewing the memory log, enabling/disabling the “chime” sound signalization (ECLIPSE 8): PROGRAM ENABLE (4) – the user code can realize programming PROGRAM DISABLE (*) - the user code cannot realize programming
5. N.A	
6. N.A	
7. N.A	
8. MANAGER <b>MANAGER in the system</b>	Manager in the system – can program user codes and rights in the system, reviewing the memory log, zone bypassing: MANAGER ENABLE (8) – the code has Manager rights MANAGER DISABLE (*) – the code has not Manager rights

**ECLIPSE 32**

**ECLIPSE 99**

*When the option 8. MANAGER is enabled, it is obligatory to enable and option 4. PROGRAM!*

*To disable/enable all user operation rights press button “0” – the button alternatively switches over all enabled/all disabled state.*

**Default settings:**

User code	ECLIPSE 8	ECLIPSE 8+	ECLIPSE 16	ECLIPSE 32	ECLIPSE 99
02-08	1, 2	1, 2	1, 2	1, 2	1, 2
09-32	x				
33-64	x	x	x	x	1, 2
65-99					

<b>ENG1 CODE</b>	TEXT MENU	3. CODES – 2. ENGINEER – 1. ENG1 CODE
	ADDRESS	0000
	OPERATION	000

**Engineer code**

This access code has full rights for programming of all engineer menus. After entering the menu, first you have to delete the current code combination with continuous pressing the button “0”. The keyboard will confirm the operation with a sound signal and will wait for entering of a new 4/6\*-digit button (see also the description of address 1000). The new code is confirmed with ENTER button.



*\* ECLIPSE 8/ECLIPSE 8+/ECLIPSE 16 allows operation only with 4-digit access codes.*

**Engineer Code by Default: 7777**

<b>ENG2 CODE</b>	TEXT MENU	3. CODES – 2. ENGINEER – 2. ENG2 CODE
	ADDRESS	0001
	OPERATION	001

ECLIPSE 32

ECLIPSE 99

**Maintenance code**

The Maintenance code can access all engineer programming menus **except the menus for 3. Codes and 8. Communication devices (ADDRESSES 1xxx and 6xxx)**.  
 By default, no code combination for maintenance code is set. After entering the menu, you have to enter new code and confirm with ENTER.  
 To delete the code combination, press for 2-3 seconds the button “0”. The keyboard will confirm the operation with a sound signal and will wait for entering of a new 4/6-digit button (see also the description of menu CODE LENGTH - address 1000). Then confirm with ENTER button.

**Maintenance Code by Default: No Code Combination**

<b>CODE LENGTH</b>	TEXT MENU	3. CODES – 3. CODE LENGTH
	ADDRESS	1000
	OPERATION	100

ECLIPSE 32

ECLIPSE 99

**Code digits’ length**

**The system allows using 4- and 6-digits codes:** engineer, maintenance and users.

Every pressing of a digital button or the arrows alternatively changes the digit number. The set parameter is confirmed with ENTER button.

**At this address is assigned:**

4 digits	The Engineer, Maintenance and Users are using 4-digit access codes.
6 digits	The Engineer, Maintenance and Users are using 6-digit access codes.



**When switching from 4- to 6-digits code, the digits 00 will automatically be added at the end. For example, the 4-digits code 1234 will become 123400.**



**When changing over from 6- to 4-digits code, only the first four figures in the 4-digits code will remain valid. For example, the 6-digits code 123456 will become 1234. Due to risk of coincidence of codes, changing over from 6- to 4-digits code IS NOT RECOMMENDED!**

ECLIPSE 99

According the requirements of EN50131 Grade 3, the code length is set automatically to 6-digits when in menu “15. STANDARD” (address 0096) option EN50131 G3 is enabled. In that case the setting could not be changed!

**Default setting: 4 digits**

<b>CODE CLONE</b>	TEXT MENU	3. CODES – 4. CODE CLONE
	ADDRESS	1001
	OPERATION	101

ECLIPSE 32

ECLIPSE 99

**User Codes Cloning**

This is a menu for copying (cloning) of attributes, rights, areas, timeslots and control options for card readers for user codes. The user access codes are not automatically cloned – they have to be assigned for every one user separately from the Manager’s programming menu. The information for cloning is set in three-digit sections with the following meaning:



**Source Code** – This is the source code which parameters will be copied. *In the example: User 01*  
**First Code to clone** – This is the first code number to which the parameters of the source code will be assigned. *In the example: User 10*  
**Last Code to clone** – This is the last code number to which the parameters of the source code will be assigned. *In the example: User 20*

It is possible to clone only serial number of codes. If it is necessary to clone parameters to one user code only, then enter 00 or the same user code in the “Last Code to clone” field. Press the ENTER button to start the cloning procedure.

## 4. INPUTS MENU

In “4. INPUTS” menu, the engineer programs some parameters and settings for the zones in the system.  
**Some of the addresses are available for programming only with LCD keyboard!**

ECLIPSE Control Panels Series – Zones capability:

Control panel	Max. Zone	Connection styles	Doubling zones
ECLIPSE 8	8	5	✗
ECLIPSE 8+	16	9	✓
ECLIPSE 16	16	5	✗
ECLIPSE 32	32	9	✓
ECLIPSE 99	99	9	✓

Quick table for 4. Inputs Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
1. Wiring	2	0	0	0	Setting the connection style for the system	✓	✓	✓	✓	✓
2. Auto Bypass	2	0	0	1	Setting the zone Auto Bypass	✗	✗	✗	✓	✓
3. Instant	2	0	0	2	Enabling operation with instant zones	✗	✗	✗	✓	✓
4. Pulse Count										
1. Pulses	2	0	0	3	Setting the pulse counter for the zones	✗	✓	✓	✓	✓
5. Timeout	2	0	0	4	Setting the time for pulse counter	✗	✓	✓	✓	✓
5. Zones										
XX. Zone	2	X	X	Y	XX – Zone Number; Y - Option	✓	✓	✓	✓	✓
1. Attach	2	X	X	0	Attaching zones to physical inputs	✗	✓	✓	✓	✓
2. Type	2	X	X	1	Setting the type of the zone	✓	✓	✓	✓	✓
3. Areas	2	X	X	2	Attaching zones to area numbers	✗	✓	✓	✓	✓
4. Options 1	2	X	X	4	Settings of general option for operation	✓	✓	✓	✓	✓
5. Options 2	2	X	X	5	Settings of extended options for operation	✓	✓	✓	✓	✓
6. Key Switch	2	X	X	6	Settings of options for key switch type zone	✓	✓	✓	✓	✓
7. Auxiliary	2	X	X	7	Settings of options for auxiliary type zone	✗	✗	✗	✓	✓
8. Name	2	X	X	8	Entering of unique name for the zone	✓	✓	✓	✓	✓
9. Line Resistance	2	X	X	9	Review the line resistance for the zone	✓	✓	✓	✓	✓
6. Zone Clone	2	0	0	5	Automatic copying of zones parameters	✗	✗	✗	✓	✓

### ZONE WIRING

TEXT MENU 4. INPUTS – 1. WIRING

ADDRESS 2000

OPERATION 200

#### Zone connection styles

Set connection style for zones – it is common for all used zones in the system, including the keyboard zones. Choose a number from the connection style diagrams below according the realized zone connection.

*ECLIPSE 8 supports only single connection in the zones.*

*ECLIPSE 8+ supports both single and doubling connection in the zones.*


*ECLIPSE 16 supports only single connection in the zones.*

*ECLIPSE 32 supports both single and doubling connection in the zones.*

*ECLIPSE 99 supports both single and doubling connection in the zones.*



The connection style diagram is different according the selected number. Follow the diagrams on the next page to choose the used style for connection in your system.



Default connection style: [2]

**ZONE  
AUTO  
BYPASS**

TEXT MENU	4. INPUTS – 2. AUTO BYPASS
ADDRESS	2001
OPERATION	201

ECLIPSE 32

**Number of Activations per Zone for Auto Bypass Mode**

The number of activations (number of alarm cycles from 1 to 9) in one arm mode, which has to be accomplished for a zone with an assigned AUTOBYPASS parameter, is entered at this address. After reaching the set number of activations, the respective zone will be automatically bypassed.

When after disarming the system, it is armed again the respective zone will be armed too.

The 0 value disables the Zone AutoBypass mode even if there is set option "1. AUTOBYPASS" in menu "4. Options 1" (address 2xx4, where xx is the zone number).

ECLIPSE 99

Default setting: [6]

<b>ZONE INSTANT</b>	TEXT MENU	4. INPUTS – 3. INSTANT
	ADDRESS	2002
	OPERATION	202

ECLIPSE 32

ECLIPSE 99

**Enabling of Instant type zones**

The engineer can enable or disable the intrusion of instant type zones during exit time running in this menu. **Attention:** The instant and entry/exit type zones must be attached to one and the same area! Enabling this operating mode would reduce the probability for a false alarm signal to be triggered off by mistake on behalf of the user.

The parameter status can be changed with pressing of random button of the keyboard.

**At this address, you set the parameter as:**

DISABLE	Disabled intrusion in INSTANT type zones during exit time.
ENABLE	Enables intrusion in INSTANT type zones during exit time.

**Default setting: DISABLE**

<b>ZONE PULSE COUNTER</b>	TEXT MENU	4. INPUTS – 4. PULSE COUNT – 1. PULSES
	ADDRESS	2003
	OPERATION	203

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99

**Number of activations in pulse count mode**

The number of pulses in Pulse Count mode is assigned at this address.

Values between 2 and 9 pulses can be entered here.

The 0 value blocks the Pulse Count mode and zone can then function with the regular time for detecting activation.

The working algorithm for a zone in Pulse Count mode is described in menu “4. INPUTS – 5. ZONES – 01. ZONE – 5. OPTIONS 2” (ADDRESS 2015), Attribute 7 “Pulse Count”.

**Default setting: [0]**

<b>ZONE TIME PULSE COUNTER</b>	TEXT MENU	4. INPUTS – 4. PULSE COUNT – 2. TIMEOUT
	ADDRESS	2004
	OPERATION	204

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99

**Time for zones in pulse count mode**

A time for zones in Pulse Count mode is assigned at this address. Enter a time in interval 0-255 sec.

See also menu “4. INPUTS – 5. ZONES – 01. ZONE – 5. OPTIONS 2” (ADDRESS 2015) for details.

**Default setting: [000]**

The following menus are described for Zone 01. The programming of Zones 02-99 is similar, as the maximal number of zones depends on the type of Eclipse panel.

<b>ZONE 1 ATTACH</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 1. ATTACH
	ADDRESS	2010
	OPERATION	210 + 01

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99

**Number of device and Zone 01 input number**

The installer can attach a device number and its input number associated to the zone.

In the maximal configuration of ECLIPSE 8+/16 can be attached and programmed up to 16 zone numbers.

In the maximal configuration of ECLIPSE 32 can be attached and programmed up to 32 zone numbers – that depends on the used connection style and addressed devices.

In the maximal configuration of ECLIPSE 99 can be attached and programmed up to 99 zone numbers – that depends on the used connection style and addressed devices.

*All zone numbers from 01 to 99 are freely programmable – the installer sets (attaches) a number of a device connected to the system bus and a number of its input – see also the examples after the description of this address.*



ECLIPSE 8+  
ECLIPSE 32  
ECLIPSE 99



**IMPORTANT:** The wireless devices from type PIR, MC, FL, FD and SR enrolled to Eclipse WL wireless expander module also must be attached to free zones in the system with type corresponding to their operation (MC – “Entry-Exit” zone type; PIR – “Instant” zone type; FD – “Fire” zone type; FL - “Panic” zone type; SR – “Tamper” zone type for watching for unauthorized opening of the siren’s box).

**When using doubling zone connection in the system** (connection styles 6-9), the second logical zone is differentiated to every physical zone – on the panel, on an expander module, on a keyboard or on a proxy reader. Note: For zones with attached wireless devices the doubling (even if it is used in the system) is not applied.

**In case the PGM4 is programmed as fire zone** in menu “5. OUTPUTS – 1. PGM OPTIONS” (ADDRESS 3000), that zone will be attached to device 01 (the control panel) as number 99. The installer can attach that fire zone to anyone free zone as sets [01] for device and [99] for input/zone number.

**Setting of device and input/zone number for a keyboard**

All ECLIPSE Series keyboards have an additional zone input appropriate for connecting of a magnetic contact or other device. The keyboard zone takes all common setting for zones. To add the keyboard zone to the system configuration you must first to attach it to a zone address and device ID number – the device in this case is the keyboard. According to the system configuration, the keyboard zone can be attached to any free zone in menu “4. INPUTS – 5. ZONES – XX. ZONE – 1. ATTACH” or address 2xx0, where xx is a zone number from 01 to 16/32/99 (depends on the type of the panel).



*Example 1. A keyboard with one on board zone input is enrolled to the control panel as Device 02. Choose a free zone in the system configuration, number 15 for example, where to attach the keyboard zone. Enter in the engineer menu “4. INPUTS - 5. ZONES - 15. ZONE - 1. ATTACH” (or address 2150), enter in sequence the number of the device (02), and the number of the input (01). The screen displays:*



*Example 2. A zone expander with 8 on board zone inputs is enrolled to the control panel as Device 10. Choose a free zone in the system configuration, number 20 for example, where to attach the first zone of the expander. Enter in the engineer menu “4. INPUTS - 5. ZONES - 20. ZONE – 1. ATTACH” (or address 2200), enter in sequence the number of the device (10), and the number of the input (01):*



To use the second zone input of the same expander you have to attach it to the next free zone in the system configuration – for example 21. In analogical way proceed with the other zone inputs of the expander to attach them to free zones in the system configuration.

<b>ZONE 1 TYPE</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 2. TYPE
	ADDRESS	2011
	OPERATION	211 + 01



The type of ZONE 01 is set in this menu.  
**Only one type can be selected for a zone!**

In address menus enter the two-digit number, which corresponds to the number of the desired type. Here is a detailed description of every zone type:

No	Type	Description
00	Unused	The zone is not used.
01	Entry/exit	<b>Entry-Exit zone (1).</b> Provides time to arm and disarm the site. After arming, the detector, which was triggered off in this zone, will not sound an alarm until the programmed EXIT TIME expires for the Area (or Areas) to which the zone is attached.



		<p>No violation of the zone when in armed mode will sound an alarm before the programmed <b>ENTRY TIME 1 (E1)</b> in menu "6. PARTITIONS – 5. AREAS – 1. AREA – 02. ENTRY TIME" expires for the Area (or Areas) to which the zone is attached. A sound signal is activated from the keyboard buzzer during entry and exit time.</p> <p>In SLEEP ARMING mode, the entry-exit type zones become instant and no entry or exit time starts running when violation in the zone occurs – the programmable ALARM and SIREN type outputs, and the communicator are activated at once.</p>
02	Follow	<p><b>Follow zone.</b> An alarm zone which is active only when the site is armed in Full and Stay arming. The zone operates instantaneously and activates the programmable ALARM and SIREN type outputs, and the communicator. Activating the zone during entry or exit time does not cause an alarm event (Note: The follow and the entry-exit zones are attached to one and same area). The entry time will start running if the follow type zone is activated while the system is in SLEEP ARMING mode. When the system is disarmed, the activation of a zone is indicated by blinking of the respective light-emitting diode for the zone (LED keyboards) or displayed zone name and number (LCD keyboards) for the time that the zone remains open (The displayed mode can be disabled for Eclipse 32/99 in the keyboard options menu).</p>
03	Instant	<p><b>Instant zone.</b> An alarm zone which is active only when the site is armed. The zone operates instantaneously and activates the programmable ALARM and SIREN type outputs, and the communicator. When the system is disarmed, the activation of the zone is indicated with active zone number for the time that the zone remains open. An INSTANT type zone can be violated during Exit time running if in menu "4. INPUTS – 3. INSTANT" (Address 2002) the "Enabled Instant" parameter is enabled and the instant and entry-exit zones are attached to one and same area.</p>
04	Fire	<p><b>24 – hour fire type zone.</b> Allows connecting 12V fire detectors to the system. These should avail of a normally closed relay output in inactive status. Any activation of the zone will trigger off SIREN type outputs, the programmable FIRE type outputs and the digital communicator. The 24-hour fire type zones are with the highest priority in the system and are indicated at first place.</p>
05	Panic	<p><b>24 – hour panic type zone.</b> Activating the zone will trigger off the PANIC type outputs; the SIREN type outputs and the digital communicator. The PANIC type zones operate in "Silent panic" mode when "3. Report only" option is set in menu "4. INPUTS - 5. ZONES - XX. ZONE - 5. OPTIONS 2" (address 2xx5), where xx is the zone number. In this case, the zone activation is not indicated on the keyboards (sound or LED indication), and only the digital communicator will send an alarm message to the monitoring station. After entering of valid user code, the MEMORY button (LED) lights on together with the LED/number of the activated zone and area. The indication of the memory can be deleted by entering a valid user code, a manager code or during the next arming.</p>
06	Tamper	<p><b>24 – hour tamper type zone.</b> Activating this zone type triggers off the SIREN output, the programmable TAMPER type outputs and the station communicator. When the system is disarmed and the TAMPER type output is programmed as "DISABLE" in menu "2. SETTINGS – 06. SOUND TMPR" (Address 0016), the activation of the zone will be indicated on the keyboards (without sound indication), and the digital communicator will send an alarm message to the monitoring station. In case the TAMPER type output is programmed as "ENABLED" in menu "2. SETTINGS – 06. SOUND TMPR" (Address 0016), the activation of the zone will cause a sound signal from the keyboards in DISARM mode. When the system is armed the settings in the menu are ignored.</p>

07	Medical	<p><b>24 – hour medical type zone.</b>  Assigning this zone type will set the programmable MEDICAL and SIREN type outputs active and will start the communicator.  The number of the activated zone is displayed irrespective of the system status. The MEDICAL type zones operate in “Silent Panic” mode when the attribute “3. Report only” option is set in menu “4. INPUTS - 5. ZONES - XX. ZONE - 5. OPTIONS 2” (address 2xx5), where xx is the zone number. In this case, the activation of the zone will not be indicated on the keyboards (sound or display indication), and only the digital communicator will send an alarm message to the monitoring station.  After entering of valid user code, the MEMORY button (LED) lights on together with the LED number of the activated zone and area.  The indication of the memory can be deleted by entering a valid user code, a manager code or during the next arming.</p>
08	Key-switch	<p><b>Key-switch type, 24–hour alarm zone.</b>  When this zone type is assigned, the respective panel input is used to transmit the arming and disarming signal with the help of a key-switch.  The installer sets the type of the zone activation:  • With an impulse (PULSE attribute is set in menu “4. INPUTS – 5. ZONES – XX. ZONE – 6. KEY SWITCH” (Address 2xx6);  • Reaction of open or in normal operation mode zone (LATCH attribute is set in menu “4. INPUTS – 5. ZONES – XX. ZONE – 6. KEY SWITCH” (Address 2xx6)).  Arming is possible in Full Arm mode only. Arming will be anticipated only when the system is ready - all zones are inactive.  The additional attributes for key-switch type zone are programmed in menu “4. INPUTS – 5. ZONES – XX. ZONE – 6. KEY SWITCH” (Address 2xx6) where “xx” is the number of the zone.</p>
09	Auxiliary	<p><b>24-hour auxiliary type zone</b>  When this zone type is assigned, respectively a number of AUX attribute should be programmed in menu “4. INPUTS – 5. ZONES – XX. ZONE – 7. AUXILIARY” (ADDRESS 2xx7, where xx is the zone number).  The AUXILIARY type zones operate in “Silent panic” mode when the attribute “3. Report only” option is set in menu “4. INPUTS - 5. ZONES - XX. ZONE - 5. OPTIONS 2” (address 2xx5), where xx is the zone number. In this case, the zone activation is not indicated on the keyboards (sound or LED indication), and only the digital communicator will send an alarm message to the monitoring station.</p>
10	Entry/exit 2	<p><b>Entry-Exit zone (2).</b>  The operation of this type zone is the same as described for Entry-Exit (1), but the in case of opening the zone during arming mode starts running <b>ENTRY TIME 2 (E2)</b> in menu “6. PARTITIONS – 5. AREAS – 1. AREA – 02. ENTRY TIME”.</p>

**Default setting:**

Zone number	Type				
	ECLIPSE 8	ECLIPSE 8+	ECLIPSE 16	ECLIPSE 32	ECLIPSE 99
01	Follow	Entry/Exit (1)	Entry/Exit (1)	Entry/Exit (1)	Entry/Exit (1)
02	Instant	Follow	Follow	Follow	Follow
03	Instant	Unused	Unused	Unused	Unused
04	Instant				
05	Unused				
06					
07	Entry/Exit (1)				
08	Unused				
09-16	x				
17-32	x	x	x	x	
33-99	x	x	x		

<b>ZONE 1 AREAS</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 3. AREAS
	ADDRESS	2012
	OPERATION	212 + 01

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99



**Association of Areas to Zone 01**

According to the system configuration, the engineer associates one or several AREA numbers for operation with ZONE 01. In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”. In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*. The final configuration of enabled Area numbers is confirmed with ENTER button.

\* To associate/disassociate all areas at the same time press button “0”.  
**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.

**The zone will be inactive if there are no associated areas to it!**

**Default setting: AREA 1**

<b>ZONE 1 OPTIONS 1</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 4. OPTIONS 1
	ADDRESS	2014
	OPERATION	214 + 01

- ECLIPSE 32
- ECLIPSE 99



**Setting of Main Attributes (Options 1) for Zone 01**

According to the system configuration, the engineer sets a range of main options for ZONE 01. In text menus the options are enabled with button 1, and are disabled with button 0. In address and operation programming menus, to select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the option. More than one option can be assigned to the zone but that depends on its type.

In address and operation menus you can directly select all option numbers with single pressing button “0” – the button alternatively switches over all enabled/all disabled state.

**The Options from 1 to 7 can be assigned only for certain zone types – see the table below for zone type compatibility!**

Options 1, 7 and 8 are not available in ECLIPSE 8/8+/16 control panel.

**The following Options are available for setting at this address:**

No	Option	Description
1	Auto BYPASS	Authorization for automatic Bypassing the zone after reaching the number of activations per armed mode as set in menu “4. INPUTS - 2. AUTO BYPASS” (address 2001) for an arming mode.
2	BYPASS	Authorization to Bypass a zone. Assigning this attribute to the respective zone will authorize bypass of the zone on behalf of the system user or manager.
3	Stay ARM	The zone is not going to be armed during STAY mode. Assigning this attribute will authorize bypassing of the zone during Stay arming mode.
4	Sleep ARM	The zone is not going to be armed during SLEEP mode. Assigning this attribute will authorize bypassing of the zone during SLEEP arming mode.
5	Force ARM	If when arming the system, the zone is open (activated), then the respective AREA will be armed, and the respective zone will be armed after its restoration.
6	DOUBLE KNOCK	DOUBLE KNOCK type zone. Assigning this attribute to the respective zone authorizes Double Knock mode performance in the zone. A time interval 1 to 5-minute (menu “6. PARTITIONS – 2. DOUBLE KNOCK” or Address 4001) starts when a detector in the zone is activated for the first time when the system is armed. An alarm event is



ECLIPSE 32

ECLIPSE 99

		<p>registered if second detector activation is recorded within this interval in the same or another zone. An alarm event will also be registered if no zone is restored within 15 sec. after the first activation of the zone. <b>Note:</b> The attribute does not apply for zones with assigned BRAVO PIR wireless motion detector. BRAVO PIR can operate in "Double knock" mode ONLY if there is a set jumper on the terminals of its PCB.</p>
7	E/E FINAL	<p>When armed the zone will perform as Entry/Exit type. The system will be armed: A) When the exit time is over; B) 3 seconds after closing the entry-exit zone.</p>
8	FAST/ REGULAR	<p>Programmable sensitivity of the zone – choose between 64ms (fast) and 256ms (regular). <b>Indication in text menus:</b> Enabled REGULAR - "Fast/Regular" Enabled FAST - "✓Fast/Regular" <b>Indication in address menus:</b> <b>LCD:</b> REGULAR - *; FAST - 8 <b>LED:</b> REGULAR - Ⓢ; FAST - Ⓣ</p>

Default setting: 2. BYPASS

<b>ZONE 1 OPTIONS 2</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 5. OPTIONS 2
	ADDRESS	2015
	OPERATION	215 + 01

**Setting of Additional Options 2 for Zone 01**

According the system configuration, the engineer sets a range of additional attributes for ZONE 01. In text menus the options are enabled with button 1, and are disabled with button 0. In address and operation programming menus, to select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the option.

More than one option can be assigned to the zone but that depends on its type.



*In address and operation menus you can directly select all option numbers with single pressing button "0" – the button alternatively switches over all enabled/all disabled state.*



*Options 1, 2, 4, 5 and 7 are not available for ECLIPSE 8.  
Options 1, 2, 4 and 5 are not available for ECLIPSE 8+/16.*

**The following Options are available for setting at this address:**

ECLIPSE 32

ECLIPSE 99

ECLIPSE 32

ECLIPSE 99

No	Option	Description
1	Bell Delay	The siren will be activated when the set Bell Delay time is over. The Bell Delay time can be programmed in menu "6. PARTITIONS – 5. AREAS – XX. AREA – 09. BELL DELAY" (Address 4xx8), where xx is the area number.
2	Fire Delay	The siren outputs will be activated but the communicator starts waiting for 30 up to 90 seconds according the fire delay operation algorithm – refer to the algorithm diagram in APPENDIX 2.
3	Report Only	<b>Silent alarm.</b> Only the programmable outputs PANIC type and the communicator are activated. There is no memory indication on the keyboards. After entering of valid user code the MEMORY button (LED) lights on.
4	Video on ARMED	<b>Video recording of alarm events</b> In case of alarm event the VIDEO ON ARMED outputs will be activated for 1 minute.
5	Write to LOG	<b>Write to LOG file</b> Every zone activation and restoring, irrespective of the system arming status, will be recorded in the system LOG file. The attribute "Write to log" concerns the events OPEN (zone activation) and CLOSE (zone restoring). This attribute is valid for all type of zones except the zones TAMPER type. If the zone is set with TAMPER type in menu "4. INPUTS



- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

		<p>– 5. ZONES – 01. ZONE – 2. TYPE” (Address 2xx1) the programming of this option has no matter.</p>
6	Chime	<p><b>“Chime” mode.</b> This parameter enables the sound signalization (Chime) for opening of an Entry-Exit, Follow or Instant type zone when the system is disarmed.</p>
7	Pulse Count	<p><b>Pulse count mode.</b> This setting provides counting of short impulses 2-4ms for the programmed time in menu “4. INPUTS - 4. PULSE COUNT - 2. TIMEOUT” (Address 2004). The number of impulses is set in menu “4. INPUTS - 4. PULSE COUNT - 1. PULSES” (Address 2003) as value is in range 2 to 9. Setting 0 will disable the Pulse Count mode and the zone can then function with the regular time for detecting activation. When the counter reaches the set number of impulses in the programmed period, an alarm is triggered off. If the number of pulses is not reached in the programmed period, the counter is restored. This operation mode is applicable for connecting of rolling shutters detector to the zone. The wiring diagram for connecting of rolling shutters detector is:</p> <div style="text-align: center;"> </div>
8	Power up Delay	<p>Setting a time period for bypassing the zone after initial power-up of the system (that eliminated the false alarms in the initial power-up of the control panel). The installer can choose between two different time intervals: 30 sec. and 120 sec. for power-up delay indication.</p> <p><b>Indication in text menus:</b> Enabled 30 sec. - “ PowerUp Delay” Enabled 120 sec. - “✓PowerUp Delay”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> 30 sec. - *; 120 sec. - 8 <b>LED:</b> 30 sec. - Ⓢ; 120 sec. - Ⓣ</p>

**Default setting: 8. Power-up delay - 30 sec**

<b>ZONE 1 KEY SWITCH</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 6. KEY SWITCH
	ADDRESS	2016
	OPERATION	216 + 01

**Setting of Key-Switch Attributes for Zone 01**

In this menu are assigned **only attributes for Key-Switch type zone.**

To select an attribute, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute. In text menus the options are enabled with button 1, and are disabled with button 0. More than one attribute can be assigned to a key-switch zone.



*Option 6 is not available for ECLIPSE 8.*

*In address and operation menus you can directly select all option numbers with single pressing button “0” – the button alternatively switches over all enabled/all disabled state.*

**The following Attributes are available for setting at this address:**

No	Attribute	Description
1	Pulse/latch	<p><b>24-hour Key-Switch type zone.</b> <b>With assigned Pulse attribute</b> - every impulse will change alternatively the arming status of the system - respectively armed/disarmed. <b>With assigned Latch attribute</b> - if the zone is activated - the area(s)* is armed, if the zone is in normal operating status - the area(s)* is disarmed. <i>*The area(s) to which the zone is associated.</i></p> <p><b>Indication in text menus:</b> Enabled PULSE - “ Pulse/Latch” Enabled LATCH - “✓Pulse/Latch”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> PULSE - *; LATCH - 1 <b>LED:</b> PULSE - Ⓢ; LATCH - Ⓣ</p>



		<b>Attention:</b> When the "Pulse" attribute is set - if the Zone is attached to more than one area, and at least one of the areas is Armed, the incoming pulse signal will disarm all of the areas attached to this Zone. The next incoming pulse signal will Arm all of the areas associated to the Zone.																						
2	Key SWITCH ARM type	<b>Setting the ARMING type</b> The enabled option is indicated with "✓" in the text menus or a digit on the LCD display (address, operation menus), or lighting on zone number on the LED display. For LED 8/16A keyboards the set option is indicated with lighting on digit button. In address menu the attributes 2 and 3 are set in a certain combination for programming the Arming type of the Key-Switch type zone:																						
3	Key SWITCH ARM type	<table border="1"> <thead> <tr> <th rowspan="2">Text menu</th> <th colspan="2">Address menu</th> <th rowspan="2">Arming type</th> </tr> <tr> <th>2</th> <th>3</th> </tr> </thead> <tbody> <tr> <td>ARM Disabled</td> <td>*</td> <td>*</td> <td>Not used</td> </tr> <tr> <td>Full ARM</td> <td>*</td> <td>3</td> <td>Full Arming mode</td> </tr> <tr> <td>Stay ARM</td> <td>2</td> <td>*</td> <td>Stay Arming mode</td> </tr> <tr> <td>Sleep ARM</td> <td>2</td> <td>3</td> <td>Sleep Arming mode</td> </tr> </tbody> </table>	Text menu	Address menu		Arming type	2	3	ARM Disabled	*	*	Not used	Full ARM	*	3	Full Arming mode	Stay ARM	2	*	Stay Arming mode	Sleep ARM	2	3	Sleep Arming mode
Text menu	Address menu			Arming type																				
	2	3																						
ARM Disabled	*	*	Not used																					
Full ARM	*	3	Full Arming mode																					
Stay ARM	2	*	Stay Arming mode																					
Sleep ARM	2	3	Sleep Arming mode																					
4	DISARM	This attribute determines whether with activation of the zone the system will be disarmed. <b>Indication in text menus:</b> Disabled DISARM - " Disarm ENB" Enabled DISARM - "✓DISARM ENB" <b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 4 <b>LED:</b> Disabled - ④; Enabled - ④																						
5	Normal/ invert	Normal or inverted operation of the zone. In case of setting the INVERT attribute, the system will be disarmed in zone activation. <b>Indication in text menus:</b> Enabled NORMAL - " Normal/Invert" Enabled INVERT - "✓Normal/Invert" <b>Indication in address menus:</b> <b>LCD:</b> NORMAL - *; INVERT - 5 <b>LED:</b> NORMAL - ⑤; INVERT - ⑤																						
6	Ignore Exit Time (Prevent Disarming the system)	When this attribute is set, the disarming via key-switch zone will be disabled during exit time. <b>Indication in text menus:</b> Enabled DISARM - " Ignore Exit Time" Disabled DISARM - "✓Ignore Exit Time" <b>Indication in address menus:</b> <b>LCD:</b> Enabled - *; Disabled - 6 <b>LED:</b> Enabled - ⑥; Disabled - ⑥																						

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

**Default setting: 1. PULSE, 5. NORMAL, 6. Enabled DISARM**

<b>ZONE 1 AUXILIARY</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 7. AUXILIARY
	ADDRESS	2017
	OPERATION	217 + 01

- ECLIPSE 32
- ECLIPSE 99

**Setting of Auxiliary Options for Zone 01**

Only one option AUX can be assigned in this menu - a number from 0 to 9. To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute. In text menus the options are enabled with button 1, and are disabled with button 0. The entered option is confirmed with ENTER.

**The following Attributes are available for setting in this menu:**

No	Attribute	Description
0	<b>24h Burglary alarm zone</b>	With this attribute assigned, the zone will be active irrespective of the arming type and the programmable ALARM and SIREN outputs, and the system communicator will be activated.
1	<b>AC loss</b>	Main power supply lost.



2	<b>Battery low</b>	Low battery charging level.
3	<b>Water leakage</b>	Activated flood detector.
4	<b>Gas detector</b>	Activated gas detector.
5	<b>GSM link trouble</b>	GSM communication failure.
6	<b>Low Bottled Gas Level</b>	Activated low bottled gas detector.
7	<b>High Temperature</b>	High temperature in the premises.
8	<b>Low Temperature</b>	Low temperature in the premises.
9	<b>Loss of Heat</b>	Loss of heat in the premises.

**Default setting: 0. 24h Burglary**

**Table for Availability of Attributes according the zone type:**

	Attribute	Zone Type								
		Entry/Exit	Follow	Instant	Fire	Panic	Tamper	Medical	Key-Switch	AUX
<b>Main</b>	1. AutoBypass	✓	✓	✓	×	×	×	×	×	×
	2. Bypass	✓	✓	✓	✓	✓	✓	✓	×	✓
	3. Stay ARM	✓	✓	✓	×	×	×	×	×	×
	4. SLEEP ARM	✓	✓	✓	×	×	×	×	×	×
	5. Force ARM	×	×	✓	×	×	×	×	×	×
	6. DOUBLE	×	✓*	✓	×	×	×	×	×	×
	7. E/E Final	✓	×	×	×	×	×	×	×	×
	8. Fast/Regular	✓	✓	✓	✓	✓	✓	✓	✓	✓
<b>Add</b>	3. Report only	×	×	×	×	✓	×	✓	×	✓

\* Note: When the attribute "6. DOUBLE" is set for "Follow" zone type, its functionality will be disabled during "Sleep" arming mode!

<b>ZONE 1 NAME</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 8. NAME
	ADDRESS	2018
	OPERATION	218 + 01

**LCD**

**Programming of the Zone 01 Name**

The engineer can enter a new name for Zone 01 in this menu. The name has to be up 16 symbols – letters (small and capital), digits and special symbols, including spaces. The letters can be entered directly by the digit buttons. The cursor moves automatically to the right after choosing of letter or digit, or may be moved manually by the arrows. To enter a digit, press the respective button and hold it for 2-3 seconds. See also item 2.8. Entering text for LCD Keyboard. Confirm the new zone name with ENTER button.

**Default name: Zone 01**

The ZONE numbers from 02 to 99 (depends on the Eclipse panel) are programmed in an analogical way.

<b>ZONE 1 LINE RESIST.</b>	TEXT MENU	4. INPUTS – 5. ZONES – 01. ZONE – 9. LINE RESIST
	ADDRESS	2019
	OPERATION	219 + 01

**LCD**

**Checking the line resistance**

The engineer can check the line resistance of the zone in this menu. It is suitable to perform diagnostics of the zone troubles. The displayed value can vary according the used hardware connection style in the system and has the following meaning:

Connection style	Displayed value	Description	
Single zone connection	1	< 1.5 kΩ	The zone is closed.
		> 1.5 kΩ	The zone is open.
	2	< 0.75 kΩ	The zone is open.
		0.75 – 1.5 kΩ	The zone is closed.
		> 1.5 kΩ	The zone is open.
	3	< 0.75 kΩ	The zone is open.
		0.75 – 1.5 kΩ	The zone is closed.
		> 1.5 kΩ	The zone is open.
	4	< 0.75 kΩ	The zone is closed.
		0.75 – 5.6 kΩ	The zone is open.
		> 5.6 kΩ	Tamper break down.
	5	< 0.75 kΩ	Tamper short-circuit.
0.75 – 1.5 kΩ		The zone is closed.	
1.5 - 5.6 kΩ		The zone is open.	
> 5.6 kΩ		Tamper break down.	
Double zone connection	6	< 0.5 kΩ	The both zones are closed.
		0.5 – 1.5 kΩ	The 1 <sup>st</sup> zone is open, the 2 <sup>nd</sup> zone is closed.
		1.5 – 2.7 kΩ	The 1 <sup>st</sup> zone is closed, the 2 <sup>nd</sup> zone is open.
		2.7 kΩ - ∞	The both zones are open.
	7	< 0.5 kΩ	The both zones are closed.
		0.5 – 1.5 kΩ	The 1 <sup>st</sup> zone is open, the 2 <sup>nd</sup> zone is closed.
		1.5 – 2.7 kΩ	The 1 <sup>st</sup> zone is closed, the 2 <sup>nd</sup> zone is open.
		2.7 – 4.9 kΩ	The both zones are open.
		> 4.9 kΩ	Tamper break down.
	8	< 0.75 kΩ	Tamper short-circuit.
		0.75 – 1.5 kΩ	The both zones are closed.
		1.5 – 2.5 kΩ	The 1 <sup>st</sup> zone is open, the 2 <sup>nd</sup> zone is closed.
		2.5 – 3.7 kΩ	The 1 <sup>st</sup> zone is closed, the 2 <sup>nd</sup> zone is open.
		3.7 – 4.9 kΩ	The both zones are open.
		> 4.9 kΩ	Tamper break down.
	9	< 0.5 kΩ	Tamper short-circuit.
0.5 - 0.75 kΩ		The both zones are closed.	
0.75 - 1.5 kΩ		The 1 <sup>st</sup> zone is closed, the 2 <sup>nd</sup> zone is open.	
1.5 – 2.7 kΩ		The 1 <sup>st</sup> zone is open, the 2 <sup>nd</sup> zone is closed.	
	> 2.7 kΩ	The both zones are open.	

ECLIPSE 8+

ECLIPSE 32

ECLIPSE 99

See also APPENDIX 5.

<b>ZONE CLONE</b>	TEXT MENU	4. INPUTS – 6. ZONE CLONE
	ADDRESS	2005
	OPERATION	205

ECLIPSE 32

ECLIPSE 99

**Zone Cloning**

This is a menu for copying (cloning) of attributes, rights, areas and timeslots from one to several zones.

The information for cloning is set in three sections with the following meaning:

```

2005>Z CLONE
[01]> [02] [05]
    
```

Source Zone                      FirstZone to clone                      Last Zone to clone

**Source Zone** – This is the source zone which parameters will be copied.  
*Zone 01 in the Example.*  
**First Zone to clone** – This is the first zone number to which the parameters of the source zone will be assigned.  
*Zone 02 in the Example.*  
**Last Zone to clone** – This is the last zone number to which the parameters of the source zone will be assigned.  
*Zone 05 in the Example.*

It is possible to clone only serial number of zones. If it is necessary to clone parameters to one zone only, then in the “Last zone to clone” field enter 00 or the same zone. Press the ENTER button to start the cloning procedure.

## 5. OUTPUTS

In “5. OUTPUTS” menu, the engineer programs some parameters and settings for the programmable outputs in the system. **Some of the addresses are available for programming only with LCD keyboard!**

**Attention:** In Eclipse 32/99 control panel, the PGM5 output is powerful (up to 1A) and is set by default as a monitored output for siren connection. If after the initial power-up no siren is connected to the PGM5 output, the system will display a system trouble “8. SIREN FAULT”. In case the PGM5 is not used for siren connection it has to be terminated with 1kOhm resistance or programmed as general output in menu “5. OUTPUTS - 2. PGMs - 01. PGM - 2. OPTIONS” (address 3051). See also the example below and the description of the available options.

### ECLIPSE Control Panels Series – PGM OUTPUTS capability:

Control panel	Max. PGM outputs	Power output, up to 1A	PGM 4 Functionality
ECLIPSE 8	5	1 (PGM 5), non-monitored	Serial link to TP2000 transmitter
ECLIPSE 8+	8	1 (PGM 5), non-monitored	Serial link to TP2000 transmitter
ECLIPSE 16	8	1 (PGM 5), non-monitored	N.A.
ECLIPSE 32	32	1 (PGM 5), monitored	Fire zone for 24V standard fire base
ECLIPSE 99	99	1 (PGM 5), monitored	Fire zone for 24V standard fire base

### Quick table for 5. Outputs Menu

Text Menu	Address	Description	ECLIPSE				
			8	8+	16	32	99
1. PGM Options	3 0 0 0	Set an optional functionality for PGM4	✓	✓	✗	✓	✓
2. PGMs							
XX. PGM	3 X X Y	XX - PGM Number; Y - Option	✓	✓	✓	✓	✓
1. Attach	3 X X 0	Attaching PGMs (06-99) to physical outputs	✗	✓	✓	✓	✓
2. Options	3 X X 1	Settings of general option for operation	✓	✓	✓	✓	✓
3. Areas	3 X X 2	Attaching PGMs to area numbers	✗	✓	✓	✓	✓
4. Activation	3 X X 3	Settings of activation event for the output	✓	✓	✓	✓	✓
5. Act. Param. 1	3 X X 4	Settings of activation Parameter 1 for the output	✓	✓	✓	✓	✓
6. Act. Param. 2	3 X X 5	Settings of activation Parameter 2 for the output	✓	✓	✓	✓	✓
7. Deact. Timer	3 X X 7	Setting a time for deactivation	✗	✗	✗	✓	✓
8. Delay	3 X X 9	Setting a delay for activation	✗	✗	✗	✓	✓

<b>PGM04 OPTIONS</b>	TEXT MENU	5. OUTPUTS – 1. PGM OPTIONS
	ADDRESS	3000
	OPERATION	300

### Programming the operation of PGM 04

The PGM 04 can be configured with different functionality for the ECLIPSE panels at this address. See the descriptions below to orientate in the available option settings.  
 PGM 04 in the ECLIPSE 8/8+ control panel can be used as a general programmable output or for serial connection to TP2000 radio transmitter.

The serial link is realized with connection between the AC terminal of the transmitter and PGM 04 at the control panel.

**Note:** In Eclipse 8+ control panel transmitting of alarm events is available only for Area 1!

**In this menu for ECLIPSE 8/8+ you set the option:**

ECLIPSE 8

ECLIPSE 8+

<b>Text menu:</b> ✓SERIAL LINK	The serial link between the control panel and TP2000 transmitter is enabled. Press button 2 to enable the option – the digit is displayed on the LCD screen or lights on the LED display (for LED8/16A button 2 is lighting). Next pressing of the same button will disable the option – an asterisk (*) is displayed on the LCD screen and no zone number on the LED display is lighting (for LED8/16A button 2 is off).
<b>Address menu:</b> (2)	

PGM 04 in the ECLIPSE 32/99 control panel can be used as a general programmable output or for two-wire connecting of fire detectors using B24 fire base.

**At this address for ECLIPSE 32/99 you set the option:**

ECLIPSE 32

ECLIPSE 99

<b>Text menu:</b> ✓FIRE OUTPUT	The fire zone provides two-wire connection using B24 fire bases. Press button 1 to enable the option – the digit is displayed on the LCD screen or lights on the LED display (for LED8/16A button 1 is lighting). Next pressing of the same button will disable the option – an asterisk (*) is displayed on the LCD screen and no zone number on the LED display is lighting (for LED8/16A button 1 is off).
<b>Address menu:</b> (1)	



In case the PGM4 is programmed as fire zone in Eclipse 32/99 control panel, that zone will be attached to Device 01 (the control panel) as zone number 99. The installer can attach that fire zone to anyone free zone as at the as programs [01] for device and [99] for input/zone number.

**2.2K resistor must be connected at the end of the fire line.**



**ATTENTION:** When the PGM04 is set as a SERIAL LINK or FIRE OUTPUT, the general programming menus for it are not available (addresses 304x). When you switch over from SERIAL LINK or FIRE OUTPUT to regular PGM option the settings in the relative programming menus for PGM04 are reset to the default values.

**Default: PGM 04 is configured as general output**

<b>PGM 01 ATTACH</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 1. ATTACH
	ADDRESS	3010
	OPERATION	310 + 01

**Number of device and PGM 01 output number**

The installer can review the device number and its output number associated to the PGM 01 output.

All PGM outputs from 01 to 05 (the PGMs on the control panel PCB) are fixed and cannot be changed. They are displayed as:

PGM 01: [1] [1] – The output is attached to the 1<sup>st</sup> output of device 01 (the control panel);

PGM 02: [1] [2] – The output is attached to the 2<sup>nd</sup> output of device 01 (the control panel), and so on.

ECLIPSE 8+

ECLIPSE 16

PGMs from 06 to 08 can be on board PGM of a keyboard (LCD 32 or LCD 32S) or a proxy reader (PRX). They can be freely programmable according the system configuration – see the examples after this address description.

ECLIPSE 32

ECLIPSE 99

PGMs from 06 to 32/99 (according the panel) can be on board PGM of an expander (ZEXP or PEXP), or a keyboard (LCD 32 or LCD 32S), or a proxy reader (PRX). They can be freely programmable according the system configuration – see the examples after this address description.

In the maximal configuration of ECLIPSE 32/99 can be attached and programmed up to 32/99 output numbers – that depends on the number of used PGM expander modules.

**IMPORTANT:** The wireless sirens BRAVO SR enrolled to Eclipse WL wireless expander module must be attached to free PGM addresses in the system with set “Siren” type – see menu “5. OUTPUTS - 2. PGMs - 01.PGM - 2. OPTIONS” (address 3xx1, option 1).

**Setting of device and output number for a keyboard or expander module**

The LCD 32 and LCD 32S ECLIPSE Series keyboards have and additional PGM output appropriate for connecting of control or signal devices. The keyboard PGM takes all common setting for PGM outputs. To add a keyboard PGM output to the system configuration it must be first attached to a PGM address and device – the device in this case is the keyboard. According to the system





configuration the keyboard PGM can be attached to any free PGM number, where xx is a PGM number from 06 to 99, depending on the type of the control panel.

*Example 1. A keyboard with one on board PGM output is enrolled to the control panel as Device 02. Choose a free PGM address (06 or greater) in the system configuration, number 15 for example, where to attach the keyboard PGM. Enter in the engineer programming menu "5. OUTPUTS – 2. PGMs - 15.PGM - 1. ATTACH" (or address 3150), enter in sequence number of devices 02, and output number 01. The screen displays:*



*Example 2. A PGM expander with 8 on board PGM outputs is enrolled to the control panel as Device 10. Choose a free PGM address (06 or greater) in the system configuration, number 20 for example, where to attach the first output of the expander. Enter in the engineer programming menu "5. OUTPUTS - 2. PGMs - 20.PGM - 1. ATTACH" (or address 3200), enter in sequence number of devices 10, and output number 01. The screen displays:*



To use the second PGM output of the same expander you have to attach it to other free PGM address in the system configuration – for example 21. Then in menu 21.PGM you should enter in sequence number of device 10 and output number 02. In analogical way, proceed with the other PGM outputs of the expander to attach them to free PGM addresses in the system configuration.



*The attached PGM outputs cannot be programmed for operation as a fire zone like PGM4.*

The following menus are described for PGM 01. The programming of PGM 02-99 is similar, as the maximal number of PGM outputs depends on the type of Eclipse panel.

<b>PGM 01 OPTIONS</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 2. OPTIONS
	ADDRESS	3011
	OPERATION	311 + 01

**Programming of PGM 01 Options**

The engineer sets a number of options for operation of the PGM 01 in this menu.

To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute.

In text menus the options are enabled with button 1, and are disabled with button 0.

More than one option is available to set. The selected options are confirmed with ENTER button.



*Pay attention that both of the option statuses are used – see the description of the options in the table below. The option numbers 3, 4 and 5 are available for ECLIPSE 32/99 control panel only.*

**The following Options are available for setting:**

No	Option	Description
1	SIREN	<p>The option concerns the operation of PGM 01 as output. With setting this option, the PGM 01 takes all common settings for sirens in the system and the settings for activation and deactivation events are not used. The output is activated, when there is an alarm event in zones associated to areas assigned to PGM 01 in menu "5. OUTPUTS - 2. PGMs - 01.PGM - 3. AREAS".</p> <p><b>Indication in text menus:</b>                      Enabled PGM - " SIREN"                      Enabled SIREN - "✓SIREN"</p> <p><b>Indication in address menus:</b>                      LCD: PGM - *; SIREN - 1                      LED: PGM - ①; SIREN - ①</p>
2	INVERT	<p>The option concerns the active state of PGM 01. The polarity of the active state can be NORMAL or INVERT:</p>



ECLIPSE 32  
ECLIPSE 99

		<table border="1"> <tr> <td><b>NORMAL</b></td> <td>(NO) The active state of the output is at high level: +12 V</td> </tr> <tr> <td><b>INVERT</b></td> <td>(NC) The active state of the output is at low level: 0 V</td> </tr> </table> <p><b>Indication in text menus:</b> Enabled NORMAL - " INVERT" Enabled INVERT - "✓INVERT"</p> <p><b>Indication in address menus:</b> <b>LCD:</b> NORMAL - *; INVERT - 2 <b>LED:</b> NORMAL - ②; INVERT - ②</p>	<b>NORMAL</b>	(NO) The active state of the output is at high level: +12 V	<b>INVERT</b>	(NC) The active state of the output is at low level: 0 V
<b>NORMAL</b>	(NO) The active state of the output is at high level: +12 V					
<b>INVERT</b>	(NC) The active state of the output is at low level: 0 V					
3	DELAY* (Setting the time unit sec/min)	<p>This option concerns the set value in menu "5. OUTPUTS – 2. PGMs – 01. PGM – 8. DELAY" (Address 3019) - time delay for activation of PGM 01.</p> <p><b>Indication in text menus:</b> Enabled SECONDS - " DELAY" Enabled MINUTES - "✓DELAY"</p> <p><b>Indication in address menus:</b> <b>LCD:</b> SECONDS - *; MINUTES - 3 <b>LED:</b> SECONDS - ③; MINUTES - ③</p>				
4	PULSED FIRE	<p>This option is available when the PGM 01 is set as a siren output. It is activated only in case of an alarm signal from a FIRE zone type.</p> <p>When the option is enabled, the output operates in a specific working mode:</p> <p><b>Indication in text menus:</b> Disabled - " PULSED FIRE" Enabled - "✓PULSED FIRE"</p> <p><b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 4 <b>LED:</b> Disabled - ④; Enabled - ④</p>				
5	DEACT. TIMER* (Setting the time unit sec/min)	<p>This option concerns the set value in menu "5. OUTPUTS - 2. PGMs - 01.PGM - 7.DEACT TIMER" (Address) 3017 - deactivation timer for PGM 01:</p> <p><b>Indication in text menus:</b> SECONDS - " DEACT.TIMER" MINUTES - "✓DEACT.TIMER"</p> <p><b>Indication in address menus:</b> <b>LCD:</b> SECONDS - *; MINUTES - 5 <b>LED:</b> SECONDS - ⑤; MINUTES - ⑤</p>				



\* NOTE: The option is not applicable when the PGM is programmed as Siren output.

**Default settings: 1. GENERAL OUTPUT, 2. POLARITY NORMAL (+12V), 3. DELAY sec, 4. PULSED FIRE DISABLED, 5. DEACT. TIMER sec.**




By default, PGM 05 is programmed as a siren output. If after the initial power-up of the control panel (Eclipse 32/99), no siren is connected to PGM 05 output, the system will display a trouble message "8. SIREN FAULT". In case the PGM 05 will be used as a general output, the setting for PGM 05 must be changed. You can leave the set by default option, but to void the displayed trouble message in that case you have to terminate the PGM 05 output with 1kOhm resistance – you can find one in the supplied spare parts kit.




Example with using text menus

Select in sequence: 5. OUTPUTS – 2. PGMs – 05. PGM – 2. OPTIONS. The screen displays:



Example with using 4-digit address menus:



<b>PGM 01 AREAS</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 3. AREAS
	ADDRESS	3012
	OPERATION	312 + 01

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

**Association of Areas to PGM 01**

According the system configuration, the engineer associates one or several AREA numbers for operation with PGM 01.  
 In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”.  
 In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.  
 The final configuration of enabled Area numbers is confirmed with ENTER button.



\* To associate/disassociate all areas at the same time press button “0”.

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.



**The PGM will be inactive if there are no associated areas to it!**

**Default setting: AREA 1**

In the next menus are set a number of an activation event for PGM 01 output and supplementary parameters depending on the set event – for zones, areas, users, troubles or other special ones.  
 The programmed activation events make sense when the PGM 01 output is programmed as general output — see the description of menu “5. OUTPUTS – 2. PGMs – XX. PGM – 2. OPTIONS”.

The types of the activation events are described in details in Table 1.

<b>PGM 01 ACTIVATION</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 4. ACTIVATION
	ADDRESS	3013
	OPERATION	313 + 01

**Programming a number of activation event for PGM 01**

Choose the type of activation (text menu) event or its corresponding number (address and operation menus) according the Table 1. To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute.  
 In text menus the options are enabled with button 1, and are disabled with button 0.  
 Only one activation event is possible to set.  
 Press the ENTER to confirm.



*The default content of the next two menus: 5. ACT. PARAM 1 and 6. ACT. PARAM 2 (addresses 3014 and 3015), depends on the set number in this menu.*

**Default setting: 20 – Area Arm**

<b>PGM 01 ACT. PARAM 1</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 5. ACT. PARAM 1
	ADDRESS	3014
	OPERATION	314 + 01

**Programming of Parameters 1 of the activation event for PGM 01**

The type of Parameters 1 depends on the set activation event in menu 4. ACTIVATION – see Table 1 for details.

**Default setting: All parameters for event 20**

<b>PGM 01 ACT. PARAM 2</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 6. ACT. PARAM 2
	ADDRESS	3015
	OPERATION	315 + 01

**Programming of Parameters 2 of the activation event for PGM 01**

The type of Parameters 2 depends on the set activation event in menu 4. ACTIVATION – see Table 1 for details.

**Default setting: 0**

<b>PGM 01 DEACT. TIMER</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 7. DEACT TIMER
	ADDRESS	3017
	OPERATION	317 + 01

**ECLIPSE 32**

**ECLIPSE 99**

**Deactivation timer for PGM 01** – setting a time for deactivation the event programmed in menu “5. OUTPUTS – 2. PGMs – XX. PGM – 4. ACTIVATION”.

A deactivation timer for the programmed event is set in this menu. The state of PGM 01 will restore after the set time is over. The engineer enters time in range 000 – 255 as the time unit (seconds or minutes) depends on the settings in “5. OUTPUTS – 2. PGMs – XX. PGM – 2. OPTIONS”, option 5. By default, the programmed time unit is in seconds.

**Default setting: [000]**

<b>PGM 01 DELAY</b>	TEXT MENU	5. OUTPUTS – 2. PGMs – 01. PGM – 8. DELAY
	ADDRESS	3019
	OPERATION	319 + 01

**ECLIPSE 32**

**ECLIPSE 99**

**Time delay for activation of PGM 01**

A time delay for the programmed in menu “5. OUTPUTS – 2. PGMs – XX. PGM – 4. ACTIVATION” event is set at this address. The activation of PGM 01 will be delayed in time set in range 000 – 255 as the time unit (seconds or minutes) depends on the settings at “5. OUTPUTS – 2. PGMs – XX.PGM – 2. OPTIONS”, option 3. By default, the programmed time unit is in seconds.

**Default setting: [000]**



**TABLE 1. Events Type**

*In case of setting of activation event and missing deactivation event (0), the PGM output restores in the way described for the activation event!*

	ADDRESS: 3xx3 - Activation	ADDRESS: 3xx4 – Set Parameter 1	ADDRESS: 3xx5 – Set Parameter 2
00	The output is not used		
<b>Event No</b>	<b>ZONE Event - Description</b>	<b>PARAMETERS 1</b>	<b>PARAMETERS 2</b>
01	<b>Zone Open</b> Activated on “OR” function (if at least one of the set area numbers is open the PGM is activated) Deactivated on “AND” function (when all of the set area numbers are closed the PGM is restored)	Enter zone number “FROM”	Enter zone number “TO” <i>If “00” is entered – not used, operates only “FROM”</i>
02	Not used	-	-
03	<b>Zone Bypassing</b> Activated on “OR” function (if at least one of the set area numbers is bypassed the PGM is activated, with no sense of the way of bypassing) Deactivated on “AND” function (when all of the set area numbers are not bypassed the PGM is restored)	Enter zone number “FROM”	Enter zone number “TO” <i>If “00” is entered – not used, operates only “FROM”</i>
04-07	Not used	-	-
08	<b>Zone Tamper</b> Activated on “OR” function (if at least one of the set area numbers is with open tamper the PGM is activated) Deactivated on “AND” function (when all of the set area numbers are with closed tamper the PGM is restored)	Enter zone number “FROM”	Enter zone number “TO” <i>If “00” is entered – not used, operates only “FROM”</i>
09-11	Not used	-	-
12	<b>Zone in Alarm</b>	Enter zone number “FROM”	Enter zone number “TO” <i>If “00” is entered – not used, operates only “FROM”</i>

ADDRESS: 3xx3 - Activation		ADDRESS: 3xx4 – Set Parameter 1	ADDRESS: 3xx5 – Set Parameter 2
	Activated on “OR” function (a signal from protected areas from type Entry-Exit, Follow and Instant, PGM is activated) Deactivated on “AND” function (when all of the set zone numbers are alarm restored the PGM is restored too)		
13	Not used		
14	<b>Zone in Fire Alarm</b> Activated on “OR” function (if at least one of the set area numbers is in fire alarm the PGM is activated) Deactivated on “AND” function (when all of the set area numbers are fire alarm restored the PGM is restored too)	Enter zone number “FROM”	Enter zone number “TO” If “00” is entered – not used, operates only “FROM”
15	Not used		
16	<b>Zone in Medical Alarm</b> Activated on “OR” function (if at least one of the set area numbers is in medical alarm the PGM is activated) Deactivated on “AND” function (when all of the set area numbers are medical alarm restored the PGM is restored too)	Enter zone number “FROM”	Enter zone number “TO” If “00” is entered – not used, operates only “FROM”
17-19	Not used	-	-
Event No	AREA Event - Description	PARAMETERS 1	PARAMETERS 2
20	<b>Area Arm</b> Activated on “OR” function (if at least one of all area numbers is armed the PGM is activated) Deactivated on “AND” function (when all area numbers are disarmed the PGM is restored)	Enter the arming type: 1 – FULL arming 2 – STAY arming 3 – SLEEP arming  <b>All arming types are enabled by default.</b>	-
21-26	Not used	-	-
27	<b>Alarm in Area</b> Activated on “OR” function (if at least one area number is in alarm the PGM is activated) Deactivated on “AND” function (when all area numbers are alarm restored the PGM is restored too)	Enter the alarm type: 1 – Burglary alarm 2 – Fire alarm 3 – Panic alarm 4 – Tamper alarm 5 – Medical alarm 6 – Ambush code  <b>All alarm types are enabled by default.</b>	-
28	Not used		-
29	<b>Panic Alarm in Area</b> Activated on “OR” function (if at least one area number is in panic alarm the PGM is activated) Deactivated on “AND” function (when all area numbers are panic alarm restored the PGM is restored too)	Enter the panic type: 1 – Silent panic 2 – Sound panic 3 – Silent medical 4 – Sound medical 5 – Fire  <b>All panic types are enabled by default.</b>	-
30-35	Not used	-	-
Event No	CODE Events - Description	PARAMETERS 1	PARAMETERS 2
36	<b>Valid User Code Enter</b> Activated on “OR” function (when a valid user code is entered the PGM is activated) Deactivation on time - 5 sec.	Enter the number of user code to start “FROM”.  <i>To set a single user code, enter 00 at the address for PARAMETERS 2. To set all possible user codes, enter 00 for both addresses PARAMETERS 1 and PARAMETERS 2.</i>	Enter the number of user code to end “TO”.

ADDRESS: 3xx3 - Activation		ADDRESS: 3xx4 – Set Parameter 1	ADDRESS: 3xx5 – Set Parameter 2
37	<b>Ambush Code Enter</b> Activated on "OR" function (when an ambush code is entered the PGM is activated) Deactivation on time - 5 sec.	Enter the number of user code to start "FROM".	Enter the number of user code to end "TO".
		<i>To set a single user code, enter 00 at the address for PARAMETERS 2. To set all possible user codes, enter 00 for both addresses PARAMETERS 1 and PARAMETERS 2.</i>	
38	<b>Blocked Keyboard</b> Activated when 3 non valid user codes are entered in sequence. Deactivation on time - 5 sec.  <i>NOTE: The keyboard blocking must be enabled at address 0011.</i>	-	-
39	<b>Valid Proxy</b> <i>Only for those cases when the proxy card and the PGM output have common areas and at least one of them is disarmed.</i> Activated on "OR" function (when a valid proximity card is placed in front of the card reader the PGM is activated). Deactivation on time - 5 sec.	Enter the number of proximity card to start "FROM".	Enter the number of proximity card to end "TO".
		<i>To set a single user code, enter 00 at the address for PARAMETERS 2. To set all possible user codes, enter 00 for both addresses PARAMETERS 1 and PARAMETERS 2.</i>	
40	<b>Invalid Proxy</b> Deactivation on time - 5 sec.	-	-
41	<b>Valid RC (remote key fob)</b> Activated on "OR" function (when a button of a valid RC is pressed, the PGM is activated). Deactivation on time – 5 sec.	Enter the number of RC to start "FROM".	Enter the number of RC to end "TO".
		<i>To set a single RC, enter 00 at the address for PARAMETERS 2. To set all possible RCs, enter 00 for both addresses PARAMETERS 1 and PARAMETERS 2.</i>	
42	<b>BRAVO RC Button</b> Activated on "OR" function (when a button of a valid BRAVO remote key fob is pressed, the PGM is activated). Deactivation on time – 5 sec.	Enter the number of BRAVO RC to start "FROM".	Enter the number of BRAVO RC to end "TO".
		<i>To set a single BRAVO remote key fob, enter 00 at the address for PARAMETERS 2. To set all possible remote key fobs, enter 00 for both addresses PARAMETERS 1 and PARAMETERS 2.</i>	
43-46	Not used	-	-
Event No	TROUBLE Event – Description	PARAMETERS 1	PARAMETERS 2
47	<b>System Fault</b> Activated on "OR" function (if at least one system trouble is present the PGM is activated) Deactivated on "AND" function (when no system troubles are present)	Enter the trouble type: 1 – AC power loss 2 – Battery loss 3 – Blown fuse 4 – Communication trouble 5 – Tamper 6 – System bus error 7 – Fire line failure 8 – Siren fault  <b>All system troubles are enabled by default.</b>	Enter the trouble type (see item 2.2 – Table of system faults): 1 (Fault 9) – Invalid time and date 2 (Fault 10) – Wireless device trouble 3 (Fault 11) – Radio jamming of the wireless expander 4 (Fault 12) – Problem with the power supply of an expander module.  <b>All system troubles are enabled by default.</b>
		-	-
48-54	Not used	-	-
Event No	Special Events – Description	PARAMETERS 1	PARAMETERS 2
55	<b>Engineer menu entry</b> The PGM is activated in Engineer menu entry. The PGM is restored in Engineer menu exit.	-	-
		-	-
56 – 58	Not used	-	-
59	<b>"Chime" Sound Signal</b> Activated on "OR" function (there is "Chime" activated in at least one area)	-	-

ADDRESS: 3xx3 - Activation		ADDRESS: 3xx4 – Set Parameter 1	ADDRESS: 3xx5 – Set Parameter 2
	Deactivation on time – 5 sec.		
60	<b>Video on armed</b> Activated in case of violation in an instant zone with "Video on armed" set option.  Deactivation on time – 1 minute.	-	-
61	<b>Fire Detector Reset</b> The PGM is activated when the Memory log file is cleared after entering of valid codes with rights for operation in the respective area.  Deactivation on time – 5 sec.	-	-
62	<b>Timeslot activation</b> Follows the activation of the respective timeslot number.	Enter a timeslot number from: Eclipse 32: from 1 to 8 Eclipse 99: from 1 to 16	-
63	Not used		
64	<b>Remote control</b> <i>Activation and deactivation (restore) of the PGM output over communication module (LAN, GPRS, VD/DTMF, ARGUS, etc).</i>	-	-
65	Not used		
66	<b>Alarm or entry time</b>	-	-
67-72	Not used	-	-



Table for the available events in Eclipse control panels:

Event	Description	ECLIPSE 8	ECLIPSE 8+	ECLIPSE 16	ECLIPSE 32	ECLIPSE 99
00	NOT USED	✓	✓	✓	✓	✓
01	ZONE OPEN	x	✓	✓	✓	✓
03	ZONE BYPASS	x	x	x	✓	✓
08	ZONE TAMPER	x	x	x	✓	✓
12	ZONE IN ALARM	x	✓	✓	✓	✓
14	ZONE IN FIRE	x	x	x	✓	✓
16	ZONE IN MEDICAL	x	x	x	✓	✓
20	AREA ARM	✓	✓	✓	✓	✓
27	ALARM IN AREA	✓	✓	✓	✓	✓
29	PANIC IN AREA	✓	✓	✓	✓	✓
36	VALID CODE ENTER	x	x	x	✓	✓
37	AMBUSH CODE	✓	✓	✓	✓	✓
38	BLOCK KBD	x	x	x	✓	✓
39	VALID PROXY	✓	✓	✓	✓	✓
40	INVALID PROXY	x	x	x	✓	✓
41	VALID REMOTE KEY FOB	x	✓	✓	✓	✓
42	BRAVO RC Button	x	✓	✓	✓	✓
47	SYSTEM FAULT	✓	✓	✓	✓	✓
55	ENG. MENU ENTRY	x	✓	✓	✓	✓
59	CHIME EVENT	x	x	x	✓	✓
60	VIDEO ON ARMED	x	x	x	✓	✓
61	FIRE RESET	✓	✓	✓	✓	✓
62	TIMESLOT	x	x	x	✓	✓
64	REMOTE CONTROL*	✓	✓	✓	✓	✓
66	ALARM OR ENTRY TIME	✓	✓	✓	x	x

\* Note: The event cannot be tested in menu 1. MAINTENANCE – 3. PGM TEST (address 0021).

## 6. PARTITIONS

In “6. PARTITIONS” menu, the engineer programs some parameters and settings for the available partitions (areas) in the system. **Some of the addresses are available for programming only with LCD keyboard!**

**Attention:** In ECLIPSE 8 control panel is available only one area in the system – AREA 01.

ECLIPSE Control Panels Series – AREA capability:

Control panel	Available AREAS
ECLIPSE 8	1
ECLIPSE 8+	3
ECLIPSE 16	3
ECLIPSE 32	8
ECLIPSE 99	16

Quick table for 6. Partitions Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
1. ACCOUNT LENGTH	4	0	0	0	Set the length of the account number	✓	✓	✓	✓	✓
2. DOUBLE KNOCK	4	0	0	1	Set the double knock time duration	✓	✓	✓	✓	✓
3. NO MOVE ARM	4	0	0	2	Set time for arming on no movement	✗	✗	✗	✓	✓
4. POSTPONE DELAY TIME	4	0	0	3	Set a postpone delay time for arming on schedule	✗	✗	✗	✓	✓
5. AREAS										
XX. AREA	4	X	X	Y	XX – AREA Number; Y - Option	✓	✓	✓	✓	✓
01. Exit Time	4	X	X	0	Set the exit time for the area	✓	✓	✓	✓	✓
02. Entry Time	4	X	X	1	Set the Entry Time 1 and Entry Time 2	✓	✓	✓	✓	✓
03. Alarm Cycle	4	X	X	2	Set the duration of the alarm cycle	✓	✓	✓	✓	✓
04. Account	4	X	X	3	Set the account number for the area	✓	✓	✓	✓	✓
05. Bell Options	4	X	X	4	Set the options for the alarm siren (bell)	✓	✓	✓	✓	✓
06. On/Off Options	4	X	X	5	Set the options for ARM and DISARM	✓	✓	✓	✓	✓
07. Panics	4	X	X	6	Set the panic types	✓	✓	✓	✓	✓
08. Name	4	X	X	7	Entering of unique name for the area	✗	✓	✓	✓	✓
09. Bell Delay	4	X	X	8	Set a delay time for the alarm siren (bell)	✗	✗	✗	✓	✓
10. Timeslot	4	X	X	9	Set a number of a timeslot for operation	✗	✗	✗	✓	✓

<b>ACCOUNT LENGTH</b>	TEXT MENU	6. PARTITIONS – 1. ACCOUNT LENGTH
	ADDRESS	4000
	OPERATION	400

### Setting the area account number digit length

An account number digit length is assigned in this menu. The digit length can be 4 or 6-digit. Every pressing of a random button or arrows changes alternatively the parameter.

**At this address you set the parameter as:**

4 digits	The area account number is 4-digit.
6 digits	The area account number is 6-digit.



*When switching from 4- to 6-digits account numbers, the digits 00 will automatically be added at the end. For example, the 4-digits number 1234 will become 123400.*



***When changing over from 6- to 4-digits numbers, only the first four figures in the 4-digits number will remain valid. For example, the 6-digits number 123456 will become 1234. Due to risk of coincidence of account numbers, changing over from 6- to 4-digits numbers IS NOT RECOMMENDED!***

**Default setting: 4 digits**

<b>DOUBLE KNOCK</b>	TEXT MENU	6. PARTITIONS – 2. DOUBLE KNOCK
	ADDRESS	4001
	OPERATION	401

**Setting the “Double knock” delay time for zones**

The engineer assigns a time interval from 1 to 5-minute in this menu. The time interval starts running when a detector in the zone (attached to the same area) is activated for the first time when the system is armed. An alarm event is registered if second detector activation is recorded within this interval in the same or another zone.  
An alarm event will also be registered if no zone is restored within 15 seconds of the first activation of the zone.



**Does not apply for BRAVO PIR wireless motion detector.**

**Default setting: 3 minutes**

<b>ARM ON NO MOVE</b>	TEXT MENU	6. PARTITIONS – 3. NO MOV ALARM
	ADDRESS	4002
	OPERATION	402

**ECLIPSE 32**

**Setting a time for automatic arming of the area on no moving activity in the zones**

**ECLIPSE 99**

The Engineer sets a time for automatic arming of the area when there is no moving activity in all associated to that area zones. The time is common for all areas in the system. The automated arming is enabled on the respective area in menu “6. PARTITIONS – 5. AREAS – XX. AREA – 06. ON/OFF OPTIONS” (address 4xx5), option 5, where “xx” is the area number from 01 to 08 (Eclipse 32) or from 01 to 16 (Eclipse 99).  
Enter a time from 001 to 255 minutes. The set 000 value disables the automatic arming of the area.



*Pay attention that the automatic arming will start if there is a set time at the address and after closing (ready for arming) of all zones in the respective area. Check also the set options described in menu “6. PARTITIONS – 5. AREAS – XX. AREA – 06. ON/OFF OPTIONS” (address 4xx5) (option 5 is enabled) for the respective area.*

**Default setting: [000]**

<b>POSTPONE TIME</b>	TEXT MENU	6. PARTITIONS – 4. POSTPONE DELAY TIME
	ADDRESS	4003
	OPERATION	403

**ECLIPSE 32**

**Setting a delay time for starting the automatic arming (Postpone) from Manager**

**ECLIPSE 99**

Enter a time from 001 to 255 minutes.  
The Engineer sets a time for delay of the automatic arming on timeslot from Manager. The automatic arming will start after a default set postpone time of 10 minutes. During of a running automatic arming procedure on set timeslot, (menu “6. PARTITIONS – 5. AREAS – XX. AREA – 10. TIMESLOT” or address 4xx9, where “xx” is an area number) entering of Manager code will delay the arming with the time programmed at this address.



*If at the time of arming, the area is not ready to be armed, the automatic arming procedure will be delayed until the area is ready to be armed, and will be armed in the next 1 minute. The Postpone time cannot be disabled or changed! It is constantly set to be 10 minutes.*

**Default setting: [010]**

The following menus are described for AREA 01. The programming of AREA 02-16 is similar, as the maximal number of AREAS depends on the type of Eclipse panel.

<b>AREA 1 EXIT TIME</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 01. EXIT TIME
	ADDRESS	4010
	OPERATION	410 + 01

**Setting of exit time for Area 1**

Exit time is assigned to Entry/Exit type zones associated to Area 1. A 3-digit number between 000 and 255 seconds is entered. For an interval of time, less than 10 seconds, the first two digits must be 0.



*In case of command for arming of two or more areas, with a common Entry/Exit type zone then every area will be armed only when its own set exit time is over. The common zone will be bypassed in the already armed areas until and the last one area is armed. For example, the Zone 01 is associated to all areas in Eclipse 32 alarm panel, and when the seven of them are armed the Zone 01 will be bypassed until and the last area 8 is armed too.*

**Default setting: 045 seconds**

<b>AREA 1 ENTRY TIME</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 02. ENTRY TIME
	ADDRESS	4011
	OPERATION	411 + 01

**Setting of entry time for Area 1**

Entry time 1 (E1) is assigned to Entry/Exit type zones, and Entry time 2 (E2) is assigned to Entry/Exit 2 type zones associated to Area 1. A 3-digit number between 000 and 255 seconds is entered. For an interval of time, less than 10 seconds, the first two digits must be 0.



*When during running of entry time, after opening of Entry/Exit type zone associated to more than one area in the system, a valid user code associated to at least one of those areas is entered following the area number for disarming, then this area will be disarmed and the other areas (which numbers are not entered for disarming) will stay armed. The common Entry/Exit type zone will be bypassed in the left armed areas.*  
*When one of the armed areas is in alarm mode and a valid code associated to other area is entered (but both areas have a common zone) the siren stops (if it is associated to the same area) and the alarm cycle continues as set. Then an alarm message is sent to the monitoring station, and the event is recorded in the LOG file. An alarm event is generated when the entry time is over regardless that the violated zone is restored or not.*



**ECLIPSE 8+/32/99:** *According the requirements of EN50131 the entry time interval is limited from 00 to 45 seconds when in menu 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled. If in this menu is set a bigger time interval (for E1/E2), for example 50 seconds, it will be automatically reduced to 45 seconds; if the set time interval is smaller than 45 seconds it will not be changed.*

**Default setting: E1[015], E2 [015]**

<b>AREA 1 ALARM CYCLE</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 03. ALARM CYCLE
	ADDRESS	4012
	OPERATION	412 + 01

**Setting of alarm cycle (bell time) for Area 1**

Duration of the alarm cycle is set for the programmable siren type outputs associated to Area 1.

A 3-digit number between 000 and 255 minutes is assigned at the address. For an interval of time, less than 10 minutes, the first two digits must be 0.

Entering of valid user code ends the alarm cycle and restores the siren type outputs.

**Default setting: 001 minute**

<b>AREA 1 ACCOUNT</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 04. ACCOUNT
	ADDRESS	4013
	OPERATION	413 + 01

**Programming of account number for communication with monitoring station for Area 1**

The engineer enters 4 or 6-digit symbols according to the settings in menu “6. PARTITIONS – 1. ACCOUNT LENGTH”. The valid symbols include digits from 0 to 9 and letters from A to E. Entering of letter “F” in the code combination means cancelation of the communication. For letters entry the engineer uses the following button combinations:

Letter	Button combination	Letter	Button combination
A	+ 0	D	+ 3
B	+ 1	E	+ 4
C	+ 2	F	+ 5

**Default setting: 4 symbols (FFFF)**

<b>AREA 1 BELL OPTIONS</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 05. BELL OPTIONS
	ADDRESS	4014
	OPERATION	414 + 01

**Programming of Bell attributes for Area 1**

The Bell attributes for Area 1 are programmed in this menu. To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute.

At end of the procedure, at the keyboard’s display must be active only the numbers of the assigned attributes. In text menus the options are enabled with button 1, and are disabled with button 0.

More than one attribute can be assigned at this address.



*Pay attention that for attribute “5. Fire alarm duration” both of the attribute statuses are used – see the description of the attribute in the table below. The attribute numbers 3 and 4 are available only for ECLIPSE 32/99 control panel.*

**In this menu you set the following attributes:**

1	ARM Squawk	Sound signalization in arming. When the option is enabled, the siren will activate singly for 1 second when arming the Area 1. <b>Indication in text menus:</b> Disabled - “ ARM SQUAWK” Enabled - “✓ARM SQUAWK”	<b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 1 <b>LED:</b> Disabled - ①; Enabled - ①
2	DISARM Squawk	Sound signalization in disarming. When the option is enabled the siren will activate twice for 1 second when disarming the Area 1. <b>Indication in text menus:</b> Disabled - “ DISARM SQUAWK” Enabled - “✓DISARM SQUAWK”	<b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 2 <b>LED:</b> Disabled - ②; Enabled - ②
3	Alarm Memory Squawk	Sound signalization for memory log record. When this option is enabled the siren will activate 4 times for 1 second in disarming the Area 1 if there was an alarm event in the Area. <b>Indication in text menus:</b> Disabled - “ AlarmMem SQUAWK” Enabled - “✓AlarmMem SQUAWK”	<b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 3 <b>LED:</b> Disabled - ③; Enabled - ③
4	10 minutes Warning	10 minutes warning signal before automatic arming on timeslot. When this option is enabled the siren will activate 3 times for 1 second 10 minutes before the start of automatic arming on timeslot. <b>Indication in text menus:</b> Disabled - “ 10 MIN WARNING” Enabled - “✓10 MIN WARNING”	<b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 4 <b>LED:</b> Disabled - ④; Enabled - ④

ECLIPSE 32

ECLIPSE 99



5	Fire Alarm Duration	<p>FIRE Alarm duration. This attribute is applicable for Fire type zones or sending of Fire alarm via keyboard button's combination. Programming this attribute affects the performance of the programmable SIREN output. When this option is enabled, the FIRE Alarm signalization will be active until a valid user or manager code is entered. If this option is disabled, the Fire Alarm signalization will be active until the Bell time for the alarm cycle set in menu "6. PARTITIONS – 5. AREAS – 1. AREA – 03. ALARM CYCLE" ends.</p> <p><b>Indication in text menus:</b>                  Disabled - " FIRE ALARM DUR."                  Enabled - "✓FIRE ALARM DUR."</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 5                  LED: Disabled - ⑤; Enabled - ⑥</p>
---	---------------------	--

**Default setting: 5. Fire Alarm Duration**

<b>AREA 1 ON/OFF OPTIONS</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 06. ON/OFF OPTIONS
	ADDRESS	4015
	OPERATION	415 + 01

**Programming of ON/OFF attributes for Area 1**

The ON/OFF (ARM/DISARM) attributes for Area 1 are programmed in this menu. To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute.

At end of the procedure, at the keyboard's display must be active only the numbers of the assigned attributes. In text menus the options are enabled with button 1, and are disabled with button 0.

More than one attribute can be assigned at this address.



Pay attention that both of the attribute statuses are used – see their description in the table below. The attribute numbers 1, 2 and 5 are available only for ECLIPSE 32/99 control panel.

**In this menu you set the following options:**

ECLIPSE 32  
ECLIPSE 99

1	Auto disarming on Timeslot	<p>Automatic disarming on set timeslot number. When this option is enabled Area 1 is disarmed according the set timeslot number in menu "6. PARTITIONS – 5. AREAS – 1. AREA – 10. TIMESLOT" (address 4019).</p> <p><b>Indication in text menus:</b>                  Disabled - " TIMESLOT DISARM"                  Enabled - "✓TIMESLOT DISARM"</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 1                  LED: Disabled - ①; Enabled - ①</p>
2	Auto ARM type – Full, Stay	<p>Setting the arming type on timeslot – Full or Stay ARM.</p> <p><b>Indication in text menus:</b>                  FULL - " AUTO ARM F/S"                  STAY - "✓AUTO ARM F/S"</p> <p><b>Indication in address menus:</b>                  LCD: FULL - *; STAY - 2                  LED: FULL - ②; STAY - ②</p>
3	Clear Bypass on Disarm	<p>Clear the bypassed zones on disarm. When this option is enabled the bypassed zones are cleared on disarm.</p> <p><b>Indication in text menus:</b>                  Disabled - " DISARM CLR BPS"                  Enabled - "✓DISARM CLR BPS"</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 3                  LED: Disabled - ③; Enabled - ③</p>
4	Quick ARM*	<p>Quick arming with one button. When this option is enabled the system can be armed without entering a used code. To arm an area the user has to hold the arming button for 2-3 seconds.</p> <p><b>Indication in text menus:</b>                  Disabled - " QUICK ARM"                  Enabled - "✓QUICK ARM"</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 4                  LED: Disabled - ④; Enabled - ④</p>



\* **ECLIPSE 8+/32/99:** According the requirements of EN50131 this option is disabled and cannot be changed when in menu 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled.



ECLIPSE 32  
ECLIPSE 99

5	Auto ARM on no movement	<p>Automatic arming when there is no movement in the zones associated to Area 1. When this option is enabled the Area 1 will be automatically armed after ending the time set at in menu “6. PARTITIONS – 3. NO MOV ALARM” (address 4002) when there is no movement in the zones associated to the Area 1.</p> <p><b>Indication in text menus:</b>                  Disabled - “ ARM ON NO MOVE”                  Enabled - “✓ARM ON NO MOVE”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 5                  LED: Disabled - ⑤; Enabled - ⑥</p>
---	-------------------------	--

Default setting: 4. Quick ARM

**AREA 1  
PANICS**

TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 07. PANICS
ADDRESS	4016
OPERATION	416 + 01

**Setting of Panic types for Area 1**

The setting for panic events concerns only the alarm signals sent via the keyboard quick panic buttons. The keyboard must be associated to Area 1 for sending the panic alarm messages. The quick button combinations for panics are: 1+3 for police alarm, 4+6 for medical alarm, and 7+9 for fire alarm. To send an alarm signal just press and hold together a button combination for at least 2-3 seconds. More than one panic can be assigned at this address.

To select an option, press the digit button corresponding to its number. The next pressing of the same button will deselect the attribute.

At end of the procedure, at the keyboard’s display must be active only the numbers of the assigned attributes. In text menus the options are enabled with button 1, and are disabled with button 0.



**Silent panic** (panics “2. Silent Police” and “4. Silent Medical” are set at this menu) – only the programmable Panic types outputs and the digital communicator are activated. There is no indication for a memory event. After entering of valid user code, the MEMORY LED lights on.

**Audible panic** (panics “1. Police”, “3. Medical” and “5. Fire” are set at this menu) – the programmable Siren and Panic outputs and the digital communicator are activated. The sirens are activated immediately with no time delay.

**In this menu you set the following options:**

1	Police	<p>Enabling of sending Police panic alarm. When this option is enabled the user can send Police panic alarm message with pressing and holding the keyboard buttons 1+3 for 2-3 seconds.</p> <p><b>Indication in text menus:</b>                  Disabled - “ POLICE”                  Enabled - “✓POLICE”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 1                  LED: Disabled - ①; Enabled - ①</p>
2	Silent Police	<p><b>This attribute will be active only when the attribute 1 is enabled!</b>                  When this option is enabled the Police panic will be silent only.</p> <p><b>Indication in text menus:</b>                  AUDIBLE - “ SILENT POLICE”                  SILENT - “✓SILENT POLICE”</p> <p><b>Indication in address menus:</b>                  LCD: AUDIBLE - *; SILENT - 2                  LED: AUDIBLE - ②; SILENT - ②</p>
3	Medical	<p>Enabling of sending Medical panic alarm. When this option is enabled the user can send Medical panic alarm message with pressing and holding the keyboard buttons 4+6 for 2-3 seconds.</p> <p><b>Indication in text menus:</b>                  Disabled - “ MEDICAL”                  Enabled - “✓MEDICAL”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 3                  LED: Disabled - ③; Enabled - ③</p>
4	Silent Medical	<p><b>This attribute will be active only when the attribute 3 is enabled!</b>                  When this option is enabled the Medical panic will be silent only.</p> <p><b>Indication in text menus:</b>                  AUDIBLE - “ SILENT MEDICAL”                  SILENT - “✓SILENT MEDICAL”</p> <p><b>Indication in address menus:</b>                  LCD: AUDIBLE - *; SILENT - 4                  LED: AUDIBLE - ④; SILENT - ④</p>



5	Fire	<p>Enabling of sending Fire panic alarm. When this option is enabled the user can send Fire panic alarm message with pressing and holding the keyboard buttons 7+9 for 2-3 seconds.</p> <p><b>Indication in text menus:</b>                  Disabled - " FIRE"                  Enabled - "✓FIRE"</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 5                  LED: Disabled - Ⓢ; Enabled - Ⓢ</p>
---	------	---

**Default setting: All disabled**



The following special cases are possible when a keyboard is used for sending of panic alarms:

1. In case of several panics are sent at the same time just the last one will be displayed.
2. When there are 3 keyboards in the system and the configuration is: the 1<sup>st</sup> keyboard is associated to Area 1, the 2<sup>nd</sup> keyboard is associated to Area 2, and the 3<sup>rd</sup> keyboard is associated to both Areas 1 and 2, then in case of panics sent the keyboards 1 and 2 will display the panics only in their own areas, and the 3<sup>rd</sup> keyboard will display the both panics. In case the panic is sent from the 3<sup>rd</sup> keyboard then the other two keyboards will display the panic alarm.

<b>AREA 1 NAME</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 08. NAME
	ADDRESS	4017
	OPERATION	417 + 01

- ECLIPSE 8+**
- ECLIPSE 16**
- ECLIPSE 32**
- ECLIPSE 99**
- LCD**

**Programming of the Area 1 Name**

The engineer can enter a new name for Area 1 in this menu. The name has to be up 16 symbols – letters (small and capital), digits and special symbols, including spaces.

The letters can be entered directly by the digit buttons. The cursor moves automatically to the right after choosing of letter or digit, or may be moved manually by the arrows. To enter a digit, press the respective button and hold it for 2-3 seconds. See also item 2.8. Entering text for LCD Keyboard.

Confirm the new area name with ENTER button.

**Default setting: AREA 1**

<b>AREA 1 BELL DELAY</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 09. BELL DELAY
	ADDRESS	4018
	OPERATION	418 + 01

- ECLIPSE 32**
- ECLIPSE 99**

**Programming of bell delay for Area 1**

The engineer assigns at the address a bell delay for activation of the programmable Siren type outputs after a burglary alarm event is registered in any arming mode.

The set time delay of this address is considered when the activated zone is not a Fire type and the option "Bell delay" is enabled in Zone Options 2 in menu "4. INPUTS – 5. ZONES – XX. ZONE – 5. OPTIONS 2" (address 2xx5), where "xx" is a zone number.

The bell delay time is set in interval from 000 to 255 seconds.

**Default setting: 000 seconds**

<b>AREA 1 TIMESLOT</b>	TEXT MENU	6. PARTITIONS – 5. AREAS – 1. AREA – 10. TIMESLOT
	ADDRESS	4019
	OPERATION	419 + 01

- ECLIPSE 32**
- ECLIPSE 99**

**Programming of timeslot for Area 1**

The supported timeslots are: Eclipse 32 - from 1 to 8; Eclipse 99 - from 1 to 16.

If the operation of the Area is not to be restricted by a timeslot, enter 0.

Use the digit buttons to enter the timeslot number. The entered number is confirmed with ENTER. For programming of timeslots, see for details Menu. 7 Schedules.



*Pay attention that when you set timeslot number at this address, the Area arming is automatic for the timeslot duration. If at the timeslot start time, there are open zones in the area the control panel will wait for zones' restoration (to be ready for arming) and after that will perform automated arming on the set timeslot.*

**Default setting: [0] - Eclipse 32 / [00] - Eclipse 99**

## 7. SCHEDULES

The “7. SCHEDULES” menu is available only for ECLIPSE 32 and ECLIPSE 99 control panels.

The term Timeslot is used to represent a set of functions related to time intervals. A timeslot is used to automate operations fixed in time, which are periodically repeated by the security system. Such operations can be: managing programmable input (e.g. managing door access); turning on lights; automatic arming or disarming security; restricting user code access; automatic setting up of temporary passage routes in secured site.

ECLIPSE 32/99 can organize timeslots to help solve tasks related to automation of periodically recurring operations. 8/16 timeslots can be organized according the system configuration. The engineer sets start and end time of the timeslot, days and holidays included, etc. The programming of holidays and nonworking days is organized at additional menus.

Quick table for 7. Schedules Menu

Text Menu	Address				Description	ECLIPSE		
						8/8+/16	32	99
1. Timeslots								
XX. Timeslot	5	X	X	Y	XX – Timeslot Number; Y - Option	x	✓	✓
1. Start	5	X	X	0	Set the start time for operation of the timeslot		✓	✓
2. End	5	X	X	1	Set the end time for operation of the timeslot		✓	✓
3. Week Days	5	X	X	2	Set the week days for operation of the timeslot		✓	✓
4. Options	5	X	X	3	Set the options for holidays		✓	✓
2. Calendar								
01. January	5	4	1	x*	Set the operation days in January	x	✓	✓
02. February	5	4	2	x*	Set the operation days in February		✓	✓
03. March	5	4	3	x*	Set the operation days in March		✓	✓
04. April	5	4	4	x*	Set the operation days in April		✓	✓
05. May	5	4	5	x*	Set the operation days in May		✓	✓
06. June	5	4	6	x*	Set the operation days in June		✓	✓
07. July	5	4	7	x*	Set the operation days in July		✓	✓
08. August	5	4	8	x*	Set the operation days in August		✓	✓
09. September	5	4	9	x*	Set the operation days in September		✓	✓
10. October	5	5	0	x*	Set the operation days in October		✓	✓
11. November	5	5	1	x*	Set the operation days in November		✓	✓
12. December	5	5	2	x*	Set the operation days in December		✓	✓

\* In address menus, the days in one month are set at four different addresses  $x = 1-4$ . For example, at address 5411 ( $x=1$ ) the installer sets the first 8 days (January 1<sup>st</sup> - 8<sup>th</sup>), at 5412 ( $x=2$ ) – next 8 days (January 9<sup>th</sup> - 16<sup>th</sup>) and so on. Generally, you can follow the table to review the exact address for every month:

5	X	X	1	1 – 8 dates
5	X	X	2	9 – 16 dates
5	X	X	3	17 – 24 dates
5	X	X	4	25 – 31 dates

The following menus are described for TIMESLOT 01. The programming of TIMESLOTS 02-16 is similar, as the maximal number of TIMESLOTS depends on the type of Eclipse panel.

<b>TIMESLOT 1 START</b>	TEXT MENU	7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 1. START
	ADDRESS	5010
	OPERATION	510 + 01

**ECLIPSE 32**

**Start time for arming on Timeslot 1**

**ECLIPSE 99**

The start time of Timeslot 1 is set in this menu. The start time must be less than the stop time set in menu “7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 2.END” (address 5011). The engineer sets the start time in format [HH:MM].



*The real arming on timeslot is realized with a delay (postpone time) of minimum 10 minutes\* after the set start time. For example, if the set start time is 08:30h, at this time a sound signal will announce the running of 10 minutes\* time interval for leaving of protected premises from users, and the real arming of the area or areas will be at 08.40h.*



**\* ATTENTION:** The postpone time is set in menu “6. PARTITIONS – 4. POSTPONE TIME” and can be set in interval 010 – 255 minutes. The postpone time cannot be disabled!

**Default setting: [00:00]**

<b>TIMESLOT 1 END</b>	TEXT MENU	7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 2.END
	ADDRESS	5011
	OPERATION	511 + 01

**ECLIPSE 32**

**End time for disarming on Timeslot 1**

**ECLIPSE 99**

The stop time of Timeslot 1 is set in this menu. The stop time must be greater than the start time set in menu “7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 1. START” (address 5010). The engineer sets the stop time in format [HH:MM].



*If to a user code has been set a timeslot from 8:30h to 17:00h, the respective user can use his code within that specified time. From 17:00h to 0:00h and from 0:00h to 8:30h the respective code will remain inactive.*

**Default setting: [23:59]**

<b>TIMESLOT 1 DAYS</b>	TEXT MENU	7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 3.WEEK DAYS
	ADDRESS	5012
	OPERATION	512 + 01

**ECLIPSE 32**

**Setting of week days for operation on Timeslot 1**

**ECLIPSE 99**

Available days of the week for Timeslot 1 are set in this menu.

In text menus the week days are enabled with button 1, and are disabled with button 0. In address menus the week days are selected using the digits buttons from 1 to 7. The selected days are presented with a digit on the display or lighting on LED number – see the table below for correspondence:

Button	Week day
1	Monday
2	Tuesday
3	Wednesday
4	Thursday
5	Friday
6	Saturday
7	Sunday



*For example, if only Wednesday is set for Timeslot 1, the user code will be valid only on Wednesday days from 8:30 to 17:00h.*

**Default setting: all week days**

**TIMESLOT 1  
OPTIONS**

TEXT MENU	7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 4.OPTIONS
ADDRESS	5013
OPERATION	513 + 01

**ECLIPSE 32**

**Setting of options for Timeslot 1**

**ECLIPSE 99**

The following options can be set in this menu:


1	Holidays	<p><b>Setting of holidays in timeslot duration.</b> When this option is enabled for Timeslot 1, the system will also note the settings in the menus for setting the active days in a month, where the engineer sets the holidays and officially nonworking days for every month in the year.</p> <p><b>Indication in text menus:</b>                  Disabled - " HOLIDAYS"                  Enabled - "✓HOLIDAYS"</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 1                  LED: Disabled - ①; Enabled - ①</p>
2	Invert	<p>Setting of normal or Inverted operation of the timeslot.</p> <ul style="list-style-type: none"> <li>• <b>Normal operation.</b> The timeslot will start according the set start time and ends according the set end time.</li> <li>• <b>Inverted operation.</b> The timeslot will start according the set end time in menu "7. SCHEDULES – 1. TIMESLOTS – 1. TIMESLOT – 2.END" (address 5011) and ends according the set start time.</li> </ul> <p><b>Indication in text menus:</b>                  Normal - " INVERT"                  Inverted - "✓INVERT"</p> <p><b>Indication in address menus:</b>                  LCD: NORMAL - *; INVERT - 2                  LED: NORMAL - ②; INVERT - ②</p>




**Example:**

Set start time 08.00h, and end time 17.00h.

**When a Normal operation of the timeslot is set, the arming diagram is as follows:**



**When an Inverted operation of the timeslot is set, the arming diagram is as follows:**



With the hatched area is shown the postpone time (10 minutes) and the set delay\* for leaving the protected area or areas before arming the system on timeslot.

\* **ATTENTION:** The postpone delay time is set in menu "6. PARTITIONS – 4. POSTPONE DELAY TIME" and can be set in interval 001 – 255 minutes. The delay time is added to the postpone time if a manager's code is entered during running of an automatic starting of the system on timeslot.

**Default setting: Holidays are disabled; Normal operation**

The settings of holidays and officially nonworking days are programmed in menu 2. CALENDAR as for every of the months is provided separate menus. The holidays and nonworking days are common for all Timeslot numbers. All months are programmed analogically – see the quick reference table at the beginning of this section.

<b>MONTH JANUARY</b>	TEXT MENU	7. SCHEDULES – 2. CALENDAR – 01. JANUARY
	ADDRESS	5411; 5412; 5413; 5414
	OPERATION	541 + 01; 542 + 01; 543 + 01; 544 + 01

**ECLIPSE 32**

**Setting of holidays and nonworking days for January**

**ECLIPSE 99**

In text menus the holidays and the non-working week days are enabled with button 1, and are disabled with button 0.

In the address and operation menu the holidays and non-working week days are set at different addresses – four for every of the months. Below are presented examples for settings for January and they are common for all other months.

The address 5411 presents 8 different fields for the first eight days of January. Every field is editable when the cursor is under it. The cursor can be moved with the arrows. In the square parentheses on the right side of the screen, the engineer can see the editable date. To set a date as holiday move the cursor under it and press button “0”. The selected holidays for the month are presented with “H” capital letter. Pressing the button “0” once again will return the previous status.




**Indication:**

**LCD:** The workdays are displayed with “-” symbol. The holidays are displayed with “H” symbol.  
**LED:** The zone numbers corresponding to the days set for holidays are lighting on.



*Programming holiday with address and operational menus for January:*



**Default setting: none**

## 8. COMMUNICATION

The menus for communication devices programming are accessible only from the Engineer of the system (engineer code 7777 by default).



**ATTENTION:** Due to differences in PSTNs provided in different countries and territories, Teletek Electronics JSC cannot provide unconditional assurance of successful operations on every PSTN network termination point. This may be subject to changes made to the communication facilities or procedures of each individual telephone service provider. Additionally, Teletek Electronics JSC alarm equipment is designed to work with traditional telephone line. Please, bear in mind that the use of alarm panels over alternative telephone systems like VoIP (Voice over Internet Protocol) may not be as effective as with traditional telephone line.

If you are experiencing problems with the use of a Teletek Electronics JSC device over PSTN, please contact us for further assistance.

ECLIPSE Control Panels Series – dialler capability:

Control panel	Digital Communicator	Protocols	Voice Dialler
ECLIPSE 8	2 Tel. numbers	SIA, CID	8 Tel. numbers
ECLIPSE 8+	2 Tel. numbers	SIA, CID	8 Tel. numbers
ECLIPSE 16	2 Tel. numbers	SIA, CID	8 Tel. numbers
ECLIPSE 32	4 Tel. numbers	SIA, CID	8 Tel. numbers
ECLIPSE 99	4 Tel. numbers	SIA, CID	8 Tel. numbers

Quick table for 8. Communication Programming Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
1. Digital Communication										
1. Options	6	0	0	0	Set options of digital communicator	✓	✓	✓	✓	✓
2. Attempts	6	0	0	1	Set the number of attempts	✓	✓	✓	✓	✓
3. Test Messages										
1. Time	6	0	0	3	Set the test message hour	✓	✓	✓	✓	✓
2. Period	6	0	0	2	Set the test message period duration	✓	✓	✓	✓	✓
4. Fault Delay	6	0	0	4	Set a time delay for line fault	✓	✓	✓	✓	✓
5. Phones										
X. Phone	6	0	X	Y	X – Phone Number; Y - Option	✓	✓	✓	✓	✓
1. Phone Number	6	0	X	0	Enter the telephone number	✓	✓	✓	✓	✓
2. Protocol	6	0	X	1	Set the communication protocol	✓	✓	✓	✓	✓
3. Messages Type	6	0	X	2	Set the message type	✓	✓	✓	✓	✓
4. Areas	6	0	X	3	Attaching phone to area numbers	*	✓	✓	✓	✓
6. UDL										
2. PC ID	6	9	0	1	Set an ID number for communication	✓	✓	✓	✓	✓
5. Options	6	9	0	4	Set the UDL Options	*	✓	✓	✓	✓
6. Rings	6	9	0	5	Set a number of rings	✓	✓	✓	✓	✓
2. Voice Dialler										
1. VD Options	6	1	0	0	Set the Voice Dialler operation options	✓	✓	✓	✓	✓
2. VD Msg Repetition	6	1	0	1	Set the number of message repetitions	✓	✓	✓	✓	✓
4. VD Language	6	1	0	3	Set the language of voice messages	✓	✓	✓	✓	✓
5. VD Phones										
X. Phone	6	1	X	Y	X – Phone Number; Y - Option	✓	✓	✓	✓	✓
1. Phone Number	6	1	X	0	Enter the telephone number	✓	✓	✓	✓	✓
3. Messages Type	6	1	X	1	Set the message type	✓	✓	✓	✓	✓
4. Areas	6	1	X	2	Attaching phone to area numbers	*	✓	✓	✓	✓

<b>PSTN OPTIONS</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 1. OPTIONS
	ADDRESS	6000
	OPERATION	600

**Setting of PSTN options (built-in digital communicator)**

The options are common for programmed telephone numbers.

Use the digit buttons to set the option numbers. Every pressing of the button changes alternatively the option status.

In text menus the options are enabled with button 1, and are disabled with button 0.



Pay attention that for some options both of the statuses are used – see the description of the options in the table below. The option number 3 is not available for ECLIPSE 8 control panel.

**In this menu you can set the following options:**

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

1	Enable Dialler	Using of the built-in digital communicator (PSTN). <b>Indication in text menus:</b> Disabled - " ENABLE DIALER" Enabled - "✓ENABLE DIALER" <b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 1 <b>LED:</b> Disabled - ①; Enabled - ①
2	TLM Enable	Enabling of Telephone Line Monitoring (TLM). When this option is enabled, in case of telephone line fault the trouble message "4. Comm. TRBL" is generated. <b>Indication in text menus:</b> Disabled - " TLM ENABLE" Enabled - "✓TLM ENABLE" <b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 2 <b>LED:</b> Disabled - ②; Enabled - ②
3	TLM ALARM	Generating of alarm event in case of telephone line failure. When this option is enabled, in case of telephone line failure when the system is armed an alarm message is generated. (The alarm message is not generated if the telephone line failure occurs when the system is disarmed and then armed with a present telephone line failure.) <b>Indication in text menus:</b> Disabled - " TLM ALARM" Enabled - "✓TLM ALARM" <b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 3 <b>LED:</b> Disabled - ③; Enabled - ③
4	Pulse Dial	Set the type of dialling – TONE or PULSE. <b>Indication in text menus:</b> TONE Dial - " PULSE DIAL" PULSE Dial - "✓PULSE DIAL" <b>Indication in address menus:</b> <b>LCD:</b> TONE Dial - *; PULSE Dial - 4 <b>LED:</b> TONE Dial - ④; PULSE Dial - ④
5	Blind Dial ("Wait dial tone" signal check)	When this option is enabled, the "Wait dial tone" signal check is disabled. <b>Indication in text menus:</b> Signal Check - " BLIND DIAL" No Check - "✓BLIND DIAL" <b>Indication in address menus:</b> <b>LCD:</b> Signal Check - *; Blind Dial - 5 <b>LED:</b> Signal Check - ⑤; Blind Dial - ⑤
6	Alternative	Option for setting the algorithm of sending alarm messages.  <b>When this option is disabled</b> , the messages are sent to <b>all set telephone numbers</b> , starting with the first recorded one.  <b>When this option is enabled</b> , if the messages are successfully sent to the first recorded phone number, the rest of the phone numbers are not dialled. If the message transmission to the first phone number is failed, the system will try to dial the next recorded phone number and so on until a successful message transmission is achieved.  <b>Note:</b> If the alarm events are assigned to different telephone numbers, the setting of this option does not matter. In that case independent message report to different telephone numbers is realized - "SPLIT Report". <b>Indication in text menus:</b> Disabled - " ALTERNATIVE" Enabled - "✓ALTERNATIVE" <b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 6 <b>LED:</b> Disabled - ⑥; Enabled - ⑥



7	PSTN/AJAX REPORT CHANNELS	<p><b>Channels for sending messages</b></p> <ul style="list-style-type: none"> <li>In <u>text menus</u>, the options are selected with pressing button “1” and are deselected with button “0”. The operation via the report channels is programmed with the following options:                     <ul style="list-style-type: none"> <li>PSTN REP. MAIN – The PSTN line is the main channel and GPRS/LAN* is the backup channel.</li> <li>AJAX REP. MAIN - The GPRS/LAN* is the main channel and PSTN line is the backup channel.</li> </ul> </li> </ul> <p>If both options are deselected, the communication via PSTN and GPRS/LAN* channels is disabled. If both options are selected, the communication is via both of them and the messages are sent through every one of the channels.</p> <ul style="list-style-type: none"> <li>In <u>address menus</u>, the options 7 and 8 are set in combination to define the used report channel:</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 10%;">7</th> <th style="width: 10%;">8</th> <th style="width: 80%;">Channel</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">*</td> <td style="text-align: center;">*</td> <td>No communication through GPRS/LAN* and PSTN channels</td> </tr> <tr> <td style="text-align: center;">*</td> <td style="text-align: center;">8</td> <td>GPRS/LAN* is the main channel, and PSTN is backup channel</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">*</td> <td>PSTN is the main channel, and GPRS/LAN* is backup channel</td> </tr> <tr> <td style="text-align: center;">7</td> <td style="text-align: center;">8</td> <td>Both channels are used</td> </tr> </tbody> </table> <p>* GPRS or LAN communication module with serial connection to Eclipse panel and registered to a user account at AJAX could server.</p>	7	8	Channel	*	*	No communication through GPRS/LAN* and PSTN channels	*	8	GPRS/LAN* is the main channel, and PSTN is backup channel	7	*	PSTN is the main channel, and GPRS/LAN* is backup channel	7	8	Both channels are used
7			8	Channel													
*	*	No communication through GPRS/LAN* and PSTN channels															
*	8	GPRS/LAN* is the main channel, and PSTN is backup channel															
7	*	PSTN is the main channel, and GPRS/LAN* is backup channel															
7	8	Both channels are used															
8																	

**Default setting: 1. PSTN Enabled, 5. Blind Dialling, 6. Alternative**

ATTEMPTS	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 2. ATTEMPTS
	ADDRESS	6001
	OPERATION	601



**Number of attempts for communication with monitoring station**

The Engineer sets the number of attempts to connect to the central station for telephone monitoring and the number of repetitions of voice messages in this menu. Use the digit numbers to enter a value from 1 to 9.

The value assigned in this menu is the number of attempts to be made for each of the telephones, configured for the digital communicator and the Voice Dialler (see the menus: “8.COMMUNICATION - 1.DIGITAL COMM - 5.PHONES - 1.PHONE - 1.PHONE NUMBER” and “8. Communication – 2. Voice Dialler – 5. VD Phones – 1. Phone – 1. Phone Number”).

*Example: If the assigned value is 4 and there are two telephone numbers set for the digital communicator, the number of attempts that will be made is 8 - by 4 attempts for each telephone number.*

After the assigned number of attempts for communication is reached, the attempts to transmit voice messages will be terminated. The attempts to transmit will be renewed to the central station first, when the next transmission event occurs.

**Default setting: 4 attempts**

TEST HOUR	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 3. TEST MESSAGES – 1. TIME
	ADDRESS	6003
	OPERATION	603

**Setting time for sending the test message (an hour to start)**

In this menu is set the first hour, at which the test message will start to be transmitted to central monitoring station. Hours and minutes are entered (HH:MM), as the entered time is the time of starting the first test.

The next test time will start after the assigned test period in menu “8. COMMUNICATION – 1. DIGITAL COMM – 3. TEST MESSAGES – 2. PERIOD” (address 6002).

**Default setting: [00:05]**

<b>TEST PERIOD</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 3. TEST MESSAGES – 2. PERIOD
	ADDRESS	6002
	OPERATION	602

**Test message period**

Duration of transmission of test message in hours (HHH) from 000 to 255 is entered. Three digits must be entered. When entering a period shorter than 10 hours the first two digits must be 0.

**Default setting: [024] hours**

<b>FAULT DELAY</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 4. FAULT DELAY
	ADDRESS	6004
	OPERATION	604

**Telephone Line Monitor (TLM) Fault Alarm activation delay**

A delay of 000 to 255 minutes is set prior to indication of a telephone line failure. Three digits must be entered. When entering a period is shorter than 10 minutes the first two digits must be 0.

**Default setting: [000] minutes**

The following menus are described for PNONE 1 of the digital communicator. The programming of PHONES 2-4 is similar, as the maximal number of PHONES depends on the type of Eclipse panel.

<b>PHONE NUMBER 1</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 5. PHONES – 1. PHONE – 1. PHONE NUMBER
	ADDRESS	6010
	OPERATION	610 +01

**Setting of Telephone 1 for the digital communicator**

A Telephone Number 1 is assigned for communicating with central station. The telephone number must not exceed 32 characters (*it is possible to enter up to 32 characters via ProsTE software and up to 16 characters via keyboard*). Some special functions can be entered by using the next button combinations:

1. Buttons + 0 - Switches on "pulse dialler". "P" letter is displayed on the screen.
2. Buttons + 1 - Switches on "tone dialler". "T" letter is displayed on the screen.
3. Buttons + 2 - 2 seconds pause. "D" letter is displayed on the screen.
4. Buttons + 3 - Switches on "Wait dial tone". "\*" symbol is displayed on the screen.
5. Buttons + 4 - "Blind dialling"; Switches off "Wait dial tone". "#" symbol is displayed on the screen.
6. Buttons + 5 - Deletes the entered telephone number.

**Default setting: none**

<b>PROTOCOL</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 5. PHONES – 1. PHONE – 2. PROTOCOL
	ADDRESS	6011
	OPERATION	611 + 01

**Setting the communication protocol for Telephone 1**

The engineer sets the communication protocol type for Telephone 1 in this menu. The supported communication protocols are CID and SIA. Every pressing of random key switches alternatively between the two protocols. Confirm your choice with ENTER button.

**LED**

In operation with Eclipse LED Keyboard the indication is different according used model:

<b>Eclipse LED32/ LED 16A VG</b>	<b>Eclipse LED16A/LED8 (Zone 1 is blinking)</b>
Enabled SIA: LEDs 1-8 are on Enabled CID: LEDs 1-8 are off	Enabled SIA: Buttons 0-9 are on Enabled CID: Buttons 0-9 are off

**Default setting: CID**

<b>MESSAGES TYPE</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM– 5. PHONES – 1. PHONE – 3. MESSAGES TYPE
	ADDRESS	6012
	OPERATION	612 + 01



**Setting of alarm messages for Telephone 1**

In this menu are assigned one or more type of the messages which will be transmitted to a central monitoring station in case of alarm condition through *Telephone Number 1 for the digital communicator*.

*To the Telephone Number 1 can be programmed to be transmitted only chosen messages. In case the user wants some messages to be transmitted and through Telephone Number 2 (3, 4 or all), then the same chosen messages have to be assigned and at the respective menu: "8.COMMUNICATION - 1.DIGITAL COMM - 5. PHONES – 2-4. PHONE - 3. MESSAGES TYPE". If it does not matter through which of the telephone numbers the messages are sent, you have to leave in menus the default programming (No messages are assigned).*

In text menus the available message types are selected with "1" button and are deselected with "0" button.

In address menus use the digit buttons 1 to 8 for programming. Pressing them each time will alternatively change the status of the respective message type - report (active status of the parameter) or no report (inactive status of the parameter). At the end of the procedure only those parameters, which correspond to the designated for report messages, should remain activated on the display.

**The following messages are assigned:**

1	ALARM& RESTORE	Message is sent in case of events: 1. ALARM	2. ALARM Restore
2	TAMPER& RESTORE	Message is sent in case of events: 1. TAMPER (from a zone; from a Tamper type zone; from a device connected to the system bus: keyboard, proxy reader, expander modules)	2. TAMPER Restore
3	PANIC& AMBUSH	Message is sent in case of events: 1. PANIC (from a zone; from a keyboard)	2. Entered AMBUSH CODE
4	FIRE ALARM	Message is sent in case of events: 1. FIRE (from a zone; from a keyboard)	2. FIRE Restore
5	ARM, DISARM, BYPASS	Message is sent in case of events: 1. ARMING 2. DISARMING	3. ZONE BYPASS
6	MEDICAL ALARM	Message is sent in case of events: 1. MEDICAL ALARM	2. MEDICAL ALARM Restore
7	TROUBLE& RESTORE	Message is sent in case of trouble/trouble restore events: 1. AC Lost/Failure 2. Battery Lost/Failure 3. Fuse Blown 4. Communication Lost 5. Error on the system bus	6. Invalid time and date 7. Problem with a wireless device 8. Radio Frequency jamming 9. Problem with the power supply of an expander module
8	SPECIAL	Message is sent in case of events: 1. Keyboard lockout 2. Engineer menu entry 3. Engineer menu exit 4. Download start 5. Download end 6. Periodic Test Report 7. Manual Test Report	8. Power Up 9. Reset 10. Time Changed 11. Absent (device) 12. Restored (device) 13. User Code Change

**Default setting: All messages enabled**

<b>AREAS</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 5. PHONES – 1. PHONE – 4. AREAS
	ADDRESS	6013
	OPERATION	613 + 01

ECLIPSE 8+

**Associating of areas to Telephone 1 of the digital communicator**

ECLIPSE 16

According the system configuration, the engineer associates one or several AREA numbers for operation with Telephone 1.

ECLIPSE 32

In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”.

ECLIPSE 99

In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.

The final configuration of enabled Area numbers is confirmed with ENTER button.



\* To associate/disassociate all areas at the same time press button “0”.

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.

**The Telephone 1 will be inactive if there are no associated areas to it!**

**Default setting: AREA 1**

The parameters for up/download programming of the integrated digital communicator are set in the following menus.

<b>PC ID</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 6. UDL – 2. PC ID
	ADDRESS	6901
	OPERATION	691

**Personal computer identification number for up/down loading.**

The PC ID number for up/down loading is configured at this address. Four digits can be introduced. Valid are symbols 0 to 9. The entered number is saved with pressing the ENTER button.



**Note:** The PC ID number must be the same with those set at the GPRS/LAN communication module connected to the panel! The PC ID number for the GPRS/LAN module is set via ProSTE software at “1.General Settings” Menu. The default set PC ID number for the GPRS/LAN module is also 1234.

**Default setting: 1234**

<b>OPTIONS</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 6. UDL – 5. OPTIONS
	ADDRESS	6904
	OPERATION	694

ECLIPSE 8+

**Options for remote control**

ECLIPSE 16

In text menus the available option is selected with “1” button and are deselected with “0” button.

ECLIPSE 32

In address menus are available options 2 and 3 for programming. The meaning of the options is described in details in the table below.

ECLIPSE 99

**The following options are assigned:**

2	ANS. MACHINE	Enabling of “Answering machine” option. <b>ANSWERING MACHINE Disable (*)</b> – The option is disabled. The connection between the control panel and the telephone line is direct. <b>ANSWERING MACHINE Enable (2)</b> – The option is enabled. Priority should be given to any automatic answering devices (like FAX or telephone answering machines), if such are connected to the telephone line. The Answering Machine function should be enabled in such cases. During initial income of a series of calls (rings), the panel temporizes the maximum number of rings, set at Address 6905. The automatic answering machine must be adjusted to a fewer number of rings. If within 4 minutes there is another series of incoming calls the panel shall answer the first one.
3	MODEM ENABLE	Enabling a connection via modem device. <b>MODEM Disable (*)</b> – The option is disabled. The connection via modem is disabled. <b>MODEM Enable (3)</b> – The option is enabled. The connection via modem is enabled. The system will play of audio file at successful connection with a modem.

**Default setting: MODEM ENABLE**

<b>RINGS</b>	TEXT MENU	8. COMMUNICATION – 1. DIGITAL COMM – 6. UDL – 6. RINGS
	ADDRESS	6905
	OPERATION	695

**Setting the number of incoming rings.**

The symbols 00 to 99 are used.

Up/down loading is disabled if “00” is entered.

**Default setting: 04**

The programming of the following menus concerns the operation of the ECLIPSE 8/8+/16/32/99 control panels with mounted voice dialler, as it is presented for VD PHONE NUMBER 1. The programming of VD PHONES 2-8 is similar.

<b>VD OPTIONS</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 1. VD Options
	ADDRESS	6100
	OPERATION	670

**Programming of options for the voice dialer**

The options are common for all programmed telephone numbers.

In text menus the available option is selected with “1” button and are deselected with “0” button. In address menus use the digit buttons to set the option numbers. Every pressing of the button changes alternatively the option status.

**In this menu you can set the following options:**

1	VD REPORT ENABLE	<p>Sending of a report upon occurrence of an event. When this option is enabled, the dialler will send report upon occurrence of an event - ALARM, FIRE, PANIC, TAMPER, MEDICAL ALARM and WATER LEAKAGE to the programmed phone numbers for the voice dialler. The panel transmits a melody sound signal upon occurrence of any of the events mentioned above.</p> <p><b>Indication in text menus:</b>                  Disabled - “ VD REPORT ENABLE”                  Enabled - “✓VD REPORT ENABLE”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 1                  LED: Disabled - ①; Enabled - ①</p>
2	VD MANAGE ENABLE	<p>User management via external telephone line. When this option is enabled, the managers in the system will be able to control the system remotely - see also the algorithm for user management in APPENDIX 3.</p> <p><b>Indication in text menus:</b>                  Disabled - “ VD MANAGE ENABLE”                  Enabled - “✓VD MANAGE ENABLE”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 2                  LED: Disabled - ②; Enabled - ②</p>
4	SKIP SITE NAME	<p>“Site name” is the name of the protected site, which the user can record as message in the voice dialler menu 5. The description of the option is:  <b>Disable</b> – The message with the site name will be played at the beginning of every message for the system status.  <b>Enable</b> – The message with the site name will be played only once at the beginning of the system status report.</p> <p><b>Indication in text menus:</b>                  Disabled - “ SKIP SITE NAME”                  Enabled - “✓SKIP SITE NAME”</p> <p><b>Indication in address menus:</b>                  LCD: Disabled - *; Enabled - 4                  LED: Disabled - ④; Enabled - ④</p>

**Note:** Disabling the options 1 and 2 at the same time will disable the operation of the voice dialler.

**Attention:** When operation of the PSTN is enabled (“8. COMMUNICATION – 1. DIGITAL COMM – 1. OPTIONS”), the voice dialler is mounted to the control panel’s PCB and also is enabled for operation, in case of a technical trouble with the voice module or with the mounted SD card, after an incoming User call the following sound signalization will be played:

- In case of problem with the mounted SD card – two short sound signals.
- In case of problem with the voice dialler or the same is missing – three short sound signals.



**Default setting: VD REPORT ENABLE, VD MANAGE ENABLE**

<b>VD MSG REP.</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 2. VD Message Rep.
	ADDRESS	6101
	OPERATION	671

**Programming of number for message repetitions for the voice dialer**

The Engineer sets the number for message repetition for the voice dialer in this menu. Set a value from 1 to 9, where 1 corresponds to one repetition, 2 – to two repetitions and so on. The entered value is confirmed with ENTER button.

**Default setting: [3]**

<b>VD LANGUAGE</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 4. VD Language
	ADDRESS	6103
	OPERATION	673

**Setting the language for the voice dialer messages**

The engineer can set the language of the voice messages transmitted from the voice dialer. Use the digit buttons to set a two-digit value for different languages. The set value is confirmed with ENTER button.

The available languages are as follows:

[00] - English; [01] - Portuguese; [02] - Italian; [03] - Romanian; [04] - Greek; [05] - Persian (Farsi); [06] - French; [07] - Turkish; [08] - Serbian; [09] - Spanish; [10] - German; [11] - Bulgarian.



**Attention:** Ask your distributor for more information whether the voice dialler supports your native language and the number which corresponds to it.

**Default setting: [00] - English**

<b>VD PHONE NUMBER 1</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 5. VD Phones – 1. Phone – 1. Phone Number
	ADDRESS	6110
	OPERATION	680 +01

**Setting of Telephone 1 for the voice dialer**

*The operation of the voice dialler is disabled if no telephone number is set in this menu.*

The telephone number must not exceed 32 characters (*it is possible to enter up to 32 characters via ProsTE software and up to 16 characters via keyboard*). Some special functions can be entered by using the next button combinations:

1. Buttons + 0 - Switches on "pulse dialler". "P" letter is displayed on the screen.
2. Buttons + 1 - Switches on "tone dialler". "T" letter is displayed on the screen.
3. Buttons + 2 - 2 seconds pause. "D" letter is displayed on the screen.
4. Buttons + 3 - Switches on "Wait dial tone". "\*" symbol is displayed on the screen.
5. Buttons + 4 - "Blind dialing"; Switches off "Wait dial tone". "#" symbol is displayed on the screen.
6. Buttons + 5 - Deletes the entered telephone number.

**Default setting: none**

<b>VD MESSAGES TYPE</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 5. VD Phones – 1. Phone – 3. Messages types
	ADDRESS	6112
	OPERATION	682 + 01

**Setting of message types to Telephone 1 for the voice dialer**

In this menu are assigned one or more type of the messages which will be transmitted to the user in case of alarm condition through *Telephone Number 1 set for the voice dialler*.



*To the Telephone Number 1 can be programmed to be transmitted only chosen messages. In case the user wants some messages to be transmitted and through Telephone Number 2 (3, 4 or*



all), then the same chosen messages have to be assigned and at the respective menu: "8.COMMUNICATION – 2.VOICE DIALER - 5. VD PHONES - 1. PHONE - 3. MESSAGES TYPE". If it does not matter through which of the telephone numbers the messages are sent, you have to leave in menus the default programming (No messages are assigned).

In text menus the available message types are selected with "1" button and are deselected with "0" button.  
In address menus use the digit buttons 1 to 8 for programming. Every pressing will alternatively change the status of the respective message type - report (active status of the parameter) or no report (inactive status of the parameter). At the end of the procedure only those parameters, which correspond to the designated for report messages, should remain activated on the display.

For the messages types refer to the table described for the built-in digital communication – see menu "8. COMMUNICATION – 1. DIGITAL COMM– 5. PHONES – 1. PHONE – 3. MESSAGES TYPE". **Note:** No Restore type events are transmitted via the voice dialler. The list with available event messages for the voice dialler is presented in Appendix 1, as there is difference according the used software version.

**Default setting: All messages enabled, except 5. ARM, DISARM, BYPASS**

<b>VD PHONE 1 AREAS</b>	TEXT MENU	8. Communication – 2. Voice Dialer – 5. VD Phones – 1. Phone – 4. Areas
	ADDRESS	6111
	OPERATION	681 + 01

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99



**Associating of areas to Telephone 1 for the voice dialler**

According the system configuration, the engineer associates one or several AREA numbers for operation with Telephone 1.

In operation with text menus, the Area is enabled with button "1" and it is disabled with button "0".

In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.

The final configuration of enabled Area numbers is confirmed with ENTER button.

\* To associate/disassociate all areas at the same time press button "0".

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and "0"; for Area 11 – buttons and "1"; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons' combination.

**The Telephone 1 will be inactive if there are no associated areas to it!**

**Default setting: AREA 1**

**9. DEVICES**

In menu "9. DEVICES" are programmed parameters and options for all enrolled devices to the control panel.

The first enrolled device is always the main PCB and this cannot be changed. It is recommended the second enrolled device to be LCD keyboard for programming and settings.

The steps for enrolling of new devices to the control panel are listed in item "5. Enrolling of new devices".

ECLIPSE Control Panels Series – DEVICE capability:

Control panel	Max. devices	Keyboards	Proximity readers	Zone exp. module	PGM exp. module	Wireless exp. module
ECLIPSE 8	2	✓	✓	x	x	x
ECLIPSE 8+	5	✓	✓	✓	x	✓
ECLIPSE 16	5	✓	✓	✓	x	✓
ECLIPSE 32	30	✓	✓	✓	✓	✓
ECLIPSE 99	30	✓	✓	✓	✓	✓

NOTE: In ECLIPSE 32/99 you can attach devices at addresses from 02 to 32. The control panel PCB is always attached to address 01 and that could not be changed. It is recommended to attach up to 30 other devices to system, and leave one of the addresses free.

In the quick table for menu "9. DEVICES" are presented all available devices in one system configuration and compatibility for operation with an Eclipse panel. The devices can be arranged and addressed according the installation.

Quick table for 9. Device Programming Menu

Text Menu	Address				Description	ECLIPSE				
						8	8+	16	32	99
01. Device [MAIN]	<i>The main PCB of the control panel – Eclipse 8, Eclipse 8+, Eclipse 16, Eclipse 32, Eclipse 99</i>									
1. ID	8	0	1	0	Review the ID number of Device 01	✓	✓	✓	✓	✓
2. Areas	8	0	1	1	Associate areas to Device 01	✗	✓	✓	✓	✓
4. Resources	8	0	1	3	Review the HW resources of Device 01	✗	✓	✓	✓	✓
XX. Device [LCD ]	<i>LCD Keyboard – Eclipse LCD32 (PR), Eclipse LCD32S</i>									
1. ID	8	X	X	0	Review the ID number of the Device	✓	✓	✓	✓	✓
2. Areas	8	X	X	1	Associate areas to the Device	✗	✓	✓	✓	✓
3. Options	8	X	X	2	Set options for operation of the Device	✗	✓	✓	✓	✓
4. Resources	8	X	X	3	Review the HW resources of the Device	✗	✓	✓	✓	✓
5. Comm Quality	6	X	X	4	Review the communication quality	✗	✓	✓	✓	✓
XX. Device [LED ]	<i>LED Keyboard – Eclipse LED32 (PR), Eclipse LED16A, Eclipse LED8</i>									
1. ID	8	X	X	0	Review the ID number of the Device	✓	✓	✓	✓	✓
2. Areas	8	X	X	1	Associate areas to the Device	✗	✓	✓	✓	✓
3. Options	8	X	X	2	Set options for operation of the Device	✗	✓	✓	✓	✓
4. Resources	8	X	X	3	Review the HW resources of the Device	✗	✓	✓	✓	✓
5. Comm Quality	8	X	X	4	Review the communication quality	✗	✓	✓	✓	✓
6. LED Relocation	8	X	X	5	Setting the first zone to be displayed	✗	✗	✗	✗	✓
XX. Device [ZEXP]/[PEXP]	<i>Expander modules – Eclipse Zone8 (PS), Eclipse PGM8 (PS)</i>									
1. ID	8	X	X	0	Review the ID number of the Device	✗	✓	✓	✓	✓
2. Areas	8	X	X	1	Associate areas to the Device	✗	✓	✓	✓	✓
4. Resources	8	X	X	3	Review the HW resources of the Device	✗	✓/✗	✓/✗	✓	✓
5. Comm Quality	8	X	X	4	Review the communication quality	✗	✓	✓	✓	✓
XX. Device [WEXP]	<i>Wireless expander module – Eclipse WL</i>									
1. ID	8	X	X	0	Review the ID number of the Device	✗	✓	✓	✓	✓
2. Areas	8	X	X	1	Associate areas to the Device	✗	✓	✓	✓	✓
4. Resources	8	X	X	3	Review the HW resources of the Device	✗	✓	✓	✓	✓
5. Comm Quality	8	X	X	4	Review the communication quality	✗	✓	✓	✓	✓
6. WL Device	8	X	X	5	Enrolling of BRAVO wireless devices	✗	✓	✓	✓	✓
7. WL Remote	8	X	X	6*	Enrolling of BRAVO remote key fobs	✗	✓	✓	✓	✓
XX. Device [PRX ]	<i>Proximity card reader – Eclipse PR, Eclipse PR IT</i>									
1. ID	8	X	X	0	Review the ID number of the Device	✓	✓	✓	✓	✓
2. Areas	8	X	X	1	Associate areas to the Device	✗	✓	✓	✓	✓
3. Options	8	X	X	2	Set options for operation of the Device	✗	✓	✓	✓	✓
4. Resources	8	X	X	3	Review the HW resources of the Device	✗	✓	✓	✓	✓
5. Comm Quality	8	X	X	4	Review the communication quality	✗	✓	✓	✓	✓
7. ARM Mode A	8	X	X	7	Set the type of Arming Mode A	✓	✓	✓	✓	✓
8. ARM Mode B	8	X	X	8	Set the type of Arming Mode B	✓	✓	✓	✓	✓

\* Address 8xx6 is accessible only from the screen for entering an address number.

ATTENTION: Up to 4 different wireless expander modules Eclipse WL can be attached to a system configuration!

<b>DEVICE 01 ID NUMBER</b>	TEXT MENU	9. DEVICES – 01. DEVICE [MAIN] – 1. ID
	ADDRESS	8010
	OPERATION	810 + 01


**Identification number for Device 01.** This is a menu just for review.

**The Device 01 is always the control panel**, and it is performed at the LCD display with it is unique name [MAIN] and ID number. The indication on the LED keyboards is lighting on Zone 01.



Example, address menu:

```
8010>DEV1_ID
[MAIN][XXXXXXXX]
```



**Default setting: MAIN**

<b>DEVICE 01 AREAS</b>	TEXT MENU	9. DEVICES – 01. DEVICE [MAIN] – 2.AREAS
	ADDRESS	8011
	OPERATION	811 + 01

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

**Association of Areas to Device 01**

According the system configuration, the engineer associates one or several AREA numbers for operation with Device 01.

In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”. In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.

The final configuration of enabled Area numbers is confirmed with ENTER button.

\* To associate/disassociate all areas at the same time press button “0”.

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.

**Default setting: AREA 1**

<b>DEVICE 01 RESOURCES</b>	TEXT MENU	9. DEVICES – 01. DEVICE [MAIN] – 4. RESOURCES
	ADDRESS	8013
	OPERATION	813 + 01

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99



**On board resources of Device 01.**

In this menu, the engineer can check on board resources (number of available zone inputs and PGM outputs) for Device 01. This is a menu just for review.

**Indication:**

**LCD 32 (S):** The maximum number of Inputs and Outputs is displayed on the screen.

**LED 16A VG/32:** The maximum number of Inputs and Outputs are reviewed with the help with the arrows. When reviewing the Inputs number LED “A1” is lighting on, zone 15 is blinking and a zone number from 1 to 8 is showing the number of inputs. When reviewing the Outputs number LED “A2” is lighting on, zone 15 is blinking and a zone number from 1 to 8 is showing the number of outputs. Note that Zone 10 corresponds to no inputs/outputs available for the device.

**LED 8/16A:** The maximum number of Inputs and Outputs are reviewed with the help with the arrows. When reviewing the Inputs number, the zone 1 is blinking and a lighting digit button shows the number of available inputs for the device. When reviewing the Outputs number, the zone 2 is blinking and a lighting digit button shows the number of available outputs for the device.

The following addresses are about the programming of DEVICE 02 – the first added to the system configuration. The manufacturer recommends that to be a control keyboard. Basically, the DEVICES 03-32 are programmed in an analogical way with some limitations depending on their type and functionality.

<b>DEVICE 02 ID NUMBER</b>	TEXT MENU	9. DEVICES – 02. DEVICE [Name] – 1. ID
	ADDRESS	8020
	OPERATION	810 + 02

**Identification number for Device 02.**

This a menu for enrolling of Device 02 to the control panel. It is recommended that to be LCD programming keyboard. The following list represents the type of devices available to enrol to the system configuration:

Indication		Description	ECLIPSE			
LED	LCD		8*	8+/16**	32***	99***
2	LCD	Keyboard LCD 32/32S	✓	✓	✓	✓
3	LED	Keyboard LED 8/16A/16A VG32	✓	✓	✓	✓
4	ZEXP	Zone expander	✗	✓	✓	✓
5	PEXP	PGM expander	✗	✗	✓	✓
6	WEXP	Wireless expander	✗	✓	✓	✓
7	PRX	Stand-alone proximity card reader	✓	✓	✓	✓
11	SIRN	BRAVO SR Wireless outdoor siren	✗	✓	✓	✓
12	MC	BRAVO MC Wireless magnetic contact	✗	✓	✓	✓
13	PIR	BRAVO PIR Wireless motion detector	✗	✓	✓	✓
15	REMT	BRAVO RC Remote key fob	✗	✓	✓	✓
16	FIRE	BRAVO FD Wireless fire detector	✗	✓	✓	✓
18	FLD	BRAVO FL Wireless flood detector	✗	✓	✓	✓



\* **Eclipse 8:** Up to 2 devices can be enrolled to the system bus: 2 keyboards, 2 proxy readers or 1 keyboard and 1 proxy reader.

\*\* **Eclipse 8+/16:** Up to 5 devices can be enrolled to the system bus irrespective of their type, except PGM expander module.

\*\*\* **Eclipse 32/99:** Up to 30 devices can be enrolled to the system bus irrespective of their type.

**NOTE:** It is not necessary to enrol the built-in proximity reader in keyboards LED 32, LCD 32 and LCD 32S.

All wireless devices must be enrolled to a wireless expander module (WEXP), which is attached to the system configuration.

The steps for enrolling devices to the control panel are described in item “5. Enrolling new devices”. You can also enter the unique ID number of the device directly with the digit buttons from the keyboard.



To delete the device from the address press and hold the button “0” for 2-3 seconds.

**Default setting: (recomended) LCD/LED keyboard**

<b>DEVICE 02 AREAS</b>	TEXT MENU	9. DEVICES – 02. DEVICE [Name] – 2.AREAS
	ADDRESS	8021
	OPERATION	811 + 02

**ECLIPSE 8+**

**ECLIPSE 16**

**ECLIPSE 32**

**ECLIPSE 99**

**Association of Areas to Device 02**

According the system configuration, the engineer associates one or several AREA numbers for operation with Device 02.

In operation with text menus, the Area is enabled with button “1” and it is disabled with button “0”.

In operation with addresses, the Area is enabled with choosing a digit button corresponding to its number. Next pressing of the same button will disable the Area\*.

The final configuration of enabled Area numbers is confirmed with ENTER button.

\* To associate/deassociate all areas at the same time press button “0”.

**Eclipse99:** To enable for operation Area 10, press in sequence buttons and “0”; for Area 11 – buttons and “1”; for Area 12 – buttons and 2, etc. To disable the same Areas, use the same buttons’ combination.

If the device is a proxy card reader, the set at this address area numbers will be armed in Full arming mode when a valid card is approached and hold in front of the reader until the red LED lights on.





**Keyboards and modules:** If all areas for a device are disabled the device becomes inactive, irrespective of that there are any options programmed for it. If the device is a keyboard then it can perform only engineer and maintenance programming, and the manager and user programming are disabled as and the arming and disarming operations with it.



**LED 8:** The keyboard supports operation with one area only. If more areas are set in this menu for LED8 keyboard, then only the area with the smallest number will be active.

**LED 16A:** The keyboard supports operation with three areas named A, B and C. If more than three areas are set in this menu for LED 16A keyboard, then only the three areas with the smallest numbers will be active.

**Proximity card readers:** If all areas for the reader are disabled at this address, then the device will operate only in MODE A and MODE B.

You must consider the following important notes for Eclipse Series Keyboards, when design and organize the security system including ECLIPSE panels!

ECLIPSE 8

Keyboard	Display type	Indication
		Area 1
LED 8	LED Icon	No specific indication
LED 16A / 16A VG	LED Icon	A
LED 32	LED Icon	A1
LCD 32 (S)	LCD Text	1

ECLIPSE 8+

ECLIPSE 16

Keyboard	Display type	Indication		
		Area 1	Area 2	Area 3
LED 8*	LED Icon	One Area: No specific indication		
LED 16A / 16A VG	LED Icon	A	B	C
LED 32	LED Icon	A1	A2	A3
LCD 32 (S)	LCD Text	1	2	3

ECLIPSE 32

ECLIPSE 99

Keyboard	Display type	Indication AREA							
		1	2	3	4	5	6	7	8
LED 8*	LED Icon	One Area: No specific indication							
LED 16A / 16A VG**	LED Icon	Three Areas: A, B and C indication							
LED 32***	LED Icon	A1	A2	A3	A4	A5	A6	A7	A8
LCD 32 (S)	LCD Text	1	2	3	4	5	6	7	8

\* **Note:** LED 8 keyboard supports operation with only one area in the system. The area number is set in menu 9. DEVICES-XX. Device-2. AREA (address 8xx1), where "xx" is the keyboard number in the system.

\*\* **Note:** LED 16A/ LED 16A VG keyboard supports operation with three independent areas in the system. The area numbers are set in menu 9. DEVICES-XX. Device-2. AREA (address 8xx1), where "xx" is the keyboard number in the system. The areas are displayed as A, B and C, where A is the area with the smaller number, and C - the area with higher one. Note that there may not be direct correspondence between the area number and the keyboard indication letter.

\*\*\* **Note:** When connected to Eclipse 99 the installer can associate up to 8 areas to one LED32 keyboard. The area numbers are set in menu 9. DEVICES-XX. Device-2. AREA (address 8xx1), where "xx" is the keyboard number in the system. The areas are displayed as A1-A8, where A1 is the area with the smaller number, and A8 - the area with higher one. Note that there may not be direct correspondence between the area number and the keyboard indication letter.

**Default setting: AREA 1**

DEVICE 02  
OPTIONS

TEXT MENU	9. DEVICES – 02. DEVICE [Name] – 3. OPTIONS
ADDRESS	8022
OPERATION	812 + 02

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99

### Setting of options for Device 02

A set of options are programmed at the address for Device 02.

In text menus, to select an option press "1" button and to deselect press "0" button.

In address menus, the options are selected with pressing the respective digit button. The next pressing of the same button deselects the option. More than one option can be programmed. The final choice is confirmed with ENTER.



- The options from 1 to 5 can be programmed only for the connected to the system bus LCD keyboards. For LED keyboards are available options from 1 to 4.
- The option 1 can be programmed for the connected to the system bus proximity card readers.
- The options must be programmed for every device separately at the respective address.
- The options are not supported for devices type MAIN, ZEXP, PEXP and WEXP.

**The following options are assigned:**

1	CHIME	<p>Sound signalization “Chime” for the Device. When this option is enabled, the “Chime” sound signal is activated in opening of entry-exit type zone.</p> <p><b>Indication in text menus:</b> Disabled - “ CHIME” Enabled - “✓CHIME”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 1 <b>LED:</b> Disabled - ①; Enabled - ①</p> <p><b>Note:</b> This option is set only for the respective device (keyboard or card reader) and can be enabled or disabled just for it in this menu. The “Chime” sound signalization must be enabled and for respective zone in menu “4. INPUTS – 5. ZONES – XX. ZONE – 5. OPTIONS 2” (address 2xx5), option “6. Chime”, where “xx” is the zone number. Also, the device and the zone must be associated (attached) to at least one common area.</p>
2	HIDE ZONE INFO	<p>Hiding the zone information for the Device, when the system is disarmed. When this option is disabled, every opening of a zone will be displayed on the screen with information for the zone number. For LED keyboards – the number of the zone is blinking. When this option is enabled, the information for the zones (open or ready for arming) will be hidden.</p> <p><b>Indication in text menus:</b> Disabled - “ HIDE ZONE INFO” Enabled - “✓HIDE ZONE INFO”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 2 <b>LED:</b> Disabled - ②; Enabled - ②</p>
3	CONFIDENTIAL	<p>Using confidential mode for the Device. The Confidential mode is a special mode, where the system information of the main screen is locked and cannot be viewed from the user. When this option is enabled and the programmed in menu “2. SETTINGS – 04. CONF. TIMER” (address 0014) time is over, the information for the current system status will be locked for viewing. The message “Confidential” is displayed on the LCD keyboards, and there is no indication on the LED keyboards.</p> <p><b>Indication in text menus:</b> Disabled - “ CONFIDENTIAL” Enabled - “✓CONFIDENTIAL”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 3 <b>LED:</b> Disabled - ③; Enabled - ③</p> <p><b>Attention:</b> The exit of the confidential mode is performed with pressing of a random button or entering of valid code (user, manager or engineer), according that “4. EXIT CONFIDENTIAL MODE” option is disabled or enabled. See also the settings of this option in case STANDARD EN50131 Grade 2/Grade 3 is enabled – at the end of this menu.</p>
4	CONFIDENTIAL EXIT	<p>Confidential mode exit. The option defines the way of exit from the confidential mode. When this option is disabled, the exit from the confidential mode is with pressing of a random button. When this option is enabled, the exit from the confidential mode is with entering of a valid code.</p> <p><b>Indication in text menus:</b> Disabled - “ CONF EXIT” Enabled - “✓CONF EXIT”</p> <p><b>Indication in address menus:</b> <b>LCD:</b> Disabled - *; Enabled - 4 <b>LED:</b> Disabled - ④; Enabled - ④</p> <p><b>Attention:</b> When the option “3. CONFIDENTIAL MODE” is disabled the setting of option “4. EXIT CONFIDENTIAL MODE” does not matter. See also the settings of this option in case STANDARD EN50131 Grade2/Grade3 is enabled – at the end of this menu.</p>



LCD

5 MAIN SCREEN

**This option is available for LCD keyboards only!**

Here the engineer sets the information displayed on the main screen on the LCD screen.

When this option is disabled, on the screen is displayed the name of the system and the current time and date.

When this option is enabled, on the screen are visible the numbers of all available areas (according the model of the panel) and their current state – Full armed, Stay/Sleep armed, disarmed, etc.

**Indication in text menus:**

Disabled - " MAIN SCREEN"

Enabled - "✓MAIN SCREEN"

**Indication in address menus:**

LCD: Disabled - \*; Enabled - 5

LED: Disabled - ☹; Enabled - ☺



**\* Options 3 and 4 are automatically enabled when in menu 15. STANDARD (address 0096) option EN50131 G2 or EN50131 G3 is enabled. When a standard option is enabled the setting for options 3 and 4 in this menu could not be changed. It will remain active until system operates under the requirements of EN50131.**

*When the option is enabled, the keyboard will enter in confidential mode irrespective of the current system status (Armed or Disarmed). The confidential mode is inactive when the system is in programming mode (user, manager or engineer).*

ECLIPSE 8+

ECLIPSE 32

ECLIPSE 99

**Default setting: 2. Zone Information Enable, 5. Info for the System Name**

**DEVICE 02 RESOURCES**

TEXT MENU	9. DEVICES – 02. DEVICE [NAME] – 4. RECOUSES
ADDRESS	8023
OPERATION	813 + 02

ECLIPSE 8+

ECLIPSE 16

ECLIPSE 32

ECLIPSE 99

**On board resources of Device 02.**

In this menu, the engineer can check on board resources (number of available zone inputs and PGM outputs) for Device 02. This address is only for review. For detailed description of the indication from keyboards see menu "9. DEVICES – 01. DEVICE [MAIN] – 4. RESOURCES".

**Default setting: according the type of the device and the used connection style**

**DEVICE 02 COMM QUALITY**

TEXT MENU	9. DEVICES – 02. DEVICE [NAME] – 5. COMM QUALITY
ADDRESS	8024
OPERATION	814 + 02

LCD

ECLIPSE 8+

ECLIPSE 16


ECLIPSE 32

ECLIPSE 99


**Communication quality for Device 02.**

The engineer can check the quality of communication between the Device 02 and the control panel). This address is only for review. The communication quality is described with signal strength, the number of sent packets and the number of repeated packets.

Example:



Check the strength of the communication signal between the device and the control panel.



**DEVICE 02 LED RELOC**

TEXT MENU	9. DEVICES – 02. DEVICE [LED] – 6. LED RELOC
ADDRESS	8025
OPERATION	815 + 02

LCD

ECLIPSE 99

**Setting of first displayed zone on a LED keyboard.**

This is a special menu accessible for programming only via LCD keyboard or ProsTE software. The menu is available only for LED keyboards as the installer sets just a zone number. This zone number is the first to be displayed on the LED panel of the respective keyboard.

Since the LED keyboards are limited for visualization of all real zones in Eclipse 99 control panel (LED32 can display up to 32 zones, LED16A - up to 16 zones and LED8 - up to 8 zones) the installer can organize the visualization and to program operation just with zones attached to one area.




In this menu the installer sets a zone number which will be displayed as Zone 01 on the LED Keyboard.

For example, the device is a LED8 keyboard, it is attached for operation with Area 1 (including zones 01-15). The users operating with this particular keyboard have rights to arm/disarm/bypass zones from 10 to 15 in the system configuration. So, in this case the installer will set in the menu Zone 10:



In this way the users will see the state just of those zones they have rights for management.



In this way the installer can organize the user management of complex system with up 99 zones via LED keyboards with distributed areas and zone indication.

It is strongly recommended preliminary planning and organizing the management of users when using LED keyboards in systems with Eclipse 99 control panel and using more than 32 zones. Note that the default setting for the LED keyboards is set to start from Zone 01.

**Default setting: [01]**

The following addresses are available for programming of Eclipse WL wireless expander only ("XX" is a number of a device from 02 to 31). **Up to 4 different wireless expanders can be connected to Eclipse 8+/16/32/99 control panel.**

You can find detailed information for installation and operation with Eclipse WL wireless expander in "Installation and programming manual for Eclipse WL".

<b>WL Device [XX]</b>	TEXT MENU	9. Devices – xx. DEVICE [WEXP] – 6. WL Device
	ADDRESS	8xx5
	OPERATION	815 + xx

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

**Enrolling of wireless devices to Eclipse WL expander module**

The installer enrolls wireless devices BRAVO series PIR, MC, FL, FD and SR type to Eclipse WL wireless expander in this menu. The number of wireless devices depends on the type of the control panel: up to 16 devices to ECLIPSE 8+/16 control panel; up to 32 to ECLIPSE 32/99.

After entering this menu, the installer has to enter a number of a device using the digit buttons of the keyboard and to confirm with pressing ENTER button. If the device number is free: the screen of LCD keyboard displays "FREE [ ]"; when using LED 16A VG/LED 32 keyboard – zone numbers from 1 to 16 are lighting on; when using LED 8/16A keyboard – the button "0" is lighting on.

To enrol a wireless device, dismount its cover and remove the protection folio from the battery. At the free position for a wireless device, press the ENTER button of the keyboard and while the message "Searching..." is displayed press the ENROLL button of the wireless device. If the enrolment is successful, the type of the device is displayed on the screen with its unique ID code. The next pressing of ENTER button of the keyboard will move back to the screen for entering number of a new device.



After the enrolment to the wireless expander, the devices PIR, MC, FD, FL and SR type have to be attached to a free zone numbers of the panel – see the examples after the description of menu "4. INPUTS – 5. ZONES – 01. ZONE – 1. ATTACH" (address 2010), as the sirens SR must be attached and also to a free PGM number with "Siren" option set – see description of menu "5. OUTPUTS – 2.PGMs – 01. PGM – 1. ATTACH" (address 3010).

<b>WL Remote</b> [XX]	TEXT MENU	9. Devices – xx. Device [WEXP] – 7. WL Remote
	ADDRESS	8xx6
	OPERATION	816 + xx

- ECLIPSE 8+
- ECLIPSE 16
- ECLIPSE 32
- ECLIPSE 99

**Enrolling of remote key fobs to Eclipse WL wireless expander module**

The installer enrolls remote key fobs BRAVO RC/RC-41/RC-21/RC-11 to Eclipse WL wireless expander in this menu. The number of enrolled key fobs depends on the type of the control panel: up to 32 remote key fobs to ECLIPSE 8+/16 control panel; up to 64 to ECLIPSE 32; up to 99 to ECLIPSE99.

**Attention: In address menu style, the address 8xx6 is accessible for entering only from the main screen in ENGINEER PROGRAMMING MENU.**

The process for enrolment of remote key fobs is analogic to those described for wireless devices.



*The enrolled remote key fobs are automatically attached to the corresponding User numbers in the system - RC1 to User 1, RC2 to User 2 and so on. Refer also to the Important Note after the description of menus “3. Codes – 1. Users – 01. User – 6. RC \* (A) FUNCT. / 7. RC (B) FUNCT.”*

The following menus are available for proximity cards readers only (“XX” is a number of a device from 02 to 31).

<b>DEVICE XX</b> <b>ARM MODE</b> A	TEXT MENU	9. DEVICES – xx. DEVICE [PRX] – 7. ARM MODE A
	ADDRESS	8xx7
	OPERATION	817 + xx

**“ARM Mode A” for Proximity Card Reader**

In this menu the engineer can set a configuration for operation (arming and/or disarming) of all areas in the system. This combination of disarm and arming types is set for every of the areas, provides the ARM MODE A for the proximity card reader. The “ARM MODE A” operation does not depend on the programmed in menu “9. DEVICES – xx. DEVICE [Name] – 2. AREAS” (address 8xx1).

To activate the ARM MODE A, the user has to approach and hold a valid card in front of the proxy reader for a 2-3 sec until the green LED is lighting on.

The engineer can set one or more areas to operate in ARM MODE A – that depends on the system configuration and organization. To set an ARM type or disarm use the buttons:

Button	Operation	Indication		
		LCD32 (S)	LED32	LED8/16A
0	No change of the Area state	[*]	[10]	Button [0]
1	Disarm	[d]	[1]	Button [1]
2	Full ARM	[f]	[2]	Button [2]
3	Stay ARM	[s]	[3]	Button [3]
4	Sleep ARM	[S]	[4]	Button [4]

**Indication:**

LCD: The respective letter for the chosen operation for the area is displayed on the screen.

LED: After entering the address, the system shows the set type for the Area 1. Use the arrow buttons to review the set types for the other Areas. To change the arming type, press the button corresponding to the respective operation. Every pressing of a button sets the new arming type and moves on to the next area number.

**Default setting: Area 1 – [s] Stay ARM**

<b>DEVICE XX</b> <b>ARM MODE</b> B	TEXT MENU	9. DEVICES – xx. DEVICE [PRX] – 8. ARM MODE B
	ADDRESS	8xx8
	OPERATION	818 + xx

**“ARM Mode B” for Proximity Card Reader**

The programming of this menu is analogical to the one described for ARM MODE A. This combination of disarm and arming types is set for every of the areas, provides the “ARM MODE B” for the proximity card reader. To activate the “ARM MODE B”, the user has to approach and hold a valid card in front of the proxy reader for a 3-4 sec until the yellow LED is lighting on.

**Default setting: Area 1 – [S] Sleep ARM**

All available for the panel version device numbers are programmed in analogical way according their type.

## APPENDIXES

## APPENDIX 1. Memory LOG Events

Code	LED Indication	Event number	Description	System Event (LOG)	Zone/ User	CID Code	SIA Code
1	①②③④⑤⑥⑦⑧	1	Burglary Alarm event	Z## Alarm	Zone No/name	1 13A	BA
2	①②③④⑤⑥⑦⑧	2	Burglary Alarm event restore	Z## Alarm R	Zone No/name	3 13A	BH
3	①②③④⑤⑥⑦⑧	3	Fire Alarm event	Z## Fire	Zone No/name	1 11A	FA
4	①②③④⑤⑥⑦⑧	4	Fire Alarm event restore	Z## Fire R	Zone No/name	3 11A	FH
5	①②③④⑤⑥⑦⑧	5	Panic Alarm event	Z## Panic	Zone No/name	1 12A	PA
6	①②③④⑤⑥⑦⑧	6	Panic Alarm event restore	Z## Panic R	Zone No/name	3 12A	PR
7	①②③④⑤⑥⑦⑧	7	Tamper Alarm event	Z## Tamper	Zone No/name	1 137	TA
8	①②③④⑤⑥⑦⑧	8	Tamper Alarm event restore	Z## Tamper R	Zone No/name	3 137	TR
9	①②③④⑤⑥⑦⑧	9	Medical Alarm event	Z## Medical	Zone No/name	1 1AA	MA
10	①②③④⑤⑥⑦⑧	10	Medical Alarm event restore	Z## Medical R	Zone No/name	3 1AA	MR
11	①②③④⑤⑥⑦⑧	11	Activated zone with "24h Burglary" AUX attribute	Z## 24h Alarm	Zone No/name	1 13A	BA
12	①②③④⑤⑥⑦⑧	12	Restored zone with "24h Burglary" AUX attribute	Z## 24h Alarm R	Zone No/name	3 13A	BH
13	①②③④⑤⑥⑦⑧	13	Activated zone with AUX "AC Loss" attribute	Z## AC Loss	Zone No	1 3A1	AT
14	①②③④⑤⑥⑦⑧	14	Restored zone with AUX "AC Loss" attribute	Z## AC Restore	Zone No	3 3A1	AR
15	①②③④⑤⑥⑦⑧	15	Activated zone with AUX "Battery Low" attribute	Z## Batt Low	Zone No	1 3A2	YT
16	①②③④⑤⑥⑦⑧	16	Restored zone with AUX "Battery Low" attribute	Z## Batt Restore	Zone No	3 3A2	YR
17	①②③④⑤⑥⑦⑧	17	Activated zone with AUX "Water leakage" attribute	Z## Water leak	Zone No	1 154	WA
18	①②③④⑤⑥⑦⑧	18	Restored zone with AUX "Water leakage" attribute	Z## Water leak R	Zone No	3 154	WR
19	①②③④⑤⑥⑦⑧	19	Activated zone with AUX "GAS Detector" attribute	Z## Gas	Zone No	1 151	GA
20	①②③④⑤⑥⑦⑧	20	Restored zone with AUX "GAS Detector" attribute	Z## Gas R	Zone No	3 151	GR
21	①②③④⑤⑥⑦⑧	21	Activated zone with AUX "GSM Link Trouble" attribute	Z## GSM Link	Zone No	1 354	YS
22	①②③④⑤⑥⑦⑧	22	Restored zone with AUX "GSM Link Trouble" attribute	Z## GSM Link R	Zone No	3 354	YK
23	①②③④⑤⑥⑦⑧	23	Activated zone with AUX "GAS Trouble" attribute	Z## Gas Trbl	Zone No	1 157	GT
24	①②③④⑤⑥⑦⑧	24	Restored zone with AUX "GAS Trouble" attribute	Z## Gas Trbl R	Zone No	3 157	GR
25	①②③④⑤⑥⑦⑧	25	Activated zone with AUX "High temperature" attribute	Z## High Temp	Zone No	1 158	KA
26	①②③④⑤⑥⑦⑧	26	Restored zone with AUX "High temperature" attribute	Z## High Temp R	Zone No	3 158	KR
27	①②③④⑤⑥⑦⑧	27	Activated zone with AUX "Low temp" attribute	Z## Low Temp	Zone No	1 159	ZA
28	①②③④⑤⑥⑦⑧	28	Restored zone with AUX "Low temp" attribute	Z## Low Temp R	Zone No	3 159	ZR
29	①②③④⑤⑥⑦⑧	29	Activated zone with AUX "Loss of heat" attribute	Z## Heat Loss	Zone No	1 153	ZA
30	①②③④⑤⑥⑦⑧	30	Restored zone with AUX "Loss of heat" attribute	Z## Heat Loss R	Zone No	3 153	ZR
31	①②③④⑤⑥⑦⑧	31	Activated zone with "Write to LOG" <sup>(1)</sup> attribute	Z## Open	Zone No	-	-
32	①②③④⑤⑥⑦⑧	32	Restored zone with "Write to LOG" <sup>(1)</sup> attribute	Z## Close	Zone No	-	-
33	①②③④⑤⑥⑦⑧	33	Zone Bypass	Z## Bypassed	Zone No/name	1 57A	UB
34	①②③④⑤⑥⑦⑧	34	Zone Bypass restore	Z## UnBypassed	Zone No/name	3 57A	UU
35	①②③④⑤⑥⑦⑧	35	Quick arming – FULL ARM	QuickArm A#	Area No/name	3 4A8	CL
36	①②③④⑤⑥⑦⑧	36	Quick arming – STAY ARM	QuickArm A#Stay	Area No/name	3 4A8	CL
37	①②③④⑤⑥⑦⑧	37	Quick arming – SLEEP ARM	QuickArm A#Inst	Area No/name	3 4A8	CL
38	①②③④⑤⑥⑦⑧	38	Arming with user code - FULL	U##Arm A#	User/Area No	3 4A1	CL
39	①②③④⑤⑥⑦⑧	39	Arming with user code - STAY	U##Arm A#Stay	User No/name	3 4A1	CL
40	①②③④⑤⑥⑦⑧	40	Arming with user code - SLEEP	U##Arm A#Inst	User No/name	3 4A1	CL
41	①②③④⑤⑥⑦⑧	41	Disarming with user code	U##Disarm A#	User/Area No	1 4A1	OP
42	①②③④⑤⑥⑦⑧	42	Remote arming - FULL	U##RemArm A#	User/Area No	3 4A7	CQ
43	①②③④⑤⑥⑦⑧	43	Remote arming - STAY	U##RemArm A#Stay	User No/name	3 4A7	CQ
44	①②③④⑤⑥⑦⑧	44	Remote arming - SLEEP	U##RemArm A#Inst	User No/name	3 4A7	CQ

45	①②③④⑤⑥⑦⑧	45	Remote disarming	U##RemDisarm A#	User/Area No	1 4A7	OQ
46	①②③④⑤⑥⑦⑧	46	Arming with key switch - FULL	Z##KeyArm A#	Zone/Area No	3 4A9	CS
47	①②③④⑤⑥⑦⑧	47	Arming with key switch - STAY	Z##KeyArm A#Stay	Zone No/name	3 4A9	CS
48	①②③④⑤⑥⑦⑧	48	Arming with key switch - SLEEP	Z##KeyArm A#Inst	Zone No/name	3 4A9	CS
49	①②③④⑤⑥⑦⑧	49	Disarming with key switch	Z##KeyDisarm A#	Zone/Area No	1 4A9	OS
50	①②③④⑤⑥⑦⑧	50	FULL Arming on Timeslot	AutoArm A#	Area No	3 4A3	CA
51	①②③④⑤⑥⑦⑧	51	STAY Arming on Timeslot	AutoArm A#Stay	Area No	3 4A3	CA
52	①②③④⑤⑥⑦⑧	52	Disarming on Timeslot	AutoDisarm A#	Area No	1 4A3	OA
53	①②③④⑤⑥⑦⑧	53	FULL Arming on "no movement"	AutoArm A#	Area No	3 4A3	CA
54	①②③④⑤⑥⑦⑧	54	STAY Arming on "no movement"	AutoArm A#Stay	Area No	3 4A3	CA
55	①②③④⑤⑥⑦⑧	55	Not ready zone with FORCE attribute when arming	Z## Forced	Zone No/name	1 57A	UB
56	①②③④⑤⑥⑦⑧	56	Not ready zone with FORCE attribute when disarming	Z## Included	Zone No/name	3 57A	UU
57	①②③④⑤⑥⑦⑧	57	Arm Delay on Timeslot	U## ArmExtend A#	User/Area No	1 464	CE
58	①②③④⑤⑥⑦⑧	58	Ambush code entered	U## Duress Alarm	User No/name	1 121	HA
59	①②③④⑤⑥⑦⑧	59	Medical panic alarm sent from keyboard	KBD## Medical	Keyboard No	1 1AA	MA
60	①②③④⑤⑥⑦⑧	60	Medical panic alarm from keyboard restored	KBD## Medical R	Keyboard No	3 1AA	MR
61	①②③④⑤⑥⑦⑧	61	Police panic alarm sent from keyboard	KBD## Panic	Keyboard No	1 12A	PA
62	①②③④⑤⑥⑦⑧	62	Police panic alarm from keyboard restored	KBD## Panic R	Keyboard No	3 12A	PR
63	①②③④⑤⑥⑦⑧	63	Fire panic alarm sent from keyboard	KBD## Fire	Keyboard No	1 11A	FA
64	①②③④⑤⑥⑦⑧	64	Fire panic alarm from keyboard restored	KBD## Fire R	Keyboard No	3 11A	FH
	①②③④⑤⑥⑦⑧	65	Keyboard blocking	KBD## Lockout	Keyboard No	1 421	JA
	①②③④⑤⑥⑦⑧	66	Entry in Engineer programming menu	Installer In	-	1 627	LB
	①②③④⑤⑥⑦⑧	67	Exit from Engineer programming menu	Installer Out	-	1 628	LX
	①②③④⑤⑥⑦⑧	68	Entry in Remote programming mode	Download Start	-	1 411	RB
	①②③④⑤⑥⑦⑧	69	Exit from Remote programming mode	Download End	-	1 412	RS
	①②③④⑤⑥⑦⑧	70	Periodical test	Periodic Tst Rep	-	1 6A2	TX
	①②③④⑤⑥⑦⑧	71	Manual test	Manual Tst Rep	-	1 6A1	TX
	①②③④⑤⑥⑦⑧	72	No AC mains power supply	AC Failure	-	1 3A1	AT
	①②③④⑤⑥⑦⑧	73	Mains power supply restore	AC Restore	-	3 3A1	AR
	①②③④⑤⑥⑦⑧	74	Battery low charge	Battery Low	-	1 3A2	YT
	①②③④⑤⑥⑦⑧	75	Battery loss	Battery Missing	-	1 311	YM
	①②③④⑤⑥⑦⑧	76	Battery restore	Battery Restore	-	3 3A9	YR
	①②③④⑤⑥⑦⑧	77	Siren output short-circuit	Bell Short	-	1 321	YA
	①②③④⑤⑥⑦⑧	78	Siren line broke out	Bell Absent	-	1 321	YA
	①②③④⑤⑥⑦⑧	79	Siren restored	Bell Restore	-	3 321	YH
	①②③④⑤⑥⑦⑧	80	2-wire fire line fault (PGM4)	Fire line Flt	-	1 373	FT
	①②③④⑤⑥⑦⑧	81	2-wire fire line fault restored (PGM4)	Fire line Rstr	-	3 373	FJ
	①②③④⑤⑥⑦⑧	82	Fuse blown out	Fuse Blown	-	1 3AA	YP
	①②③④⑤⑥⑦⑧	83	Fuse restore	Fuse Restore	-	3 3AA	YQ
	①②③④⑤⑥⑦⑧	84	Telephone line loss	Comm Ch Trouble	PSTN	1 351	LT
	①②③④⑤⑥⑦⑧	85	Telephone line restore	Comm Ch Restore	PSTN	3 351	LR
	①②③④⑤⑥⑦⑧	86	System power up	Power UP	-	1 3A8	RR
	①②③④⑤⑥⑦⑧	87	System reset	Reset	-	1 3A5	YW
	①②③④⑤⑥⑦⑧	88	Time change	Time Changed	-	3 625	JT
	①②③④⑤⑥⑦⑧	89	Sending of message is impossible.	Comm Msg Trouble	GPRS/PSTN/LAN	1 354	YC
	①②③④⑤⑥⑦⑧	90	Sending of message is impossible restored. /Report to monitoring station restored.	Comm Restore	GPRS/PSTN/LAN	3 354	YK
	①②③④⑤⑥⑦⑧	91	Periphery device loss	D## Absent	Device No/name	1 333	ET
	①②③④⑤⑥⑦⑧	92	Periphery device restore	D## Restore	Device No/name	3 333	ER
	①②③④⑤⑥⑦⑧	93	Tamper from periphery device	D## Tamper	Device No/name	1 145	TA
	①②③④⑤⑥⑦⑧	94	Tamper from periphery device restore	D## Tamper R	Device No/name	3 145	TR
	①②③④⑤⑥⑦⑧	95	Arming on "no movement" failure	A## Failed AutoArm	Area No	-	-
	①②③④⑤⑥⑦⑧	96	User Code Changed	U## Code Changed	User No/name	-	JV

① ② ③ ④ ⑤ ⑥ ⑦ ⑧	97	Invalid date and time	Invalid clock	-	1 626	JT
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	98	Clearing the log from user	U# #Memory Clear	User No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	99	Arming without reviewing the current system troubles	U# #OverrideARM	User No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	100	Low battery charge of wireless device (PIR, MC, FL, FD)	WLDev##Batt Low	WL Dev. No/name	1 384	XT
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	101	Low battery charge of wireless device Restore (PIR, MC, FL, FD)	WLDev##Batt OK	WL Dev. No/name	3 384	XR
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	102	Lost battery of wireless device (PIR, MC, FL, FD)	WLDev##Batt Lost	WL Dev. No/name	1 381	US
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	103	Wireless device Restored (PIR, MC, FL, FD)	WLDev##Restore	WL Dev. No/name	3 381	UR
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	104	Dirty smoke chamber of wireless fire alarm detector (FD)	WLDev##Clear Fire	WL Dev. No/name	1 616	AS
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	105	Dirty smoke chamber of wireless fire alarm detector Restored (FD)	WLDev##Fire Rest	WL Dev. No/name	3 616	AN
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	106	Radio frequency jamming of wireless expander	WLExp RF Jamming	Device No/name	1 344	XQ
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	107	Radio frequency jamming of wireless expander Restored	WLExp RF Jam Rest	Device No/name	3 344	XH
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	108	Loss of main power supply of device	D## AcLost	Device No/name	1 342	ET
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	109	Loss of main power supply of device Restore	D## Ac Restore	Device No/name	3 342	ER
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	110	Problem with battery of wireless device (PIR, MC, FL, FD)	WLDev##Batt Trbl	WL Dev. No/name	1 338	ET
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	111	Problem with battery of wireless device Restore (PIR, MC, FL, FD)	WLDev##Batt Rest	WL Dev. No/name	3 338	ER
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	112	Blown up fuse of device	D## Fuse Blown	Device No/name	1 337	ET
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	113	Blown up fuse of device Restore	D## Fuse Rest	Device No/name	3 337	ER
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	118	Communication with monitoring station failed	Comm Ch Trouble	GPRS	1350	YS
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	133	The number of entered incorrect codes (address 16 in the Manager's menus) is reached.	Remote Access Code	Tamper	-	JA
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	134	Forced arming when there is a trouble with the communication (PSTN/GPRS) and the connection of the siren to PGM5 (Eclipse 32) is incorrect – no balancing resistor is connected between +PGM and +AUX terminals.	Prevent-Settings	-	1455	CD
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	135	Low battery (trouble with the battery) of wireless siren (SIR)	WLDev PGM## Batt Low	PGM No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	136	Battery Restore of wireless siren (SIR)	WLDev PGM## Batt OK	PGM No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	137	Wireless siren Lost (SIR)	WLDev PGM## Lost	PGM No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	138	Wireless siren Restore (SIR)	WLDev PGM## Restore	PGM No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	139	Trouble with tamper switch of wireless siren (SIR)	WLDev PGM## Tamper	PGM No/name	-	-
① ② ③ ④ ⑤ ⑥ ⑦ ⑧	140	Tamper switch of wireless siren Restore (SIR)	WLDev PGM## Tamper Restore	PGM No/name	-	-


(1) – The events are not sent to the monitoring software.

**Supported event numbers for transmitting via different SW versions of Eclipse VD:**


Eclipse VD	Event Numbers
Prior to SW 2.00	1, 3, 5, 7, 9, 58, 59, 61, 63, 72, 74, 75, 91, 93
SW 2.0 - 2.15	1, 3, 5, 7, 9, 11, 17, 19, 35, 38, 41, 42, 45, 46, 49, 50, 52, 53, 58, 59, 61, 63, 65, 72, 73, 74, 75
SW 2.16	1, 3, 5, 7, 9, 11, 13, 17, 19, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 58, 59, 61, 63, 65, 72, 73, 74, 75, 91, 93

**Supported event numbers for transmitting with a melody signal, when the Voice Dialer is enabled (address 6100) but it is missing or is out of order: 1, 3, 5, 7, 9, 17, 59, 61, 63, 91, 93**

### APPENDIX 2. FIRE DELAY Operation Algorithm



### APPENDIX 3. VD/DTMF Operation Algorithm



**If during 40 seconds time interval there is no action – pressed button, the system will break up the line.**


*\* Note: When operating with Eclipse 8 the messages for entering of Area number are missed and the user has not to enter an Area number. When operating with Eclipse 8+/16 the correspondence of the Areas is: Area 1 (A), Area 2 (B) and Area 3 (C).*

### APPENDIX 4. Text Tree-Structure Menus ECLIPSE Series


There are several ways for setting parameters in text menus – that depends on the menu:


- **When the submenu allows choosing only one option** or attribute, or parameter from a list, the installer scrolls down to the desired one and confirms his choice with  button. The set option is displayed with a “check” mark in front of it. The exit of the submenu is automatic. See Example 1.


- **When the submenu allows choosing of several options** or attributes, or parameters at the same time then the installer has to scroll down to each one and to enable it with pressing the  button. The set option is displayed with a “check” mark in front of it. The installer has to move to the next option using the arrow buttons and so on. To disable an option, scroll down to it and press  button – the “check” mark will be deleted. When all the desired options are selected, the choice is confirmed with  button. See Example 2.





The text menus are available only in operation with LCD keyboard!  
 The provided text tree structures are complete for Eclipse 99 control panel.  
 For resources of supported User Codes, Zones, Areas, etc. in Eclipse 8/8+/16/32 - refer to the detailed descriptions in item 7!

















**Note:** The menus are available only for ECLIPSE 32/99 control panel.







To the 1. MAINTENANCE Menu

- 1) The menus are accessible only for LED Keyboards.
- 2) The menus are accessible only for proximity card readers [PRX].
- 3) The menus are accessible only for Eclipse WL wireless expander [WEXP].

**NOTE!**  
Available areas:  
Eclipse 8+: 1-3  
....  
Eclipse 16: 1-3  
Eclipse 32: 1-8  
Eclipse 99: 01-16

**NOTE!**  
Use buttons:  
0 to DISABLE  
1 to ENABLE

**\* NOTE**  
When the option EN50131 G2/G3 is enabled, the system automatically sets the following:  
3. OPTIONS: CONFIDENTIAL and CONF EXIT are always enabled  
  
*Option MAIN SCREEN is available for LCD Keyboards only.*

In the menus are set combinations of operation in the areas – arming type and/or disarming for every area. Use the buttons to set the respective operation:

Button	Operation	Indication
[0]	No change of the Area state	[*]
[1]	Disarming	[d]
[2]	Full ARM	[f]
[3]	Stay ARM	[s]
[4]	Sleep ARM	[S]

Supported wireless devices BRAVO Series:

Device	Description
PIR	Wireless motion detector
MC	Wireless magnetic contact
FLD	Wireless flood detector
FIRE	Wireless fire detector
SIRN	Wireless outdoor siren
REMT	Remote key fob

## APPENDIX 5. Style Diagrams for Zone Connection

(The value is checked in menu "4. INPUTS – 5. ZONES – zz. ZONE – 9. LINE RESIST" (ADDRESS 2zz9), where "zz" is a zone number)

**LEGEND:** "✓" means "lower than" value; "↗" means "higher than" value.

### SINGLE ZONE CONNECTION

**1** N.C. WITHOUT EOL

Value	Description
✓ 1.5 kΩ	The zone is closed
1.5 kΩ ↗	The zone is open

**2** N.C. WITH EOL

Value	Description
✓ 0.75 kΩ	The zone is open
0.75 - 1.5 kΩ	The zone is closed
1.5 kΩ ↗	The zone is open

**3** N.O. WITH EOL

Value	Description
✓ 0.75 kΩ	The zone is open
0.75 - 1.5 kΩ	The zone is closed
1.5 kΩ ↗	The zone is open

**4** N.C. WITHOUT EOL, WITH TAMPER AND TAMPER RECOGNITION

Value	Description
✓ 0.75 kΩ	The zone is closed
0.75 - 5.6 kΩ	The zone is open
5.6 kΩ ↗	Tamper break-off

**5** N.C. WITH EOL, WITH TAMPER AND WIRE FAULT RECOGNITION

Value	Description
✓ 0.75 kΩ	Tamper short-circuit
0.75 - 1.5 kΩ	The zone is closed
1.5 - 5.6 kΩ	The zone is open
5.6 kΩ ↗	Tamper break-off

### DOUBLING ZONE CONNECTION

**6** N.C. WITHOUT EOL

Value	Description
✓ 0.5 kΩ	The two zones are closed
0.5 - 1.5 kΩ	First zone open, second zone closed
1.5 - 2.7 kΩ	First zone closed, second zone open
2.7 kΩ - ∞	The two zones are open

**7** N.C. NO EOL, WITH TAMPER RECOGNITION

Value	Description
✓ 0.5 kΩ	The two zones are closed
0.5 - 1.5 kΩ	First zone open, second zone closed
1.5 - 2.7 kΩ	First zone closed, second zone open
2.7 - 4.9 kΩ	The two zones are open
4.9 kΩ ↗	Tamper break-off

**8** N.C. WITH EOL, WITH TAMPER RECOGNITION

Value	Description
✓ 0.75 kΩ	Tamper short-circuit
0.75 - 1.5 kΩ	The two zones are closed
1.5 - 2.5 kΩ	First zone open, second zone closed
2.5 - 3.7 kΩ	First zone closed, second zone open
3.7 - 4.9 kΩ	The two zone are open
4.9 kΩ ↗	Tamper break-off

**9** N.C. WITHOUT EOL, WITHOUT TAMPER

Value	Description
✓ 0.5 kΩ	Tamper short-circuit
0.5 - 0.75 kΩ	The two zones are closed
0.75 - 1.5 kΩ	First zone closed, second zone open
1.5 - 2.7 kΩ	First zone open, second zone closed
2.7 kΩ ↗	The two zones are open

# Teletek

electronics

[www.teletek-electronics.com](http://www.teletek-electronics.com)

Address: Bulgaria, Sofia - 1407, 14A Srebarna Str.  
Tel.: +359 2 9694 800, Fax: +359 2 962 52 13  
e-mail: [info@teletek-electronics.bg](mailto:info@teletek-electronics.bg)