## How to mount Brandplate on StreetSiren DoubleDeck?

Updated August 4, 2020

## In order to mount the faceplate:

- **1.** Turn off the external power of the siren, if connected.
- **2.** Unscrew the fixing screw from the bottom of the siren with a Ph 2 screwdriver if the siren is mounted on the SmartBracket mounting plate.
- **3.** Remove the siren from the SmartBracket mounting panel, turning it counterclockwise if the siren is mounted on the mounting plate.
- **4.** Turn off the device by pressing the power button for 3 seconds.
- **5.** Turn off the external power supply (if applicable) by unscrewing the terminal blocks and disconnecting the power wires.
- **6.** Place the front side of the siren on a hard surface and unscrew the 4 screws on the rear panel with a PH2 screwdriver.
- **7.** Turn the siren over while holding the front and back of the body. Remove the protective plastic panel.



When installing the panel, do not remove the plastic frame and do not remove the LED strip from the seat!

**8.** Drill a hole in the plastic protective plate at the defined location.



- **9.** Mount Brandplate on the protective plastic panel. When properly mounted, the Brandplate clamps the rubber for the tamper on the protective plastic panel.
- **10.** Fix the Brandplate to the protective plastic panel using the bundled bolt.
- **11.** Fit the protective plastic panel in place (the Ajax logo on the connection side of the LED strip to the board) with little effort. The properly mounted plastic panel will protrude above the LED frame no more than 1.0 to 1.5 mm.
- **12.** Turn the siren over while holding the front and back of the body, and tighten 4 screws.
- **13.** Turn on the siren and check the status of tampers in the app.